

# TOSHIBA

FILE NO. 810-200451


## SERVICE MANUAL



**SHOWVIEW**

## DVD VIDEO RECORDER/ VIDEO CASSETTE RECORDER

# *D-VR3SB* *D-VR3SG* *D-VR3SF*



Dec., 2004<sup>©</sup>



# CONTENTS

- 1. Precautions**
  - 2. Reference Information**
  - 3. Product Specification**
  - 4. Operating Instructions**
  - 5. Disassembly and Reassembly**
  - 6. Alignment and Adjustments**
  - 7. Circuit Operating Descriptions**
  - 8. VCR Deck Operating Descriptions**
  - 9. Troubleshooting**
  - 10. Exploded View and Parts List**
  - 11. Electrical Parts List**
  - 12. Block Diagram**
  - 13. Wiring Diagram**
  - 14. PCB Diagrams**
  - 15. Schematic Diagrams**
-



# MEMO

---



# 1. Precautions

## 1-1 Safety Precautions

1) Before returning an instrument to the customer, always make a safety check of the entire instrument, including, but not limited to, the following items:

(1) Be sure that no built-in protective devices are defective or have been defeated during servicing. (1) Protective shields are provided to protect both the technician and the customer. Correctly replace all missing protective shields, including any removed for servicing convenience.

(2) When reinstalling the chassis and/or other assembly in the cabinet, be sure to put back in place all protective devices, including, but not limited to, nonmetallic control knobs, insulating fish papers, adjustment and compartment covers/shields, and isolation resistor/capacitor networks. Do not operate this instrument or permit it to be operated without all protective devices correctly installed and functioning.

(2) Be sure that there are no cabinet openings through which adults or children might be able to insert their fingers and contact a hazardous voltage. Such openings include, but are not limited to, excessively wide cabinet ventilation slots, and an improperly fitted and/or incorrectly secured cabinet back cover.

(3) Leakage Current Hot Check-With the instrument completely reassembled, plug the AC line cord directly into a 120V AC outlet. (Do not use an isolation transformer during this test.) Use a leakage current tester or a metering system that complies with American National Standards Institute (ANSI) C101.1 Leakage Current for Appliances and Underwriters Laboratories (UL) 1270 (40.7). With the instrument's AC switch first in the ON position and then in the OFF position, measure from a known earth ground (metal water pipe, conduit, etc.) to all exposed metal parts of the instrument (antennas, handle brackets, metal cabinets, screw-heads, metallic overlays, control shafts, etc.), especially any exposed metal parts that offer an electrical return path to the chassis.

Any current measured must not exceed 0.5mA. Reverse the instrument power cord plug in the outlet and repeat the test. See Fig. 1-1.

Any measurements not within the limits specified herein indicate a potential shock hazard that must be eliminated before returning the instrument to the customer.




Fig. 1-1 AC Leakage Test

(4) Insulation Resistance Test Cold Check-(1) Unplug the power supply cord and connect a jumper wire between the two prongs of the plug. (2) Turn on the power switch of the instrument. (3) Measure the resistance with an ohmmeter between the jumpered AC plug and all exposed metallic cabinet parts on the instrument, such as screwheads, antenna, control shafts, handle brackets, etc. When an exposed metallic part has a return path to the chassis, the reading should be between 1 and 5.2 megohm. When there is no return path to the chassis, the reading must be infinite. If the reading is not within the limits specified, there is the possibility of a shock hazard, and the instrument must be repaired and rechecked before it is returned to the customer. See Fig. 1-2.






Fig. 1-2 Insulation Resistance Test

- 2) Read and comply with all caution and safety related notes on or inside the cabinet, or on the chassis.
- 3) Design Alteration Warning-Do not alter or add to the mechanical or electrical design of this instrument. Design alterations and additions, including but not limited to, circuit modifications and the addition of items such as auxiliary audio output connections, might alter the safety characteristics of this instrument and create a hazard to the user. Any design alterations or additions will make you, the servicer, responsible for personal injury or property damage resulting therefrom.
- 4) Observe original lead dress. Take extra care to assure correct lead dress in the following areas:  
(1) near sharp edges, (2) near thermally hot parts (be sure that leads and components do not touch thermally hot parts), (3) the AC supply, (4) high voltage, and (5) antenna wiring. Always inspect in all areas for pinched, out-of-place, or frayed wiring. Do not change spacing between a component and the printed-circuit board. Check the AC power cord for damage.
- 5) Components, parts, and/or wiring that appear to have overheated or that are otherwise damaged should be replaced with components, parts and/or wiring that meet original specifications. Additionally, determine the cause of overheating and/or damage and, if necessary, take corrective action to remove any potential safety hazard.
- 6) Product Safety Notice-Some electrical and mechanical parts have special safety-related characteristics which are often not evident from visual inspection, nor can the protection they give necessarily be obtained by replacing them with components rated for higher voltage, wattage, etc. Parts that have special safety characteristics are identified by shading, an (  ) or a (  ) on schematics and parts lists. Use of a substitute replacement that does not have the same safety characteristics as the recommended replacement part might create shock, fire and/or other hazards. Product safety is under review continuously and new instructions are issued whenever appropriate.

## 1-2 Servicing Precautions

---

**CAUTION :** Before servicing units covered by this service manual and its supplements, read and follow the Safety Precautions section of this manual.

**Note :** If unforeseen circumstances create conflict between the following servicing precautions and any of the safety precautions, always follow the safety precautions. Remember: Safety First.

### 1-2-1 General Servicing Precautions

- (1) a. Always unplug the instrument's AC power cord from the AC power source before (1) re-moving or reinstalling any component, circuit board, module or any other instrument assembly, (2) disconnecting any instrument electrical plug or other electrical connection, (3) connecting a test substitute in parallel with an electrolytic capacitor in the instrument.
- b. Do not defeat any plug/socket B+ voltage interlocks with which instruments covered by this service manual might be equipped.
- c. Do not apply AC power to this instrument and /or any of its electrical assemblies unless all solid-state device heat sinks are correctly installed.
- d. Always connect a test instrument's ground lead to the instrument chassis ground before connecting the test instrument positive lead. Always remove the test instrument ground lead last.

**Note :** Refer to the Safety Precautions section ground lead last.

- (2) The service precautions are indicated or printed on the cabinet, chassis or components. When servicing, follow the printed or indicated service precautions and service materials.
- (3) The components used in the unit have a specified flame resistance and dielectric strength. When replacing components, use components which have the same ratings. Components identified by shading, by ( $\triangle$ ) or by ( $\nabla$ ) in the circuit diagram are important for safety or for the characteristics of the unit. Always replace them with the exact replacement components.

- (4) An insulation tube or tape is sometimes used and some components are raised above the printed wiring board for safety. The internal wiring is sometimes clamped to prevent contact with heating components. Install such elements as they were.

- (5) After servicing, always check that the removed screws, components, and wiring have been installed correctly and that the portion around the serviced part has not been damaged and so on. Further, check the insulation between the blades of the attachment plug and accessible conductive parts.

### 1-2-2 Insulation Checking Procedure

Disconnect the attachment plug from the AC outlet and turn the power ON. Connect the insulation resistance meter (500V) to the blades of the attachment plug. The insulation resistance between each blade of the attachment plug and accessible conductive parts (see note) should be more than 1 Megohm.

**Note :** Accessible conductive parts include metal panels, input terminals, earphone jacks, etc.

## 1-3 ESD Precautions

---

### Electrostatically Sensitive Devices (ESD)

Some semiconductor (solid state) devices can be damaged easily by static electricity.

Such components commonly are called Electrostatically Sensitive Devices(ESD). Examples of typical ESD devices are integrated circuits and some field-effect transistors and semiconductor chip components. The following techniques should be used to help reduce the incidence of component damage caused by static electricity.

- (1) Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, obtain and wear a commercially available discharging wrist strap device, which should be removed for potential shock reasons prior to applying power to the unit under test.
- (2) After removing an electrical assembly equipped with ESD devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.
- (3) Use only a grounded-tip soldering iron to solder or unsolder ESD devices.
- (4) Use only an anti-static solder removal devices. Some solder removal devices not classified as "anti-static" can generate electrical charges sufficient to damage ESD devices.
- (5) Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ESD devices.
- (6) Do not remove a replacement ESD device from its protective package until immediately before your are ready to install it.(Most replacement ESD devices are packaged with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive materials).

- (7) Immediately before removing the protective materials from the leads of a replacement ESD device, touch the protective material to the chassis or circuit assembly into which the device will be installed.

**CAUTION :** Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.

- (8) Minimize bodily motions when handling unpackaged replacement ESD devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity sufficient to damage an ESD device).

## 1-4 Handling the optical pick-up

The laser diode in the optical pick up may suffer electrostatic breakdown because of potential static electricity from clothing and your body.

The following method is recommended.

- (1) Place a conductive sheet on the work bench (The black sheet used for wrapping repair parts.)
  - (2) Place the set on the conductive sheet so that the chassis is grounded to the sheet.
  - (3) Place your hands on the conductive sheet (This gives them the same ground as the sheet.)
  - (4) Remove the optical pick up block
  - (5) Perform work on top of the conductive sheet. Be careful not to let your clothes or any other static sources touch the unit.
- ◆ Be sure to put on a wrist strap grounded to the sheet.
  - ◆ Be sure to lay a conductive sheet made of copper etc. Which is grounded to the table.




Fig.1-3

- (6) Short the short terminal on the PCB, which is inside the Pick-Up ASS'Y, before replacing the Pick-Up. (The short terminal is shorted when the Pick-Up Ass'y is being lifted or moved.)
- (7) After replacing the Pick-up, open the short terminal on the PCB.

## MEMO

---

## 2. Reference Information

---

### 2-1 Introduction to DVD

---

#### 2-1-1 The Definition of DVD

DVD is the next generation medium and is the acronym of the Digital Versatile Disc or the Digital Video Disc, which maximizes the saving density of the disk surface using the MPEG-2 compression technology to enable the storage of 17G bytes of data on the same size CD.

##### 1) 7 times the storage capacity of the conventional CD





- Minimized the track pitch and pit size to 1/2 of conventional CD.
- Uses red laser with short-wavelength of 650nm (635nm).

##### • DVD Vs. CD-ROM

	CD-ROM	CD-R/RW	DVD-ROM	DVD-R/RW	DVD-RAM
Disc Thickness	1.2mm	1.2mm	0.6*2mm	0.6*2mm	0.6*2mm
Lens NA	0.45	0.45(0.5)	0.6	0.6	0.6
Laser wavelength	780um	780um	650um	650um	650um
Track pitch	1.6pm	1.6pm	0.74pm	0.74pm	0.615pm
Capacity	0.65GB	0.65GB	4.7GB	4.7GB	4.7GB
Track structure	Pit train	Groove	Pit train	Groove	Land/Groove

##### 2) Disc Formats

DVD consists of two 0.6mm discs attached together, enabling access to the upper and lower side of the disk, and 4 sides could be used at maximum.



## 2-1-2 DVD Types

FORMAT	TYPE	APPLICATIONS
<b>DVD-Video</b>	Playback Only	High quality image and sound for movies and other video media.
<b>DVD-ROM</b>	Read Only	Multi-functional, multi-media software that requires large storage capacity.
<b>DVD-Audio</b>	Playback Only	High quality sound that exceeds the CD, multi-channel Audio.
<b>DVD-R</b>	1 Time Recording	As with CD-R, write only once
<b>DVD-RAM</b>	Rewritable (more than 100,000times)	This can be virtually used as hard-disk, with a random read-write access
<b>DVD-RW</b>	Rewritable (About 1000times)	Similar to DVD-RAM except than its technology features a sequential read-write access more like phonograph than a hard disk.



## 2-2 DVD-Video Fromat

### 2-2-1 Main Features

- 1) Able to store up to 160 minutes of Movie by utilizing the MPEG-2 compression technology. (Aver. 133min.)
- 2) Enables more than 500 lines of horizontal resolution. (Class corresponding to the Master Tapes used in broadcasting stations)
- 3) Provides Dolby Digital 5.1ch Surround 3D sound, which enables theater quality sound (NTSC area).
  - For PAL areas, 1 of either MPEG-2 Audio or Dolby Digital must be selected.
- 4) Multi-Language
  - Able to store up to 8 languages of dubbing.
  - Able to store up to 32 subtitle languages.
- 5) Multi-Aspect Ratio  
3TV Mode alternatives ; 16:9 Wide Screen (DVD Basic)/4:3 Pan & Scan/Letter Box.
- 6) Multi-Story  
Possible to implement Interactive Viewing which enables the user to select the scenario.
- 7) Multi-Angle  
Able to view the camera angle you selected among the scenes recorded with multiple camera angles.

**Note ;** The above media features must have the DVD Title that contains the appropriate contents to function properly.

### 2-2-2 Audio & Video Specifications

Classification		DVD-Video		Video-CD	LD
VIDEO	Compression	MPEG-2		MPEG-1	Analog
	Pixel	720 x 480		352 x 240	
	Horizontal resolution	Max. 500 Lines		Max. 250 Lines	Max.420 Lines
	Compression rate	1/40		1/140	Analog
	Transmission speed	Max. 9.8Mbps (variable)		1.15Mbps (fixed)	
	TV aspect	16:9 / 4:3		4:3	4:3
AUDIO	Audio	Max. 8 streams		2CH stereo	<div style="border: 1px solid black; padding: 2px;">           2 Analog CH.            2 Digital CH.            (16Bit/44.1KHz)         </div>
	Recording type	Dolby Digital	Linear PCM	MPEG-1 Layer 2	
	Transmission rate	448Kbps/stream	6.144Mbps/stream	224Kbps	or <div style="border: 1px solid black; padding: 2px;">             1 Analog CH.              1 Stream of Dolby Digital              2 Digital CH.              (16Bit/44.1KHz)           </div>
	Channel	5.1CH/stream	8CH/stream	2CH	
	Sampling frequency	48KHz	16, 20, 24Bit/48, 96KHz	16Bit/44.1KHz	

2-2-3 Detailed Feature



DVD-Video Feature 1	When Developing the DVD Software, various addition and modification is possible.
---------------------	--

As the storage capacity increases, the DVD-Video separates the main data and the additional data such as the Multi-Function into different data areas, enabling the control of time-data ratio to provide the format that enables the flexible Software development

- 1 Movie (3.5Mbps)
  - + Subtitle (1 Language)
  - + Surround Audio (1 Language)
  - = 160min storage (4.673Gbytes)
- 1 Movie (3.5Mbps)
  - + Subtitle (4 Language)
  - + Surround Audio (4 Language)
  - = 160min storage (4.680Gbytes)
- 1 Music Video (4Mbps)
  - + 2ch High quality Audio (96kHz/24bit)
  - = 72min storage (4.648Gbytes)

DVD-Video Feature 2	Application of the MPEG-2 compression technology.
---------------------	---

DVD-Video uses the variable compression technology, the MPEG-2 to compress the moving image optimally, minimizing the Data loss to Provide a clear, natural screen while increasing the storage time.

DVD-Video	<ul style="list-style-type: none"><li>• MPEG-2 (Variable compression : Max. 1/40)<ul style="list-style-type: none"><li>• Field unit compression.</li><li>• Compression rate change according to the amount of Data.</li><li>• Differentiates the still image anf the moving image compression rete, reducing Data loss and enables efficient compression.</li></ul></li></ul> 
Video-CD	<ul style="list-style-type: none"><li>• MPEG-1 (Fixed compression : Max. 1/140)<ul style="list-style-type: none"><li>• Frame unit compression.</li><li>• Compresses all data using the same ratio.</li></ul></li><li>- Fast movements are jagged, and unnatural</li></ul> 

**DVD-Video Feature 3****High quality surround audio.**

DVD-Video can store the audio using the 5.1ch Dolby Digital compression or the advanced Linear PCM method, providing the better-than-CD quality and theater like audio quality.

- **Dolby Digital (AC-3)**
  - Unlike the traditional Dolby pro-Logic method, the Dolby Digital method separates all 5 main channels (Front L/R, Center, Surround (Rear) L/R) and the Sub woofer to provide live surround audio.
  - Using the Down Mix method, the conventional Dolby Pro-Logic and Stereo are all compatible.
  - Each separated channels are played back at CD quality sound. (Frequency band: 20Hz ~ 20KHz)
- **Linear PCM (Pulse Code Modulation)**
  - Provides the high quality Digital sound without the audio data compression.
  - Various Digital Recordings are possible as shown in the table to the right.

Sampling Frequency	Bit Rate
48KHz	16bit
	20bit
	24bit
96KHz	16bit
	20bit
	24bit

- **Dolby Digital compatible Audio Mode**

Audio Coding Mode	Channel Format					Remark
		Front		Surround (Rear)		
	L	C	R	L	R	
1/0		0				Mono
2/0	0		0			Stereo
3/0	0	0	0			Surround
2/1	0		0	Mono		
3/1	0	0	0	Mono		
2/2	0		0	0	0	
3/2	0	0	0	0	0	

#### DVD-Video Feature 4


#### Multi-Language

- Audio Dubbing - Max. 8 Languages
- Subtitle - Max. 32 Languages. Capable of storing, and selectiong.
- Linear PCM (Pulse Code Modulation)

#### DVD-Video Feature 5

#### Multi-Aspect

- Unlike the conventional VCD or LD, DVD-Video has the default of 16:9 Wide, and can be viewed using the conventional 4:3 TV, enabling the expansion of viewer selection capabilities.
- 16 : 9 TV : Wide Mode (16:9 Wide Full Screen)
- 4 : 3 TV : Letter Box Mode, Pan & Scan Mode




**Note ;** Only enable to be worked correctly by an appropriate data supported this function in Disc.

#### DVD-Video Feature 6

#### Multi-Angle

- Up to 9 angles of view may be stored, enabling the viewer to select a specific viewpoint at a given time.  
--> Especially, for the Music Video and Sports Title, this provides a more lively image of the scene.



**Note ;** Only enable to be worked correctly by an appropriate data supported this function in Disc.

## DVD-Video Feature 7

## Multi-Story

- DVD-Video provides the environment suitable for the bi-directional Software development, providing multiple scenarios. This feature enables the Multi-Story function.

## OPTION


## Parental Lock

- For the titles that are not suitable for children viewing, Parental Locks are set, requesting user defined passwords for viewing
- Parental Locks may be set on specific frames of the Title, enabling the player to skip those frames during playback.

## COPYRIGHT

## Regional Code &amp; Macrovision

- Classify the world into 6 regions, and if the DVD Title and the Player's "Regional Code" do not agree, playback is prohibited.
- **Regionnal Coding is optional for the Soft developers (Region 0 All Code), but the Hardware developers must adopt the appropriate regionnal code for sale.**
  - Region 1 : The United States and its territories, Canada.
  - Region 2 : Europe, Japan, Greenland, Egypt, South Africa, the Middle East.
  - Region 3 : Taiwan, Hongkong, Korea, South East Asia.
  - Region 4 : Mexico, South America, Australia, New Zealand.
  - Region 5 : Russia, Eastern Europe, India, Africa.
  - Region 6 : China.
  - Region 0 : Worldwide (All Code)




- Adoption of the Macrovision System disables the copying on to other media.

Remark	DVD-Video Authoring Process
--------	-----------------------------

- The image quality of the DVD-Video may vary according to the quality of the Master and the Authoring Process
  - The image quality of the DVD-Video varies according to the Digital Mastering Source such as the conventional LD, VCD, or Original Film.
  - Different Authoring Process are used according to the Software developers, and this may affect the DVD image quality.

• **Authoring Process**



## 2-3 Flash & Drive Firmware Update of a DVD Recorder-VCR

### WARNING

It is very important ; please read the below notice before updating your unit.  
The following events may interrupt the update process and MAY RESULT IN PERMANENT DAMAGE TO THE UNIT WHILE UPDATING.

- Unplugging the power cord.
- Power Outage.
- Dirt or Scratch in the disc.
- Open a disc tray during processing.

### 2-3-1 Main Flash Update procedure

- 1) Press OPEN/CLOSE to open the disc tray.
- 2) Insert the update CD-R disc, label facing up.
- 3) Press OPEN/CLOSE to close the disc tray.




[ Remote Control ]

After checking old and new version, select "Yes" or "No" with "◀" or "▶" on the remote control.

\* The indication of Version is "YYMMDD.xx.ModelName"

\* If you can't see the message above, try to use other new disc instead of current one.  
Generally, this caused by disc quality and by disc creating problem.

- 4) Press the ENTER button on the remote control.



You can see "LOAD" on Front Display.

- 5) It takes about 5 minutes to finish a update.  
The message on the screen will be displayed after finishing a update and the tray will be opened automatically. And then do not turn off the unit until it goes off automatically.




\* If the message above isn't displayed after 10 minutes more and you can conclude that this unit had a critical damage after a Power off, replace a old flash with new one due to Flash memory's Damage.  
(Location No. : DIC3 - Main PCB)

- 6) After removing a update disc, turn on the unit with power button and press REW and FF button on the front panel at the same time during 5 seconds. "CLR" will be displayed on the front display  
The next screen will be displayed. Check the update version number. The Flash update is ended.



## 2-3-2 Drive Firm Update procedure

- 1) Press OPEN/CLOSE to open the disc tray.
  - 2) Insert the update CD-R disc, label facing up.
  - 3) Press OPEN/CLOSE to close the disc tray.
- \* It takes about 1~2 minutes to show below message.




[ Remote Control ]

After checking old and new version, select "Yes" or "No" with "◀" or "▶" on the remote control.  
\* The indication of Version is "YYMMDD.xx.ModelName"

- \* If you can't see the message above, try to use other new disc instead of current one.  
Generally, this caused by disc quality and by disc creating problem.




- 4) Press the ENTER button on the remote control.



You can see "LOAD" on Front Display.

- 5) It takes about 1~2 minutes to finish a update.

The message on the screen will be displayed after finishing a update and the tray will be opened automatically. And then do not turn off the unit until it goes off automatically.



- 6) After removing a update disc, turn on the unit with power button and press REW and FF button on the front panel at the same time during 5 seconds.

"CLR" will be displayed on the front display and next screen will be displayed.

Check the update version number. Finally, the Drive Firmware update is ended.



## MEMO

### 3. Product Specification

<b>General</b>	Power requirements	220 ~ 240V, 50Hz
	Power consumption	45Watts
	Weight	4.1Kg
	Size	430mm(W) x 321mm(D) x 82mm(H)
	Operating ambient Temperature	+5°C to 35°C
	Installation Condition	Operation Position : Horizontal, Relative humidity : Below 75%
<b>Input</b>	Video Input	Euro Scart Socket : 1.0Vp-p(Vnbalanced) 750ohm
	Audio Input	Euro Scart Socket : -8dBm, 47Kohm unbalanced
<b>Output</b>	RF out	VHF 21-69(Initial CH60)
	Audio(DVD, VCR)	RCA jack, Euro Scart Socket
	Audio(DVD only)	Digital audio out (optical, coaxial, RCA jack)
	Video(DVD, VCR)	RCA jack, Euro Scart Socket
	Video(DVD only)	S-Video out, RGB out : Euro Scart Socket
<b>VCR</b>	Tape format	VHS type video tape, S-VHS type video tape(Playback only)
	Color system	PAL, NTSC
	Video S/N	Above 43dB(standard recording)
	Resolution	Above 240/lines(standard recording)
	Audio S/N	Above 68dB(Hi-Fi), 39dB(Mono)
	Audio frequency characteristics	20Hz - 20KHz(Hi-Fi)
<b>Recording</b>	Picture compression format	MPEG-II
	Audio compression format	Dolby AC-3 256kbps
	Recording Quality	LP (2 Mbps), SP (4Mbps), XP (8 Mbps)
	Video S/N ratio	Min. 50dB at standard recording
	Audio S/N ratio	Min. 85dB
	Audio frequency characteristics	20 Hz ~ 20 KHz
<b>Disc</b>	Play back	DVD-Video , Audio-CD
	Recorder and play back	DVD-RAM, DVD-RW, DVD-R

**MEMO**

# 4. Operating Instructions

## Getting Started

### Before Reading the User's Manual

Make sure to read the following terms before reading the user's manual.

Icons that will be used in manual	
Icon	Term
	DVD
	RAM
	RW
	R
	CD
	JPEG
	MP3
	NOTE
	Preliminary

### About the use of this user's manual

- 1) Be sure to be familiar with Safety Instructions before using this product. (See pages 2-7)
- 2) If a problem occurs, check for Troubleshooting.

### Copyright

©2004 Toshiba Corporation.  
All rights reserved. No part or whole of this user's manual may be reproduced or copied without the prior written permission of Toshiba Corporation.

12 - English

### How to use the DVD Recorder-VCR

#### Step 1 Select the disc type

This unit can record on the following types of discs. If you want to repeatedly record on the same disc or you want to edit the disc after recording, select a rewritable DVD-RW or DVD-RAM type disc. If you want to save a recording without any changes, choose a non-rewritable DVD-R.



#### Step 2 Format the disc to start recording

Unlike a VCR, the recorder automatically starts formatting when an unused disc is inserted. This is required for the preparation of recording on a disc.

##### Using a DVD-RAM

This type of disc can be formatted in DVD-Video Recording format (VR mode). You can edit recorded images and create a playlist in a specific sequence according to your requirements.

##### Using a DVD-RW

This type of disc can be formatted in either DVD-Video format (Video mode) or DVD-Video Recording format (VR mode). For an unused disc, a message that asks whether to format in VR mode or not is displayed. You can play a video mode disc on various DVD components. A VR mode disc allows more varied editing.

##### Using a DVD-R

This type of disc can be formatted in DVD Video format. After formatting is complete, you can record on the disc. You can play this type of disc on various DVD components only when they have been finalised.

- You can only use one format on a DVD-RW.
- You can change the DVD-RW format to another format. It should be noted that the data of the disc may be lost when changing formats.

#### Step 3 Recording

There are two different recording methods: Direct Recording and Timer Recording. Timer recording is classified as recording type: Once, Daily or Weekly or recording mode: XP (high quality mode), SP (standard quality mode), LP (long recording mode) and EP (extended mode) according to the recording mode.

#### Step 4 Playing

You can select the title you want to play in a displayed menu and then immediately start playback.

A DVD consists of sections, called titles, and sub sections, called chapters.

During recording, a title is created between two points where you start and stop recording. DVD-RW/DVD-R discs(in Video mode) can automatically create chapters according to the recording mode when finalised.

#### Step 5 Editing a recorded disc

Editing on discs is easier than conventional video tapes. The recorder supports many different edit functions, possible only with DVDs.

With a simple and easy edit menu, you can operate various edit functions, such as delete, copy, rename, lock, etc., on a recorded title.

##### Creating a playlist (DVD-RAM/DVD-RW in VR mode)

With this recorder, you can create a new playlist on the same disc and edit it without the change of the original recording.

#### Step 6 Finalising & Playing on other DVD components

To play your DVD on other DVD components, finalising may be necessary. First, finish all editing and recording operations, then finalise the disc.

##### When using a DVD-RW disc in VR Mode

Although finalising is generally unnecessary when playing the disc on a VR Mode compatible component, a finalised disc should be used for playback on that type of component.

##### When using a DVD-RW disc in Video Mode

The disc should be finalised first to enable playback on anything other than this recorder. No more editing or recording can be made on the disc once it has been finalised.

To enable recording on the disc again, Disc should be unfinalised.


##### When using a DVD-R disc

You should finalise the disc to play it on a component other than this recorder. You cannot edit or record on the disc once it has been finalised.

English - 13


Description

Front Panel




1. DVD DECK
2. DVD OPEN/CLOSE BUTTON
3. VCR DECK
4. VCR EJECT BUTTON
5. ON/STANDBY BUTTON
6. INPUT SELECT BUTTON
7. S-VIDEO INPUT JACK
8. VIDEO INPUT JACK
9. AUDIO L/R INPUT JACK
10. DV IN JACK
11. PROGRAM V/I/A BUTTON
12. FRONT PANEL DISPLAY
13. DVD/VCR SELECT BUTTON
14. TIME SLIP BUTTON
15. RECORD BUTTON
16. REW/SKIP BUTTON (VCR/DVD)
17. STOP BUTTON
18. PLAY/STILL BUTTON
19. FF/SKIP BUTTON (VCR/DVD)
20. TO DVD BUTTON
21. TO VCR BUTTON

Front Panel Display




1. When the indicator is on, DVD is activated.
2. DVD-RAM is activated.
3. DVD-RW or DVD-R is activated.
4. When you watch STEREO channel or playback Hi-Fi VCR tapes, STEREO indicator lights.
5. VCR is activated.
6. DVD or CD media is loaded.
7. Record function is working.
8. The time, counter position or current deck status is indicated.
9. When you set a Timer recording, it or current deck status is indicated, this indicator is light.
10. VHS Videotape is loaded.

Rear Panel



1. S-VIDEO OUT JACK
2. AUDIO OUT L/R JACK
3. DIGITAL AUDIO OUT JACK (OPTICAL)
4. DIGITAL AUDIO OUT JACK (COAXIAL)
5. AUDIO/VIDEO JACK
6. AV1 (EURO AV) IN/OUT SCART (EURO-21) SOCKET
7. AV2 (DEC/EXT.) SCART (EURO-21) SOCKET
8. OUT TO TV CONNECTOR
9. AERIAL IN CONNECTOR

Tour of the Remote Control



- 1. **ON/STANDBY Button**
- 2. **NUMBER Button**
- 3. **IPC Button**
- 4. **VCR Button**
- 5. **DVD Button**  
Press this when you use a DVD.
- 6. **TV Control Buttons**
  - **VOLUME Button**  
TV volume adjustment
  - **PROG/TRK Button**  
Use this to select a TV programme.
- 7. **OPEN/CLOSE Button**  
To open and close the disc and Video cassette.
- 8. **VIDEO Plus+ Button**  
Press this when you use video plus+.
- 9. **Playback-related Buttons**  
Search, Skip, Stop, Play/Still

16 - English

Connecting & Setting Up

- Quick Overview ..... 17
- Unpacking ..... 18
- Connecting DVD Recorder-VCR to the TV using the RF Cable ..... 18
- Connecting the Scart Cable ..... 19
- Connecting the Video Cable ..... 20
- Connecting the Audio Cable ..... 21
- Connecting External Devices ..... 23
- Preparing the Remote Control ..... 24

Quick Overview

A Quick overview presented in this guide will give you enough information to start using the recorder.

- Step 1 : Unpacking
- Step 2 : Connecting DVD Recorder-VCR to the TV using the RF Cable
- Step 3 : Connecting the Scart Cable
- Step 4 : Connecting the Video Cable
- Step 5 : Connecting the Audio Cable
- Step 6 : Connecting External Devices
- Step 7 : Preparing the Remote Control

English - 17

## Step 1: Unpacking

### Accessories

Check for the supplied accessories below.

- Audio/Video Cable
- RF Cable for TV
- Remote Control
- Batteries for Remote Control (AA Size)
- User's Manual
- Dispose of batteries according to local environmental regulations. Do not put them in the household trash.

## Step 2: Connecting DVD Recorder-VCR to the TV using the RF Cable

To receive television programmes a signal must be received from one of the following sources:

- An outdoor aerial
- An indoor aerial
- A cable television network
- A satellite receiver

Make sure that both the television and the DVD Recorder-VCR are switched off before connecting the cables.

1 Remove the aerial or network input cable from the television.

2 Connect this cable to the 75Ω coaxial socket marked "ANT" on the rear of your DVD Recorder-VCR.


3 Plug the RF cable supplied into the socket on your DVD Recorder-VCR.

18 - English

4 Plug the other end of the RF cable into the connector previously used for the aerial on the television.

Note

- To obtain better quality pictures and sound on your television, you can also connect your DVD Recorder-VCR to the television via the SCART cable (see next page) if your television is equipped with this type of connection.




## Step 3: Connecting the Scart Cable

### Method 1 : Connecting DVD Recorder-VCR to the TV using the SCART Cable

You can connect your DVD Recorder-VCR to the television using the SCART cable if the appropriate input is available on the television. You thus:

- Obtain better quality sound and pictures
- Simplify the setting up procedure of your DVD Recorder-VCR
- Regardless of the type of connection chosen, you must always connect the RF cable supplied. Otherwise, no picture will be visible on the screen when the DVD Recorder-VCR is switched off.
- Make sure that both the television and the DVD Recorder-VCR are switched off before connecting the cables.

1. Connect the RF cable as indicated in the previous section.
2. Connect one end of the SCART cable to the AV1 (EURO AV) socket on the rear of the DVD Recorder-VCR.
3. Plug the other end into the appropriate connector on the television.




## Connections

### Method 2 : Connecting DVD Recorder-VCR to a Satellite Receiver or Other Equipment

You can connect your DVD Recorder-VCR to a Satellite receiver or other DVD Recorder-VCR using the SCART cable if the appropriate outputs are available on the equipment chosen. The following illustrations give a few examples of the connection possibilities.

1. **AV1 (EURO AV): By means of 21-pin Scart Cable**  
Plug the SCART Cable with satellite receiver or other equipment into the AV1 (EURO AV) socket on the rear of the DVD Recorder-VCR.  
After making this connection, select the source by pressing the INPUT SEL. button for the AV1 input sources.
2. **By means of RF Cable**  
After making this connection, you must preset the station received through the satellite tuner.  
RF output channel of the satellite receiver should be adjusted away from channel 60, which is used by the DVD Recorder-VCR, e.g. re-adjust to channel 65.




English - 19



1. **AV2 IN: By means of 21-pin Scart Cable**  
Plug the SCART Cable with satellite receiver or other equipment into the AV2 (DEC/EXT.) socket on the rear of the DVD Recorder-VCR.  
After making this connection, select the source by pressing the INPUT SEL. button for the AV2 input sources.
2. **By means of RF Cable**  
After making this connection, you must preset the station received through the satellite tuner. RF output channel of the satellite receiver should be adjusted away from channel 60, which is used by the DVD Recorder-VCR, e.g. re-adjust to channel 66.

After making this connection, you must preset the station received through the satellite tuner. RF output channel of the satellite receiver should be adjusted away from channel 60, which is used by the DVD Recorder-VCR, e.g. re-adjust to channel 66.



## Connections

### Step 4: Connecting the Video Cable

There are several ways to connect your DVD Recorder-VCR. Select one of the following video connecting methods that best suits you below.

- Method 1 : Connecting to a Video input jack
- Method 2 : Connecting to an S-video input jack


#### S-Video Modes

- S-Video is available only if your TV supports S-Video input. If S-Video output does not work, check the TV connections and the TV input selection settings.

#### Method 1 : Connecting to a video input jack

Connect a video(yellow) cable between the VIDEO (yellow) OUT jack on DVD Recorder-VCR and VIDEO(yellow) IN jack on the TV(or AV amplifier).


- You will enjoy regular quality images.
- Connect audio cables (white and red) between the ANALOG AUDIO OUT jack on the DVD Recorder-VCR and AUDIO IN jack on TV (or AV amplifier).



#### Method 2 : Connecting to an S-video input jack

Connect an S-video cable(not supplied) between the S-VIDEO OUT jack on DVD Recorder-VCR and S-VIDEO IN jack on the TV (or AV amplifier).

- You will enjoy high quality images. S-Video separates the picture element into black and white (Y) and color (C) signals to present clearer images than regular video input mode.




### Step 5 : Connecting the Audio Cable

There are several ways to connect your DVD Recorder-VCR. Select the audio connection that best suits you below.

- Method 1 : Connecting to your TV
- Method 2 : Connecting to a stereo amplifier (analog audio out / digital audio out)
- Method 3 : Connecting to an AV amplifier with a digital input jack.


#### Method 1 : Connecting to your TV

This connection will use your TV's speakers.




**Method 2 : Connecting to a stereo amplifier with analog input jacks**

If your stereo amplifier only has audio input jacks (L and R), use the analog audio out jacks.



**Method 3 : Connecting to an AV amplifier with the digital input jack**

If your AV amplifier only has a Dolby Digital or DTS decoder and a digital input jack, use this connection. To enjoy Dolby Digital or DTS sound, you must set up the audio settings. (See page 38)



**Step 6 : Connecting External Devices**

This allows you to connect your DVD Recorder-VCR to other external devices and view or record their outputs.


- **Method 1 :** Connecting a external devices to the AUX in jacks.
- **Method 2 :** Connecting a Camcorder to the DV IN jack.

Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

"DTS" and "DTS Digital Out" are trademarks of Digital Theater Systems, Inc.

**Method 1 : Connecting a external devices to the AUX jacks**

You can use the AUX jacks on the front panel of the DVD Recorder-VCR. You can record from connected equipment. When an input source is inserted into AUX while viewing TV, the input will be switched to AUX automatically.




**Connections**

**Method 2 : Connecting a Camcorder to the DV IN jack**

If your camcorder has a DV output jack, connect it to the DV input jack of your DVD Recorder-VCR.

- If your camcorder has a DV output jack, see page 79 for more information.




- Some models of DV format digital video cameras may support a different compression format. From such equipment, recording is not possible.
- Depending on the models of DV format digital video cameras, recording may not work properly or some functions may be disabled.

## Step 7 : Preparing the Remote Control

- Install Batteries in the Remote Control**
- Open the battery cover on the back of the remote.
  - Insert two AA batteries. Make sure that the polarities (+ and -) are aligned correctly.
  - Replace the battery cover.
- If remote does not operate properly:**
- Check the polarity + - of the batteries (Dry-Cell)
  - Check if the batteries are drained.
  - Check if remote sensor is blocked by obstacles.
  - Check if there is any fluorescent lighting nearby.


Dispose of batteries according to local environmental regulations. Do not put them in the household trash.



- Do not expose the remote sensor of the recorder to a strong light source such as direct sunlight or other illumination. If you do so, you may not be able to operate the recorder via the remote control.

## Setting the Remote Control

Your DVD Recorder-VCR remote control will work with Toshiba televisions and compatible brands.



**To determine whether your television is compatible, follow the instructions below.**

1. Switch your television on.
2. Point the remote control towards the television.
3. Hold down the TV button and enter the four-figure code corresponding to the brand of your television, by pressing the appropriate numeric buttons.

## Controllable TV Codes

Brand name	Brand code
AIWA	001 071 021 051
AKAI	021 024 031 043 051 052 061
BAIRD	011 024
BANG & OLUFSEN	041
BEKO	018
BLAUPUNKT	011 031 031
BRUNNEN	041 041 051
BUSH	011 031 051 051
CROWN	011 011 041 041 051 061
DANISH	051
DEANWOOD	041 041 051
DECCA	031 014 071 041 051 051
FERGUSON	031 071 031 019 021 031 031 031
064 061	
FNALUX	021 044 071 081 031 011 021
021 021 031 031 041 041	
FISHER	041 012 018 021 021 041 051
051	
FINNAI	001 018 041 041 051
011 021	
GOLDSTAR	011 031 031 041 051
GOODMANS	011 031 031 051
GRANDIA	011 024 021 051 051 051 051
GRUNDIG	011 071 021 021 031
HINARI	024 041 051 051
HITACHI	021 022 021 051 051 051 051 051
051 041 051	
INNO HIT	011 028 041 051 031 061
021 024 028 021 021 041 051	
ITT	021 024 028 021 021 041 051
ITT-NOKIA	021 024 028 021 021 041 051
JVC	011 043 051 051
LOCHE OPTA	041 051 051 051
LUOR	024 028 021 021 051
MAGNAVOX	051 071 018 021 041 041 051
051 051	
MARANTZ	001 051
MATSU	001 071 018 021 041 041 041
051 051 051	
MEIZ	041 033 031 041 041 041 051
MITSUBISHI	021 022 031 041 051 051 051
051 071	
NATIONAL	031 051 051 051 051 051 051
051	
NOKIA	021 024 028 021 041 041 051
NORDMENN	021 031 031 041 041 041 041
051 051	
OC-ARC	041
ORION	001 018 021 031 041 041 041
051 051 051	
PANASONIC	031 051 051 051 051 051 051
051	
PHILCO	001 011 018 021 021 031 031 041
051 051	
PHILIPS	001 018 021 041 041 051 051
051 051	
PIONEER	031 043 051 051 051
PROSCAN-HOISON	011 044 021 051
RCA	011 071 031 031 031 031 031
REALISTIC	031 031 031 031 031 031 031
051 041 021 031 051 051 071	

## Connections

## Connections

SABA	0281 0351 0381 0421 0431 0471 0541
SALISHO	0641 0651 0661 0671
SALORA	0231 0411 0441 0451 051
SAMSUNG	0231 0241 0251 0281 0411 0491 0501
0631 0661 0791	
SANYO	0021 0441 0481 0121 0171 0181 0201
0231 0241 0451 0511 0651 0671 0701	
0711 0721	
SCHNEIDER	0111 0511 0611 0281 0461 0501 0581
0591	
SEG	0081 0121 0151
SELEC	0031 0511 0611 0351 0501 0561
SHARP	0651 0511 0571 0201 0501
SIEMENS	0071 0221 0331 0571 0631
SINGER	0081 0471 0631
SINDYNE	0001 0091 0101 0131 0191 0231 0361
0471 0501 0551 0581 0651	
SONY	0441 0451 0571 0681
TANDBERG	0041 0301 0351 0431 0461 0571 0651
TATUNG	0091 0141 0171 0441 0451
TECHNICS	0371 0501 0511 0531 0761 0841 0911
1061	
TELEFUNKEN	0071 0281 0381 0421 0431 0521 0601
0621 0671	
TENSAI	0041
THOMSON	0381 0351 0371 0381 0391 0421 0461
0521 0541 0641 0671 1041	
THORN	0041 0071 0281 0291 0341 0421 0491
0601 0671	
UNIVERSUM	0021 0481
YAMAHA	0201 0501 0321 0331 0451 0511 0571
0651 0771	
ZANUSSI	0031 0051 0061 0351 0501 0561
ZENITH	0531

Result: If your television is compatible with the remote control, it will switch off.

It is now programmed to operate with the remote control.

■ If several codes are indicated for your television brand, try each one in turn until you find one that works.

■ Please note if TV manufacturer may change their remote control code without notice, this function may not work.

**You can then control the television using the following buttons.**


Button	Function
TV ON/STANDBY	Used to switch the television on and off.
INPUT SEL.	Used to select an external source.
VOL + or -	Used to adjust the volume of the television.
PROG/TRK (Δ or ∇)	Used to select the required channel.

■ The various functions will not necessarily work on all televisions. If you encounter problems, operate the television directly.

System Setup	
• On-Screen Menu Navigation	26
• Plug & Auto Setup	27
• Setting the Date and Time	28
• Presetting the Stations Automatically	29
• Presetting the Stations Manually	30
• Clearing a Preset Station	31
• Changing the Preset Manual Setup Table	32
• Setting the VCR Output Channel	33
• Setting Up the Language Features	34
• Setting Up the Audio Options	38
• Setting Up the Display (Video) Options	39
• Setting Up the Parental Control	40
• VCR Setting	41
• Intelligent Picture Control (IPC)	43
• Selection the Colour Mode	44
• Front Display	45
• NICAM	46
• AV1 Output	46

## On-Screen Menu Navigation

The on-screen menus allow you to enable or disable various functions on your DVD Recorder-VCR. Use the following buttons to open and navigate through the on-screen menus.



### 1 MENU Button

Press this button on the remote control while the DVD or VCR is in Stop or Play mode to open the on-screen MAIN MENU.

### 2 Up/Down and Left/Right

Use these buttons to move the selection bar  
▲▼◀▶ to cycle through the menu options.

### 3 OK Button

Press this button on the remote control to confirm any new settings.

### 4 RETURN Button

Press this button on the remote control to return to the last MENU screen displayed or to exit the on-screen MENU all together.

## Plug & Auto Setup


The DVD Recorder-VCR will automatically set itself up when it is plugged into the mains for the first time. TV stations will be stored in memory. The process takes a few minutes. The DVD Recorder-VCR will then be ready for use.

### 1 Connect the RF cable as indicated on page 19.


- Connecting Your DVD Recorder-VCR to the TV using the RF Cable.

### 2 Plug the DVD Recorder-VCR into the mains.


- "Auto" in the front panel display flickers.




### 3 Start the auto setup.



### 4 Start the auto scanning.




### 5 Wait current time and date are displayed automatically.



### 6 Check the date and time.

- if it is: Correct  
Press OK button then the data and time will be saved.
- if it is: Incorrect  
Refer to "Setting the Date and Time" menu, when you want to change the date and time.




## System Setup

## Setting the Date and Time

Your DVD Recorder-VCR contains a 24-hour clock and calendar used to:


- Automatically stop programme recording
- Preset your DVD Recorder-VCR to record a programme automatically. You must set the date and time
- You must set the date and time when you purchase the DVD Recorder-VCR
- Do not forget to reset the time when you change clocks from winter to summer time and vice versa.

- 1 With the unit in Stop mode, press the MENU button.




- 2 Using the ▲▼ buttons, move the selection bar to 'Setup' then press OK to select.

- 3 Select "Clock Set" using the ▲▼ buttons, then press the ► or OK button.



- 4 Press ◀▶ to select the hour, minutes, day, month and year.
  - The option selected highlight.



- 5 Press the ▲▼ button to increase or decrease the value.
  - The day of the week is displayed automatically.
  - You can hold the ▲▼ buttons down to scroll more quickly through the values.

- 6 Press OK button, then the date and time will be saved. If you don't press OK button, it will not be saved.

- 7 On completion, press RETURN to exit the menu.



- You must have the aerial connected to set the Auto Clock. Connecting the RF Cable on page 19.
- Auto Clock : The DVD Recorder-VCR sets the clock automatically by searching for a channel that carries a time signal.

## Presetting the Stations Automatically


You do not need to preset the stations if you have already set them automatically (see Plug & Auto Set Up on page 27).  
Your DVD Recorder-VCR contains a built-in tuner used to receive television broadcasts.  
You must preset the stations received through the tuner. This can be done:

- Plug & Auto Set up (see page 27)
- Automatically
- Manually (see page 30)


- 1 Open "MENU"  
With the DVD in Stop press the MENU button.

- 2 Select "Setup"  
Using the ▲▼ buttons, move the selection bar to "Setup" then press ► or OK to select.

- 3 Select "Install"  
Using the ▲▼ buttons, move the selection bar to "Install", then press ► or OK to select.




- 4 Select "Auto Setup"  
Move the selection ▲▼ buttons to "Auto Setup" then press ► or OK button to select from the following options:




## System Setup

- 5 Press ► or OK button.  
A message appears, indicating that any channels already preset on the DVD Recorder-VCR will be deleted.



- 6 Press OK to start the auto scanning.

- The first frequency band is scanned and the first station found is displayed and stored. And the DVD Recorder-VCR searches for the second station and so on.
- When the automatic scanning procedure has finished, the DVD Recorder-VCR switches automatically to programme 1.
- The number of stations automatically stored by the DVD Recorder-VCR depends on the number of stations that it has found.




- 7 If you wish to cancel the auto scanning before the end, press the OK button.
  - The time and date are set automatically from the broadcast signal. If the signal is weak or ghosting occurs, the time and date may not be set automatically.
  - Once the auto scanning procedure has finished, some stations may have been stored more than once; select the stations with the best reception and delete the ones no longer required.

# Presetting the Stations Manually


If you have already set then automatically, you do not need to preset the stations manually.

- 1 Open "MENU"  
With the DVD in Stop mode, press the MENU button.
- 2 Select "Setup"  
Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Setup" then press  $\blacktriangleright$  or OK button to select.
- 3 Select "Install"  
Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Install", then press  $\blacktriangleright$  or OK button to select.


## System Setup




- 4 Select "Manual Setup"  
Move the selection bar to "Manual Setup", using the  $\blacktriangle$   $\blacktriangledown$  buttons then press  $\blacktriangleright$  or OK button to select.



- 5 Press the  $\blacktriangle$   $\blacktriangledown$  buttons to select a PR number as required then press  $\blacktriangleright$  or OK button to select.




- 6 Press the  $\blacktriangle$   $\blacktriangledown$  button to select Edit. Then press  $\blacktriangleright$  or OK button to be displayed "Manual Setup" menu.



- 7 Press the  $\blacktriangle$   $\blacktriangledown$  buttons to start scanning the channels. The frequency band is scanned and the first station found is displayed.

- 8 Press the  $\blacktriangle$   $\blacktriangledown$  buttons until the NAME is selected. The station name is set automatically from the broadcast signal.

- 9 To change the programme's name, press the  $\blacktriangleright$  button. The first letter of the name flashes.



- 10 To...  
Select a Character  
Then...  
Press the  $\blacktriangle$   $\blacktriangledown$  button until the required name character is displayed (letters, numbers or "-" character)  
Move to the next or previous character  
Then...  
Press the  $\blacktriangle$   $\blacktriangledown$  buttons respectively.


- 11 If you...  
Wish to store the station displayed  
Then...  
Press the  $\blacktriangle$   $\blacktriangledown$  buttons until the MFT is selected.  
Press the  $\blacktriangle$   $\blacktriangledown$  buttons to adjust the picture, if necessary.  
Select Done to store the station.  
Do not wish to store the station displayed  
Then...  
Press the  $\blacktriangle$   $\blacktriangledown$  buttons until the CH is selected.  
Press the  $\blacktriangle$   $\blacktriangledown$  buttons to go on scanning the frequency band and display the next station.  
Go back to the beginning of step.

- 12 Press the  $\blacktriangle$   $\blacktriangledown$  buttons to select Done and then press OK button to confirm manual setting.  
Repeat this procedure from step 5 onwards, until all the required stations have been stored.


# Clearing a Preset Station

If you have stored a TV station:  
• That you do not require  
• At the wrong programme position you can cancel it.


- 1 Open "MENU"  
With the DVD in Stop mode, press the MENU button.
- 2 Select "Setup"  
Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Setup" then press  $\blacktriangleright$  or OK button to select.
- 3 Select "Install"  
Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Install", then press  $\blacktriangleright$  or OK button to select.




- 4 Select "Manual Setup"  
Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Manual Setup" then press  $\blacktriangleright$  or OK button to select.



- 5 Press the ▲▼ buttons to select a PR number as required then press ► or OK button to select.



- 6 Press the ▲▼ button to select Delete. Then press OK button to delete.



- 7 Press the ◀▶ buttons to select Yes, and then press the OK button.

- 8 Repeat the same procedure from Step 5 onwards until all the required stations have been cleared.

- 9 On completion, press the RETURN button four times to exit the menu.

## Changing the Preset Manual Setup Table

You can rearrange the Manual Setup Table and give different programme numbers to the manual setup listed according to your own preferences.

- 1 Open "MENU"


With the DVD in Stop mode, press the MENU button.

- 2 Select "Setup"

Using the ▲▼ buttons, move the selection bar to "Setup" then press ► or OK button to select.


- 3 Select "Install"

Using the ▲▼ buttons, move the selection bar to "Install", then press ► or OK button to select.




- 4 Select "Manual Setup"

Move the selection bar to "Manual Setup", using the ▲▼ buttons then press ► or OK button to select.



- 5 Press the ▲▼ buttons, until the required preset TV programme is selected then press ► or OK button to select.



- 6 Press the ▲ or ▼ button to select Swap. To change the programme number assigned to a station press the OK button on the remote control.

• For example, to move a TV station in programme 1 to programme 3).

- 7 Press the ▲▼ buttons to select required position. And then press OK button again to swap the position.

- 8 On completion, press the RETURN button four times to exit the menu.

## Setting the VCR Output Channel

- 1 Open "MENU"


With the DVD in Stop press the MENU button.

- 2 Select "Setup"

Using the ▲▼ buttons, move the selection bar to "Setup" then press OK to select.


- 3 Select "Install"

Using the ▲▼ buttons, move the selection bar to "Install", then press OK to select.



- 4 Select "VCR Output CH"

Move the selection bar to "VCR Output CH" using the ▲▼ buttons then press OK to select.



- 5 Select the required output channel (Ch21~Ch69) by pressing the ▲ or ▼ button then press OK to Select.

→ Ch21 → .Ch38 → .Ch69

- 6 On completion, press RETURN button four times to exit the menu. Then tune your television again

## System Setup


## System Setup

## Setting Up the Language Features

If you set the player menu, disc menu, audio and subtitle language in advance, they will come up automatically every time you watch a movie.


### Audio

- 1 With the DVD in Stop mode, press the MENU button on the remote control.
- 2 Select "Setup" using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button.





- 3 Select "Language" using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button. Language setup menu will be displayed.

- 4 Use  $\blacktriangle$   $\blacktriangledown$  buttons to select the "Audio" and press the  $\blacktriangleright$  or OK button.



- 5 Select the desired Language using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button.




-  Press the RETURN or  $\blacktriangleleft$  button to return to the previous menu. Press the MENU button to exit the menu.


Note

### Subtitle


- 1 With the DVD in Stop mode, press the MENU button on the remote control.
- 2 Select "Setup" using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button.
- 3 Select "Language" using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button. Language setup menu will be displayed.



- 4 Use  $\blacktriangle$   $\blacktriangledown$  buttons to select the "Subtitle" and press the  $\blacktriangleright$  or OK button.



- 5 Use the  $\blacktriangle$   $\blacktriangledown$  buttons to select "Subtitle".



- Some discs may not contain the language you select as your initial language; in that case the disc will use its original language setting.

## System Setup

- 6 Press the  $\blacktriangleright$  or OK button.
  - Subtitle is selected and the screen returns to Language Setup menu.




## Disc Menu


- 1 With the DVD in Stop mode, press the MENU button on the remote control.

- 2 Select "Setup" using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button.

- 3 Select "Language" using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button. Language setup menu will be displayed.




- 4 Use  $\blacktriangle$   $\blacktriangledown$  buttons to select the "Disc Menu" and press the  $\blacktriangleright$  or OK button.



## 5

- Use the  $\blacktriangle$   $\blacktriangledown$  buttons to select Disc Menu Language.




- 6 Press the  $\blacktriangleright$  or OK button.  
• Disc Menu language is selected and the screen returns to Language Setup menu.

## On-Screen Menu


- 1 With the DVD in Stop mode, press the MENU button on the remote control.

- 2 Select "Setup" using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button.

- 3 Select "Language" using  $\blacktriangle$   $\blacktriangledown$  buttons, then press the  $\blacktriangleright$  or OK button. Language setup menu will be displayed.



- 4 Use  $\blacktriangle$   $\blacktriangledown$  buttons to select the "On-Screen Menu" and press the  $\blacktriangleright$  or OK button.



## System Setup

- 6 Press the  $\blacktriangleright$  or OK button.  
• On-Screen Menu is selected and the screen returns to Language Setup menu.

# Setting Up the Audio Options

Allow you to setup the Audio device and sound status depending on the audio system in use.

- 5
- Use the **▲▼** buttons to select the desired item.  
Then press the **►** or **OK** button.
- Note
- Press the **RETURN** or **◀** button to return to the previous menu. Press the **MENU** button to exit the menu.

## Digital Output

1. PCM :
- Converts to PCM(2CH) 48kHz audio.  
Select PCM when using the  
Analogue Audio Outputs.
2. Bitstream :
- Converts to Dolby Digital/MP3  
Bitstream (5.1CH). Select Bitstream  
when using the Digital Audio Output.

## DTS

1. Off :
- Doesn't output digital signal.
2. On :
- Outputs DTS Bitstream via digital output only. Select DTS when connecting to a DTS Decoder.

- Note
- When DTS soundtrack is played, sound does output from Analog Audio Output.

## Dynamic Compression

1. On :
- To select dynamic compression.
2. Off :
- To select the standard range.

# System Setup

# Setting Up the Display(Video) Options

This function allows you to setup the TV screen settings.

- 5
- Use the **▲▼** buttons to select the desired item.  
Then press the **►** or **OK** button.
- Note
- Press the **RETURN** or **◀** button to return to the previous menu. Press the **MENU** button to exit the menu.

## Display(Video) Options

This function depends on disc type. It may not work for some disc types.

### TV Aspect

Depending on the type of television you have, you may want to adjust the screen setting. (aspect ratio)

- 4:3 Letter Box :
- Select when you want to see the total 16:9 ratio screen DVD supplies, even though you have a TV with a 4:3 ratio screen. Black bars will appear at the top and bottom of the screen.

- 4:3 Pan - Scan :
- Select this for conventional size TV when you want to see the central portion of the 16:9 screen. (Extreme left and right side of movie picture will be cut off.)

- 16:9 Wide :
- You can view the full 16:9 picture on your widescreen TV.


### 3D Noise Reduction

- Off : Normal
- On : Select to remove noise from the screen

- 1
- With the DVD in Stop mode, press the **MENU** button on the remote control.  
You can't use the Setup functions during playback.

- 2
- Select "Setup" using **▲▼** buttons, then press the **►** or **OK** button.

- 3
- Select "Video" using **▲▼** buttons, then press the **►** or **OK** button.  
Video option menu will be displayed.



- 4
- Select the sub menu using **▲▼** buttons, then press the **►** or **OK** button.




## Setting Up the Parental Control

The Parental Control function works in conjunction with DVDs that have been assigned a rating - which helps you control the types of DVDs that your family watches. There are up to 8 rating levels on a disc.


1 With the DVD in Stop mode, press the MENU button on the remote control.

2 Select "Setup" using ▲▼ buttons, then press the ► or OK button.

3 Select "Parental control" using ▲▼ buttons, then press the ► or OK button.





4 Enter the 4-digit password using the 0 to 9 buttons on the remote control.  
• The 'Confirm the password.' message will be displayed. Enter your password again.




40 - English

5 Select Password On/Off using ▲▼ buttons, then press the ► or OK button.



6 Select Rating Level you want using ▲▼ buttons, then press the ► or OK button.  
• For example, if you select up to Level 6, discs that contain Level 7, 8 will not play. Higher number indicates the program is more intended to adult use only



• Press the RETURN or ◀ button to return to the previous menu. Press the MENU button to exit the menu.  
• Refer to Troubleshooting if you forget your password.

Note

## About the Change Password;

1 Select Change Password using ▲▼ buttons, then press the ► or OK button.  
• The 'Enter the password.' message will be displayed.

2 Enter the 4-digit password using the 0 to 9 buttons on the remote control.  
• The 'Confirm the password.' message will be displayed.

3 Enter your password again using the 0 to 9 buttons on the remote control.


• Press the RETURN or ◀ button to return to the previous menu. Press the MENU button to exit the menu.

Note

## VCR Setting

If you want your VHS Video tapes to play automatically when you insert them, turn on Auto Play.

Note  
• Only tapes that are missing the Record Safety Tab will play automatically when inserted.




## System Setup

1 Open "MENU"  
With the VCR in play mode, Press the MENU button.

2 Select "Setup"  
Using the ▲▼ buttons, move the selection bar to "Setup" then press ► or OK button to select.

3 Select "System"  
Use the ▲▼ buttons to highlight "System" then press the OK button.




English - 41

## System Setup

4 Select "VCR"


Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "VCR", then press  $\blacktriangleright$  or OK to select.



6


Move the selection bar to "Auto Play," then press  $\blacktriangleright$  button to select from the following options:

- On - The VCR will automatically begin playing a video tape when it is inserted, as long as the safety tab of the cassette has been removed.
- Off - Auto play is disabled.



5 Select "Tape Length"

Press the  $\blacktriangleright$  button to select the Tape Length. This information is usually printed on the tape box. The menu cycles through: E180, E240, E280 or E300. Once the type of cassette is set, the VCR can display the amount of time remaining on the tape when you press the DISPLAY button.



7

Move the selection bar to "Auto Repeat". It sets the VCR to play a tape repeatedly (unless a tape control is activated (Stop, Fast Forward or Rewind)).



# Intelligent Picture Control (IPC)

The Intelligent Picture Control Feature allows you to adjust the sharpness of the image automatically, according to your own preferences.

1 Open "MENU"


With the VCR in play mode, Press the MENU button.

2 Select "Setup"

Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Setup" then press  $\blacktriangleright$  or OK button to select.


3 Select "System"

Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "System" then press  $\blacktriangleright$  or OK button to select.



4 Select "VCR"

Move the selection bar to "VCR", then press  $\blacktriangleright$  or OK button.




## System Setup

5 Select "IPC"

Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "IPC" then press  $\blacktriangleright$  or OK button to select the IPC option.

- When intelligent picture control mode is ON, the sharpness of the image is adjusted automatically.



6 To adjust the sharpness manually, press the  $\blacktriangledown$  button to turn the IPC mode OFF.

Press the  $\blacktriangle$   $\blacktriangledown$  buttons until the picture is displayed according to your preferences.

- If you do not press a button within ten seconds, the IPC menu disappears automatically.

8 On completion, press RETURN button to exit the menu.

You also can directly select this function using IPC button on the remote control.

## Selection the Colour Mode

Before recording or playing back a tape, you can select the required system standard. Otherwise, the system automatically selects the reception standard when you select Automatic.

- When playing back a tape, the standard is automatically selected by the DVD Recorder-VCR.

### 1 Open "MENU"


With the VCR in play mode, Press the MENU button.

### 2 Select "Setup"

Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Setup" then press  $\blacktriangleright$  or OK button to select.


### 3 Select "System"

Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "System" then press  $\blacktriangleright$  or OK button to select.



### 4 Select "VCR"


Move the selection bar to "VCR", then press  $\blacktriangleright$  or OK button.



### 5 Select "Colour System"

Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Colour System" then press  $\blacktriangleright$  or OK button to select Colour System option.

- Automatic : When playing back a tape, the system standard is automatically selected by the DVD Recorder-VCR.
- BW : Black and White.



### 6 On completion, press RETURN three times to exit the menu.

## Front Display

You can set the Front Panel Display to be bright all the time, dim all the time, dim during power off.

### 1 Open "MENU"


With the DVD in Stop mode, press the MENU button.

### 2 Select "Setup"

Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Setup" then press  $\blacktriangleright$  or OK button to select.

### 3 Select "System"


Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "System" then press  $\blacktriangleright$  or OK button to select.



### 4 Set "Front Display"

Move the selection bar to "Front Display," then press  $\blacktriangleright$  or OK button to select from the following options:

- Automatic – Front Panel Display will dim automatically during power off.
- Bright – Front Panel Display will be bright all the time.
- Dim – Front Panel Display will be dim all the time.



## System Setup

## System Setup

### NICAM


NICAM programmes are divided into 3 types:  
NICAM Stereo, NICAM Mono and Bilingual (transmission in another language).  
NICAM programmes are always accompanied by a standard mono sound broadcast and you can select the desired sound.

1 Open "MENU"  
With the VCR in play mode, Press the MENU button.

2 Select "Setup"  
Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "Setup" then press  $\blacktriangleright$  or OK button to select.

3 Select "System"  
Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "System" then press  $\blacktriangleright$  or OK button to select.

4 Select "NICAM"  
Using the  $\blacktriangle$   $\blacktriangledown$  buttons, move the selection bar to "NICAM" then press  $\blacktriangleright$  or OK button until NICAM option is selected.



46 - English

5	To... Mono mode	Press $\blacktriangle$ or $\blacktriangledown$ until... Off is displayed. Only set at this position to record the standard mono sound during a NICAM broadcast if the stereo sound is distorted due to inferior reception conditions.
	NICAM mode	On is displayed. On: Normally set at this position.

6 On completion, press RETURN three times to exit the menu.

### AV 1 Output

- RGB : Sends RGB signal from the AV JACK (SCART terminal)
- Video : Sends COMPOSITE VIDEO signal from the AV JACK (SCART terminal).

## Playback

This section introduces basic functions of playback by disc type.

DOLBY DIGITAL

Dolby Digital

DTS

Digital Audio

PAL

PAL Colour System in Australia, New Zealand, etc.

STEREO

Stereo

DIGITAL SOUND

Digital Audio

MP3

MP3

• Before Playing .....47

• Playing a Disc .....48

• Using the Search & Skip Functions .....50

• Slow Motion Play / Step Motion Play ...50

• About QUICK .....51

• Repeat Play .....52

• Using the A-B Repeat Function .....53

• Moving to a Scene Directly .....53

• Selecting the Subtitle & Audio Language 54

• Changing the Camera Angle .....55

• Using Bookmarks .....56

• Zooming-In .....57

• Check Remaining Time .....58

• Using the Disc and Top Menu .....58

• Playing Back an Audio CD (CDDA) ...59

• Play Option Mode .....60

• To Programme Tracks .....61

• Photo CD Playback .....62

• Playing back an MP3 CD9 .....63

• Using PIP .....64

• Playing the VCR .....65

• Tracking .....65

• Special VCR Playback Features .....66

• S-VHS Playback .....66

• Variable Search System .....67

English - 47

### Before Playing

Read the following information before playing a disc.

**Region code (DVD-Video only)**

Both the DVD Recorder-VCR and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.


The Region Number for this DVD Recorder-VCR is described on the rear panel of the DVD Recorder-VCR.

Disc types that can be played


Disc Types	Disc Logo	Recorded content	Disc Shape	Max. Playing Time
DVD-VIDEO		AUDIO + VIDEO	Single sided(5) Double sided(5)	about 240 about 80
AUDIO-CD		AUDIO	Single sided(5) Double sided(5)	about 74 about 20
JPEG CD-RRW		JPEG Images	Single sided(5) Double sided(5)	-
MP3 CD-RRW		MP3 Audio	Single sided(5) Double sided(5)	-
DVD-RAM		AUDIO + VIDEO	Single sided (5) (47GB)	100 (Extended Quality) 2 (SP Standard Quality) 4 (LP Long Playback) 8 (EP Extended) 16 (FP Full Playback)
DVD-RW		AUDIO + VIDEO	Double sided (8) (84GB)	2 (SP Standard Quality) 4 (LP Long Playback) 8 (EP Extended) 16 (FP Full Playback)
DVDR		AUDIO + VIDEO	5 (47GB)	1 (VP Excellent Quality) 2 (SP Standard Quality) 4 (LP Long Playback) 8 (EP Extended) 16 (FP Full Playback)


Discs that cannot be played


- DVD-Video with a region number other than "2" or "ALL"
- 3.9 GB DVD-R Disc for Authoring.
- DVD-RAM not recorded following the Video Recording Standard
- Unfinalised DVD-R recorded on other equipment
- NTSC discs
- DVD-ROM/DVD+RW/PDMMV-Disc/DVX Video Disc, etc
- CVD/CD-ROM/CDV/CD-G/CD-I

- 

Note
- This DVD Recorder-VCR can only operate with discs that are compatible with DVD-RAM Standard Version 2.0.
  - Playback and/or recording may not work for some types of discs, or when specific operations, such as angle change and aspect ratio adjustment, are being performed. Information about the discs is written in detail on the box. Please refer to this if necessary
  - Do not allow the disc to become dirty or scratched. Finger prints, dirt, dust, scratches or deposits of cigarette smoke on the recording surface may make it impossible to use the disc for recording.
  - To protect a DVD-RAM disc from damage, use a cartridge.
  - DVD-RAM/DVD-RW/DVD-R discs may not be able to play on some DVD players, depending on the player, disc and the condition of the recording.
  - Discs with NTSC programs recorded on them cannot be recorded using this product.




- 

CAUTION
- 1 Press the OPEN/CLOSE button.
  - 2 Place a disc gently into the tray with the disc's label facing up.
  - 3 Press OPEN/CLOSE button to close the disc tray.
    - Your DVD Recorder-VCR closes the disc tray and plays the disc automatically.
    - When a recordable media (DVD-RAM, DVD-RW, DVD-R, etc.) is used, Auto Playback cannot be activated without pressing the Play button. When pressing the ON/STANDBY button while a disc is in the tray, the unit will be activated. Press PLAY to start playback.
    - If you insert MP3 Disc, your DVD Recorder-VCR will display the file list on the screen and start.
    - When a JPEG disc is inserted, folders and a file list are displayed in the Album format.
- 

Note
- When you stop disc play, the recorder remembers where you stopped, so when you press PLAY button again, it will pick up where you left off. (unless the disc is removed or the recorder is unplugged, or if you press the STOP button twice.) This function is only applicable to DVD-Video, DVD-RAM/ DVD-RW/DVD-R or Audio CDs (CDDA).

Playback

- 4 Press the STOP button to stop playback.
- 

Note
- When you stop disc play, the recorder remembers where you stopped, so when you press PLAY button again, it will pick up where you left off. (unless the disc is removed or the recorder is unplugged, or if you press the STOP button twice.) This function is only applicable to DVD-Video, DVD-RAM/ DVD-RW/DVD-R or Audio CDs (CDDA).

## Using the Search & Skip Functions

### Searching through a Chapter or Track

During play, press the SEARCH ◀▶ or ▶▶ button on the remote control. The playback speed will change as follows.

DVD-VIDEO	▶▶Fast X2▶▶▶Fast X4▶▶
DVD-RAM/DVD-RW	▶▶Fast X8▶▶▶Fast X16▶▶
DVDR	▶▶Fast X32▶▶▶Fast X128
AUDIO CD(CDDA)	▶▶Fast X2▶▶▶Fast X4▶▶
	▶▶Fast X8

- You can scan the program in reverse order. To return to normal speed playback, press the ▶▶ button.

### Skipping Chapters or Tracks

- During play, press the ◀◀ or ▶▶ button on the remote control.
- If you press the ◀◀ button, it moves to the beginning of the chapter or track. Pressing the button once again within 3 seconds returns to the beginning of the previous chapter or track.
  - If you press the ▶▶ button
  - If you press the ▶▶ button, it moves to the next chapter or track.

### Skipping ahead 30 seconds

In play mode, press F.ADV/SKIP button to cue ahead exactly 30 seconds.

## Slow Motion Play/ Step Motion Play

### Slow Motion Play (DVD-VIDEO/DVD-RAM/DVD-RW/DVD-R)

During pause mode, press the SEARCH ◀◀ or ▶▶ button.

- Each time you press the ▶▶ button :
  - ▶▶ Slow 1/8 ▶▶▶ Slow 1/4 ▶▶▶ Slow 1/2
- Each time you press the ◀◀ button :
  - ◀◀ Slow 1/8 ▶▶▶ Slow 1/4 ▶▶▶ Slow 1/2

To return to normal speed playback, press the ▶▶ button.

### Step Motion Play (DVD-VIDEO/DVD-RAM/DVD-RW/DVD-R)

During pause mode, press the F.ADV/SKIP button on the remote control.

- Each time the button is pressed, a new frame will appear.

To return to normal speed playback, press the ▶▶ button.

- No sound is heard during STEP or SLOW mode.


## About QUICK

The QUICK functions allows you to easily search for a desired scene by accessing title, chapter, track and time. You can also change the subtitle and audio settings and set some features including Repeat, Angle and Zoom.

Press the QUICK button on the remote control during playback.


### DVD-VIDEO

Title/Chapter/Time/Subtitle/Audio/Repeat/Angle/Zoom




### DVD-RAM/DVD-RW

Title/Time/Subtitle/Audio/Repeat/Zoom



### DVD-R

Title/Chapter/Time/Audio/Repeat/Zoom



#### What's a track?

- A track is usually a song on a Audio CD (CDDA) or MP3 disc.

#### What's a chapter?

- A title on a DVD disc is usually divided into chapters.

#### What's a title?

- A title means usually a film contained on a DVD disc.

- This may not work for some discs. When an audio CD(CDDA) or a MP3 disc is inserted, depending on the type, the information display may not be appear.

- Regarding the DVD-Video mode, the Time Search function does not operate in some discs.

- To make the screen disappear, press the QUICK again.

## Playback

## Playback




## Repeat Play

### Using Repeat Play (For DVD-VIDEO/DVD-VIDEO-RAM/DVD-RW/DVD-R)

"Chapter repeat" is only available in DVD-Video.

1 Press the QUICK button.



2 Use **▲▼** buttons to select Repeat and use **▶** button to select the A-B, Title or Chapter you want to play repeatedly.

3 Press OK button.  
Repeat play allows you to repeat title, chapter or A-B.  
• To make the screen disappear, press the QUICK or RETURN button.

### Using Repeat Play (For Audio CD/MP3)

1 Press the QUICK button during playback.  
Repeat is highlighted.

2 Press OK button.


3 Press the **▲▼** buttons to select the Track or Disc you want to playback repeatedly.  
For MP3 discs, you can select Track, Folder or Disc.

4 Press OK button.  
Repeat play allows you to repeat a track, folder or the entire disc.

## Using the A-B Repeat Function

### For DVD-VIDEO/DVD-VIDEO-RAM/DVD-RW/DVD-R

1 Press the QUICK button during playback.



2 Use **▲▼** to select Repeat and use **▶** button to select A-B.

3 Press OK button.

4 Press the OK button at the point where you want the repeat play to start (A) and then press the OK button at the point where you want the repeat play to Stop (B).

- The minimum A-B Repeat time is 5 seconds.
- Your DVD Recorder-PCR will playback the selected section repeatedly.


### To return to normal playback

Select Off on the Repeat item or press the CLEAR button on the remote control.

## Moving to a Scene Directly


You can find the desired scene easily using the QUICK function.

1 Press the QUICK button during playback.



2 Use **▲▼** to select the Title, Chapter or time you want to find the desired scene.


3 If you want to select a title or chapter, select it using the **◀▶** buttons. Then, press the OK button.  
• You can enter the desired item directly using the number buttons.



## Playback

## Playback

4 If you want to move to a desired time, enter the time in the sequence of hour, minute, and second using the number buttons and then press the OK button.




## Selecting the Subtitle & Audio Language

Audio languages and subtitle languages may not work depending on disc type. It is available during playback only.

### Selecting the subtitle language

1 Press the QUICK button during playback.




2 Use **▲▼** to select Subtitle and use **◀▶** buttons to select the desired subtitle language.

- If a disc contains subtitles, you can select a desired subtitle language by pressing the **◀▶** buttons.
- Subtitle display may be different depending on disc type.
- DVD subtitles may overlap with your TV's subtitles. If this occurs, disable the caption function on your TV.
- Some discs allow you to select languages from the disc menu only.

### Selecting the Audio language

1 Press the QUICK button during playback.



2 Use **▲▼** to select Audio and use **◀▶** buttons to select the desired audio language.


- Audio languages may be different because they are disc-specific.
- Some discs allow you to select languages from the disc menu only.

## Changing the Camera Angle

When a DVD contains multiple angles of a particular scene, you can select the Angle function.

1 Press the QUICK button during playback.

2 Use **▲▼** to select Angle and use **◀▶** buttons to select the desired angle.




Note This function is disc-dependent, and may not work with all DVDs. This function does not work when a DVD has not been recorded with a multi-camera angle system.

## Using Bookmarks

Set marks at scenes you want to see again so that you can start playback from the marked position.

### Setting a book mark

1 Press the MARKER button during playback.



2 Press the OK button when the desired scene appears.

- The number 1 is displayed and the scene is memorized.

3 Press ► button to move to the next position.

4 Press the OK button again when the desired scene appears.

- The number 2 is displayed and the scene is memorized. Repeat above to bookmark other positions. You can bookmark up to 10 scenes.

### Bookmarking with DVD-RAM/ DVD-RW(VR) disc

- The screen will display "Marker" in place of "Bookmark" if you are playing a DVD-RAM/DVD-RW(VR).
- Up to 99 scenes can be marked.
- If you press the OK button during playback, bookmarks are saved in the order of title.

### Playing Back a Bookmark


1 Press the MARKER button.

2 Press the ◀▶ buttons to select a bookmarked scene.

3 Press the OK button to start playing from the selected scene.


### Clearing a Bookmark

1 Press the MARKER button.




2 Press the ◀▶ buttons to select a marked scene you want to delete.

3 Press CLEAR button to delete the selected bookmark.




## Zooming-In

1 Press the QUICK button during playback.



2 Use ▲▼ buttons to select Zoom, and then press the OK button.



3 Press ▲▼◀▶ buttons to move to the area you want to enlarge.

4 Press the OK button.

- The screen will be enlarged to twice the normal size.
- If you press the OK button again after the screen was enlarged to twice the normal size, the screen size will be enlarged to four times the normal size.

DVD-V/VIDEO	normal size →2X →4X →2X
DVD-R/AM/DVD-RW	→ normal size
DVD-R	


5 To return to the normal size, press the OK button repeatedly until the screen becomes of normal size.

## Playback

## Playback

## Check Remaining Time

- 1 Press DISPLAY button on the remote control. Following information will be displayed.
- Current deck status, Current counter, recording speed, remaining time, input channel, current time.)



## Using the Disc and Top Menu

Some type of discs contains a dedicated menu system that allows you to select special functions for title, chapter, audio track, subtitle, film preview, information on characters, etc.

### For DVD-VIDEO disc

- 1 Press the DISC MENU button to enter the disc menu of the disc.
- Move to the setup menu related to playback operation.
  - You can select audio language and subtitle etc. provided by the disc.

- 2 Press the TOP MENU button to move to the top menu of the disc.
- Use this button if the disc contains more than one title. Some discs may not support the top menu functionality.

### For DVD-RAM/DVD-RW/ DVD-R disc

- 1 Press the TITLE LIST button to display title list.

- Note
- Title List : Title refers to a recorded video stream. Title List shows list to help you select a title. Since the title list consists of the information on stream that is actually recorded, if one title is deleted, that title cannot be played again.
  - Play List : This refers to a unit of playback, which is made by selecting a desired scene in the entire Title List. When one playlist is played, only the scene selected by the user will play and then stop. Since only the information necessary for playing a desired scene is included in a playlist, even if that playlist is deleted, the original data will not be deleted.

## Playing Back an Audio CD (CDDA)

Each disc has a variety of menu functions available.

- 1 Insert an audio CD (CDDA) into the disc tray.
- The audio CD menu appears and the tracks (songs) are played back.



- 2 Press **▲▼** buttons to select the track (song) to start playback from, and then press the OK button.
- You can also select the track (song) by pressing the number buttons on the remote.

### Audio CD(CDDA) Screen Elements



- ① **Repeat mode:** Repeat off/Repeat Track/Repeat Disc.
- ② **Current track (song):** Displays the title of the track currently being played.
- ③ Displays the current play index and total track number.
- ④ This shows the operating state of a disc and a playback time corresponding to a portion that is currently played.
- ⑤ Displays the track list (song list) and the playing time of each track.
- ⑥ Button display.
- ⑦ **Play Option:** Normal, Random, Intro or Playlist

### Playback

### Audio CD (CDDA) Screen Elements

- 1 **▲▼** : Select a track (song).
- 2 **▶** : Playback the selected track (song).
- 3 **OK (⏏)** button: Playback the selected track (song).
- 4 **(▶▶)** button: Playback the next track.
- 5 **(◀◀)** button: Returns to the beginning of the current track when pressed during playback. If you press this button within three seconds after playback starts, the previous track will be played. If you press this button after three seconds, the current track will be replayed from the beginning.
- 6 Press the **(◀◀/▶▶)** button: **▶▶Fast X2▶▶Fast X4▶▶Fast X8**


## Play Option Mode

- **Normal :** Tracks on a disc are played in the order in which they were recorded on the disc.
- **Playlist :** The Playlist playback option allows you to select the order in which you want tracks to play.
- **Intro :** The first 10 seconds of each track is played. If you press the ► button during Intro play, Normal Play will be performed from the track currently playing. When Intro Play is completed, Normal Play is performed.
- **Random :** The Random option plays a disc's tracks in random order. After a random list is generated and played completely, another random list is generated and played. Random Play continues until the play option is changed.



The same can be used with a Mp3 disc.


- 1 Press the QUICK button during playback. Repeat mode will be highlighted.




- During Playback, repeat mode will be highlighted.
- During Stop, Play option will be highlighted.

- 2 Select Play Option Mode using the ◀▶ buttons and press the OK button.

- The play option screen will appear.



- 3 Select a desired play option using the ▲▼ buttons and press the OK button.




60 - English


## To Program Tracks

You can register a maximum 30 tracks in the playlist.

- 1 During Playback, press the QUICK button. Repeat Mode will be highlighted.




- 2 Select Play Option using the ◀▶ buttons.



- 3 Press the OK button. The play option screen will appear. Select Playlist using the ▲▼ buttons and press the OK button.

- The playlist screen will appear.




- 4 Select tracks in the order in which you want them to play using the ▲▼ buttons. Press the OK button.



Press the ►|| (PLAY/PAUSE) button to playback playlist.

- 5 If you playlisted a wrong track, select the wrong track using the ▲▼ buttons and press the CLEAR button. The wrong track will be removed.

## Playback




English - 61

# Photo CD Playback

1 Insert a photo CD (JPEG) into the disc tray.

2 The screen shown below will appear automatically. (Press **▶|** (PLAY/PAUSE) button to switch to slide show mode.)



To see the next 6 pictures, press the **▶|** button. To see the previous 6 pictures, press the **◀|** button.

3 Select Photo using **▲ ▼** buttons, then press the OK button.



4 Use the **◀ ▶** buttons to select clips menu and then press the OK button.

- ◀** : Returns to the Album screen.
- ▶** : The unit enters slide show mode. Before the slide show can begin, the photo interval (slide show speed) must be set.
- ▶** : Each time the OK button is pressed, the picture rotates 90 degrees clockwise.
- ▶** : Each time OK button is pressed, the picture is enlarged up to 4X. (Normal → 2X → 4X → 2X → Normal)

## When using a combination MP3/JPEG disc


1 If you want to listen to MP3 files, but you're currently in Photo mode, press **■** (STOP) button twice and then press MENU button to bring up the Menu screen.

2 Select Music using the **▲ ▼** buttons then press the **▶** or OK button. MP3 screen will be shown.

# Playing back an MP3 CD

1 Insert an MP3 CD into the disc tray.

- The MP3 menu is displayed and the tracks (songs) are played back.



2 Press the **▲ ▼** buttons to select the folder you want to hear, and then press the OK button.

- Press the **▲ ▼** buttons to select the track (song) you want to hear, and then press the OK button.
- You can also select the desired track (song) by pressing the number buttons on the remote.

## Buttons on the Remote Control

1 **▲ ▼** : Selects a track (song).

2 **▶** : Play back the selected track (song).

3 **OK (▶)** button: Play back the selected track (song) or displays the files in the selected folder.

## When using a combination MP3/JPEG disc

1 If you want to watch Photo files, but you're currently in MP3 mode, press STOP button twice and then press MENU button to bring up the Menu screen.

2 Select Photo using the **▲ ▼** buttons then press the **▶** or OK button. Photo screen will be shown.

## Playback

4 **RETURN (↶)** button: Moves to the parent of the folder to which the current song belongs.

5 **▶|** button: Play back the next track.

6 **◀|** button: Returns to the beginning of the current track when it is pressed during playback. If it is pressed again, your DVD Recorder-VCR plays back the previous track.

## Using PIP

The PIP function allows you to view a sub screen together with the main screen in DVD mode. You can watch both DVD and TV together.

 **Note**  
■ PIP does not work in VCR mode.

- 1** During Playback, press the PIP button.
- The current disc is played back on the PIP screen located at the bottom of the screen.



## Switching between the PIP and main screens

- 1** Press the PIP button again.
- The main and PIP screen will be switched.




- Deactivating PIP**
- 1** Press the PIP button again.
- PIP will be deactivated.



## Playing the VCR

To play a standard VHS Video tape, videotape, just insert it into the VCR deck and press the PLAY button. You can turn on the Auto Play to enable the VCR deck to play automatically when you insert a videotape that is missing the Record Safety Tab. See pages 41–42.



- 1 Adjust Tracking Manually**
- During playback, press the PROG/TRK  $\vee/\wedge$  buttons to remove white lines from the picture.

The Tracking adjustment removes the white lines that sometimes appear during playback because of slight differences in recording decks. You may also set tracking manually.

## Playback

- 1 Insert VHS Video tape**
- Insert a standard VHS Video tape into the VCR deck.
- When a videotape is inserted, power will turn on automatically.

- 2 Play Tape**
- Press the  $\blacktriangleright$  (PLAY/PAUSE) button on the remote control or on the front panel of the unit. The videotape will begin to play automatically if it is missing the Record Safety Tab and Auto Play is turned on. See pages 41–42.

- 3 Stop Playback**
- Press the  $\blacksquare$  (STOP) button on the remote control or on the front panel of the unit.

## Special VCR Playback Features

While a videotape is playing, you can enjoy a variety of special playback features, including Still, Frame Advance, Skip, Slow motion, and more. Press the Play button again to resume normal playback.

### 1 Still

In Play mode, press **II**(PLAY/PAUSE) to still a single frame.

### 2 Frame Advance

In the pause mode, press FADV/SKIP to advance to the next frame.

### 3 Cue/Review

In Play mode, press Forward (**►**) or Rewind (**◄**) to Cue/Review at two speeds:

- Picture Search — Press and release to advance the tape forward or backward at 5 times normal speed.
- Jet Search — Press and hold to advance the tape forward or backward at 7 times normal speed.

### 4 Skip

In Play mode, press FADV/SKIP to cue ahead exactly 30 seconds. Press FADV/SKIP repeatedly up to 4 times to cue ahead 2 minutes.

### 5 Slow motion

In pause mode, press **►►** button for slow motion. Press the press **►►** button repeatedly to vary slow motion speed from 1/5 to 1/20 of normal playback. Press the **►II**(PLAY/PAUSE) button twice to resume normal viewing.

## S-VHS Playback

The DVD Recorder-VCR allows you to playback high quality S-VHS tapes.

### 1 Insert a S-VHS Tape

Insert an S-VHS tape into the VCR deck.

### 2 Start Playback

Press **II**(PLAY/PAUSE) on the remote control to begin playback of the S-VHS tape.


## Variable Search System

**Press the QUICK button to display the search screen in the stop mode.** When a program is recorded, the starting point is given an index mark for easy location. However, the VHS Index Search System (VISS) cannot recognize index marks made by old VCRs. If the VCR has trouble finding a mark, it is probably because the cassette was recorded on a VCR without VISS. If you want to index two programs in a row, set your VCR to stop, then start recording each program.

### 1 Go to [0:00:00] stop

Use this feature when you want to search for the [0:00:00] counter position on a cassette.

### 1 Press the CLEAR button at the point on the tape where you want to set the counter to [0:00:00].



### 2 While a cassette is stopped, press the QUICK button.

### 3 Select "Go To Zero", and then press the OK button.

**Note** The VCR will rewind or fast forward, searching for the [0:00:00] counter position, and then automatically stop at that position.

### End search

Use this feature when you want to search for a blank position to record a program on a cassette.

### 1 While a cassette is stopped, press the QUICK button.

Select "End Search", and press the OK button.



**Note** The VCR will fast forward, searching for a blank position, and then automatically stop at that position. If the VCR reaches the end of the tape during end search, the tape will be ejected.

### Scan and play

Use scan and play when you don't know exactly where a program is located on a cassette tape.

#### - Forward Intro Scan

Highlight "Forward Intro Scan", then press the OK button.

#### - Reverse Intro Scan

Highlight "Reverse Intro Scan", then press the OK button.

## Playback



Recording

This section shows various DVD recording methods.

• Before Recording . . . . . 68

• Recording the current Programme you are watching . . . . . 70

• Making a One Touch Recording (OTR) . . . . . 71

• Using the Videoplus+ Feature . . . . . 71

• Modifying Videoplus+ Programming . . . . . 73

• Using the Timer Programming Feature . . . . . 74

• Editing Timer Programme Feature . . . . . 75

• Deleting a Timer Programming . . . . . 76

• Videoplus+ Extended . . . . . 77

• Watching the Images Being Recorded (Time Slip) . . . . . 78

• Recording from External Devices . . . . . 78

• Recording through a DV Jack . . . . . 79

• Basic VCR Recording . . . . . 79

• Special Recording Features . . . . . 80

• Record Speed . . . . . 80

• Copy to DVD or VCR . . . . . 81

68 - English

Before Recording

Prerequisite

This unit can record on various types of discs. Before recording, read the following instructions and select the disc type according to your preference.

Recordable discs

This recorder can record on the following discs.

DVD-RAM	DVD-RW	DVD-R

•DVD-RWs and DVD-RAMs are rewritable.  
•DVD-Rs are non-rewritable.

This can be due, among other reasons, to problems and errors that can occur during the creation or recording of DVD and other software and the manufacture of software discs (including blank discs). Moreover, because of variations in the quality of discs, this recorder may not be able to record on all discs that bear a DVD-RAM, DVD-R or DVD-RW logo, but you should not encounter difficulty if you use only high quality recordable DVD discs.

If you happen to encounter difficulties playing or recording a DVD disc of playing a CD disc, please feel free to call our Customer Service Hotline.

Compatibility between Toshiba Recorder and Other Company's Recorder.

Disc Types	Recording Format	Recording Device	Finalising	Additional Recording on the DVD Recorder/VCR
DVD-RAM	VR Mode	Toshiba	X	Recordable
		Other Company	Finalised	Not recordable
		Toshiba	not finalised	Recordable
		Other Company	Finalised	Not recordable
DVD-RW	VR Mode	Toshiba	Finalised	Not recordable
		Other Company	not finalised	Recordable (D-VR3 Toshiba Models)
		Toshiba	not finalised	Recordable (D-VR3 Toshiba Models)
		Other Company	Finalised	Not recordable
DVD-R	V Mode	Toshiba	Finalised	Recordable (D-VR3 Toshiba Models)
		Other Company	not finalised	Not recordable
		Toshiba	not finalised	Recordable (D-VR3 Toshiba Models)
		Other Company	Finalised	Not recordable

Note

Finalise  
- This closes the DVD-RW/DVD-R so no additional recording can be done.  
Unfinalise  
- This allows additional recording on a finalised DVD-RW disc.  
- A DVD-RW disc that has been recorded by DAO in a PC cannot be unfinalised.  
- A DVD-RW disc that has been recorded in Video Mode of a different maker's recorder cannot be unfinalised.  
- A DVD-R disc cannot be unfinalised.

Recording Formats

When you insert an unused disc, the following message appears. Since available functions differ depending on the disc type, select a disc that best fits your preferences.  
DVD-RAM: Use after formatting the disc.

DVD-RW: When unused DVD-RW disc is first inserted, the message "Do you want to initialize this disc" will be displayed. If you select Yes, the disc will be formatted in VR mode. If you want to change the mode, refer to Formatting a Disc on page 101.

DVD-R: Formatting DVD is unnecessary and only Video Mode Recording is supported.

Recording

Broadcasts that contain copy control signals may have one of the following three signal types, Copy-Free, Copy-Once and Copy-Never. If you want to record a copy-once type program, use DVD-RW with CPRM in VR Mode and DVD-RAM.

Concerning copy control signals.

	Copy-Free	Copy-Once	Copy-Never
DVD-RW(Ver.1.1) DVD-RW(Ver.1.1) with CPRM	Yes	No	
VR mode	Yes	Yes*	
Video mode	Yes	No	
DVD-R (For General Ver.2.0)	Yes	No	
DVD-RAM (Ver.2.1)	Yes	Yes*	

Once "Copy Once" has been recorded, additional recording cannot be performed.  
This \* marked parts are compatible with CPRM.

DVD-RW( Video mode)/DVD-R

• This mode automatically creates chapters at specified intervals during finalization.  
• Simple editing (erasing titles/changing title name).

DVD-RAM/DVD-RW(VR mode)

• This mode involves multiple editing functions (such as deletion of a whole title, partial deletion of a title, etc.).  
• Various editing options using a created Playlist.

Unrecordable pictures

Pictures with copy protection cannot be recorded on this DVD Recorder-VCR.  
When the DVD Recorder-VCR receives a copy guard signal while recording, recording stops and the following message appears on the screen.

Recording

Broadcasts that contain copy control signals may have one of the following three signal types, Copy-Free, Copy-Once and Copy-Never. If you want to record a copy-once type program, use DVD-RW with CPRM in VR Mode and DVD-RAM.

Concerning copy control signals.

	Copy-Free	Copy-Once	Copy-Never
DVD-RW(Ver.1.1) DVD-RW(Ver.1.1) with CPRM	Yes	No	
VR mode	Yes	Yes*	
Video mode	Yes	No	
DVD-R (For General Ver.2.0)	Yes	No	
DVD-RAM (Ver.2.1)	Yes	Yes*	

Once "Copy Once" has been recorded, additional recording cannot be performed.  
This \* marked parts are compatible with CPRM.

English - 69

4-29

## Recording the current Programme you are watching



### Preliminary

1. Check the aerial cable is connected.
  2. Check the remaining time of disc.
- DVD-RAM/DVD-RW discs should be formatted in advance before beginning recording. Most new discs are sold unformatted. Make sure to format your unformatted discs before recording.
3. Corresponding station should be preset.

**1** Press the OPEN/CLOSE button and place a recordable disc on the disc tray.

**2** Press the OPEN/CLOSE button to close the disc tray.

**3**

- Press the PROG/TRK  $\nabla/\wedge$  buttons to select the station you want to record.
- The AV1, AV2 or AUX using the INPUT SEL. button for a satellite tuner or external Video source.

**4** Press the REC SPEED button on remote control, to select the recording speed (quality).

- X(P)High: approx. 1 hour  $\rightarrow$  SP(Standard, approx. 2 hours)  $\rightarrow$  LP(Low, approx. 4 hours)  $\rightarrow$  EP(Extended Play, approx 6 hours)

**5** Press the  $\bullet$  (REC) button.

**6** Press the  $\blacksquare$  (STOP) button to stop or finish a recording in progress.

- The message "Updating the information of disc. Please wait for a moment".

## Pausing / Resuming

- Press the REC PAUSE button to pause a recording in progress.
- Press the REC PAUSE button again during pause to resume recording.
- You can switch stations by pressing the PROG/TRK  $\nabla/\wedge$  buttons while recording pauses.



### Note

- You can't change the recording speed and programme during recording.
- Recording will stop automatically if there is not enough space for recording.
- Up to 99 titles can be recorded onto a disc.
- If the power interrupted due to power failure or other reasons, the title being recorded will not be saved onto the disc.
- Recording will stop automatically if a copy protected image is input.
- Do not use DVD-R authoring discs with this unit.

## Making a One Touch Recording (OTR)



One-Touch Recording (OTR) allows you to add recording time in 30-minute increments up to 9 hours at the touch of a button.

**1** Use the PROG/TRK  $\nabla/\wedge$  buttons or number buttons to select the station to record.

**2** **Start Recording.**  
Follow the instructions on page 70 to begin recording.

**3** **Activate OTR.**  
While in Record mode, press the REC button again to activate One-Touch Recording (OTR).

- Record length 0:30 appears on the On-Screen Display and the DVD Recorder-VCR will record for exactly 30 minutes.

**4** **Add Recording Time.**  
Continue pressing REC to add recording time in 30 minute increments up to 9 hours.

- The DVD Recorder-VCR stops recording automatically when the time has elapsed.

$\rightarrow$  REC  $\rightarrow$  30  $\rightarrow$  1'00  $\rightarrow$  1'30  $\rightarrow$  2'  $\rightarrow$  2'30  $\rightarrow$  3'  
9'  $\leftarrow$  8'  $\leftarrow$  7'  $\leftarrow$  6'  $\leftarrow$  5'  $\leftarrow$  4'  $\leftarrow$  3'00


## Using the Videoplus+ Feature

Before presetting your DVD Recorder-VCR:

- Switch on both the television and your DVD Recorder-VCR
- Check that the date and time are correct
- Insert the cassette or Recordable DVD on which the programme is to be recorded (safety tab intact) Up to twelve programmes can be preset.


**1** To enter a Videoplus+, press the VIDEO Plus+ button. Press the  $\blacktriangle$  and  $\blacktriangleright$  or OK buttons to select Videoplus+.

- A message is displayed to allow you to enter the Videoplus+ code.
- If all twelve programmes have been set, the message Timer is full is displayed. Refer to page 76 if you wish to cancel a preset recording.



**2** Press the numeric buttons to enter the code opposite the programme that you wish to record in your television magazine.


- If you wish to correct the Videoplus+ code that you are entering:
  - Press the  $\blacktriangleleft$  button until the digit to be corrected is cleared
  - Enter the correct digit



## Recording

## Recording

- 3 Press the OK button.
- The information concerning the programme is displayed.
  - When using the Videoplus+ function for the first time with stored stations, the programme number flashes. On the first occasion, you must enter the station number manually by pressing the **▲▼** buttons.



- Refer to the following page if:
- The programme number or times flash
  - You wish to modify the programme

- 4 If the programme and times are correct, press the OK button.

- 5 Press the ONSTANDBY button to activate the timer.

- 6 Refer to page 76 if you wish to:
- Check that your DVD Recorder-VCR has been programmed correctly
  - Cancel a preset recording

- Note
- The numbers next to each TV programme listing are Videoplus+ code numbers, which allow you to programme your DVD Recorder-VCR instantly with the remote control. Tap in the Videoplus+ code for the programme you wish to record.
  - Videoplus+ is a trademark of Gemstar Development Corporation. The Videoplus+ system is manufactured under licence from Gemstar Development Corporation.

## Modifying Videoplus+ Programming

If you wish to correct the programme displayed or modify certain elements, such as the recording speed, refer to following instruction before pressing RETURN button.

If you wish to...	Then...
Select an input source other than the tuner (AV1, AV2 or AUX)	<ul style="list-style-type: none"><li>• Press the <b>▲</b> or <b>▼</b> buttons, until the PR selection mode.</li><li>• Press the INPUT SEL. button one or more times to change the input source selection.</li></ul> <p>Result: The programme number is replaced by:</p> <ul style="list-style-type: none"><li>• The AV1, AV2 or AUX source using the INPUT SEL. button for a satellite tuner or external video source</li><li>• The input source must be selected before changing any other value.</li></ul>
Record a programme every day (Monday to Sunday) at the same time	<ul style="list-style-type: none"><li>• Press the <b>▲</b> or <b>▼</b> buttons, until the Day selection mode.</li><li>• Press the <b>▲</b> or <b>▼</b> buttons, until the Daily value is displayed.</li></ul>
Record a programme every week on the same day and at the same time	<ul style="list-style-type: none"><li>• Press the <b>▲</b> or <b>▼</b> buttons, until the Day selection mode.</li><li>• Press the <b>▲</b> or <b>▼</b> buttons, until the W- (Week) value is displayed, followed by the required day.</li></ul> <p>Example: W-SA (Weekly Saturday)</p>
Extend the recording time	<ul style="list-style-type: none"><li>• Press the <b>▲</b> or <b>▼</b> buttons, until the End selection mode.</li><li>• Press the <b>▲</b> or <b>▼</b> buttons to increase or decrease the stop time.</li></ul>
Select the recording speed	<ul style="list-style-type: none"><li>• Press the <b>▲</b> or <b>▼</b> buttons, until the recording speed selection mode.</li><li>• Press the <b>▲</b> or <b>▼</b> buttons until the correct indication is displayed:<ul style="list-style-type: none"><li>• AUTO (Auto tape speed select)</li><li>• XP (high quality)</li><li>• SP (Standard Play)</li><li>• LP (Long Play)</li><li>• EP (extended mode)</li></ul></li><li>• VCR</li><li>• AUTO</li><li>• SP</li><li>• LP</li></ul>
Select the PDC recording	<ul style="list-style-type: none"><li>• Press the <b>▲</b> or <b>▼</b> buttons, until the VPS/PDC off mode.</li><li>• Press the <b>▲</b> or <b>▼</b> buttons until the "On" indication is displayed.</li><li>• Do not select PDC unless you are sure the programme you wish to record is broadcast with PDC. If you do set PDC On (by selecting "On" in the right - hand column on the screen), then you must set up the start-time EXACTLY according to the published TV schedule. Otherwise the timer recording won't take place.</li></ul>

## Recording

### Using the Timer Programming Feature

1. Check the antenna cable is connected.


2. Check the remaining time of the disc.

3. Check the date and time are correct.

Make sure the Clock has been set (Setup - Clock Set) before you proceed with a timer recording.


1 Press the VIDEO Plus+ button.

- Programme menu is displayed.
- Using the MENU button:
  - 1 Press the MENU button.
  - 2 Press the  $\blacktriangle$   $\blacktriangledown$  buttons to select Program and then press the  $\blacktriangleright$  or OK button.
  - 3 Select Standard Timer.
- If the current time is not set. Set the current time first.



2 Press the  $\blacktriangle$   $\blacktriangledown$  buttons to select 'Standard Timer' and then press the  $\blacktriangleright$  or OK button.

3 Press the  $\blacktriangle$   $\blacktriangledown$  button to select scheduled Record List, and then press the  $\blacktriangleright$  or OK button.



4 Set timer recording option.

- The Timer Recording screen is displayed. Fill the input items using the arrow buttons.
- $\blacktriangle$   $\blacktriangledown$ : Moves to the previous/next item.
- $\blacktriangle$   $\blacktriangledown$ : Sets a value.
- TO: Select the media to record DVD or VCR.
- PR: The video input source (AV1 or AV2), or the broadcasting channel you want to make a timer recording from.
- Day: Set the recording day.
- Start/End Time: Start and End time of the timer recording.
- Speed: See page 75
- VPS: Video Programme System
- PDC: Programme Delivery Control

DVD

AUTO: Select when you want to set video quality automatically. It depends on the remaining time on the DVD.

XP (high quality): Select when video quality is as important. (Approx. 1 hour)

SP (standard quality): Select to record in standard quality. (Approx. 2 hours)

LP (low quality): Select when a long recording time is required. (Approx. 4 hours)

EP (extended mode): Select when a longer recording time is required. (Approx. 6 hours about 1.2 Mbps)

VCR

AUTO: Select when you want to set video quality automatically. It depends on remaining time of VCR tape.

SP: Standard Play, for best picture quality.

LP: Long Play, for maximum recording time (3 times SP).

5 Press the OK button.

If you make a mistake  
Press the  $\blacktriangle$   $\blacktriangledown$  buttons to select the item you want to change.

If the timer settings overlap  
The programs are recorded in order of priority. If timer recording is set for the first program and then again for the second program and both programs overlap, the first program has priority. After recording of the first program is complete, the second program starts being recorded.

To exit without saving the current setting  
Press the MENU or VIDEO Plus+ button.

To return to the previous menu  
Press the RETURN button if you don't want to set a timer recording.

6 Turn the power off to finish the timer recording. will not work when the power is on.


- When power is switched on, program recorded for recording in Timer Recording will be automatically cleared after the start time and date have passed.
- $\odot$  will appear on the front panel. It means that a timer recording is registered.
- $\odot$  will blink if disc or tape is not inserted.

Recording

Editing the settings for a timer recording

1 Press the MENU button.

2 Press the  $\blacktriangle$   $\blacktriangledown$  buttons to select "Programme" and then press the  $\blacktriangleright$  or OK button.




3 Press the **▲▼** buttons to select "Standard Timer" and then press the **►** or **OK** button.




4 Press the **▲▼** buttons to select the number of the timer programming you want to edit, and then press the **►** or **OK** button.

- The Edit and Delete items are displayed.



5 Press the **▲▼** buttons to select "Edit", and then press the **OK** button.

- The timer programming screen is displayed. Edit the items you want to modify. See the timer programming section for more information on timer programming input sources. (74 page)



6 Press the **OK** button to confirm the edited setting.


## Deleting a Timer Programming

Follow these directions to delete an entry from the timer record list.

1 Press the **MENU** button.


2 Press the **▲▼** buttons to select Programme and then press the **►** or **OK** button.

3 Press the **▲▼** buttons to Standard Timer, and then press the **►** or **OK** button.



4 Press the **▲▼** buttons to select the number of the timer recording you want to delete, and then press the **OK** button.

- The "Edit" and "Delete" items are displayed.



5 Press the **▲▼** buttons to select "Delete", and then press the **OK** button.

- You will be prompted with the delete confirm message such as "Do you want to delete 'No.01'?".

6 Press the **◀▶** buttons to select Yes, and then press the **OK** button.

- The selected entry will be deleted from the list.

7 Press the **MENU** button after finishing the operation. The menu screen will disappear.

## Videoplus+ Extended

To prevent delays or over-runs the DVD Recorder ~VCR has a function called VideoPlus+ Extended allowing you to extended the recording time by up to 60 minutes.

- Only use if PBC is not available or set to OFF.

1 Open "MENU"


With the DVD in Stop, press the **MENU** button.

2 Select "Program"

Using the **▲▼** buttons, move the selection bar to "Programme" then press **►** or **OK** to select.

3 Select "VideoPlus+ Extended"

Using the **▲▼** buttons, move the selection bar to "VideoPlus+ Extended", then press **OK** to select.



4 Press the corresponding **▲▼** buttons, until the VideoPlus+ Extended time, then the press **►** or **OK** to select.

5 Press the **MENU** button after finishing the operation.

## Recording

## Watching the Images Being Recorded (Time Slip)



This function allows you to watch the recently recorded 10-second images on the PIP screen while a recording is in progress.

### 1

- Press the **TIME SLIP** button on the remote control.
- The recently recorded 10-second images are played back on the PIP screen.
  - This function starts to operate 10 seconds from the time you press the **REC** button.
  - On the **TIME SLIP** screen, you can playback, scan, or perform other operations for the recorded program using the playback related buttons.
- Press the **◀▶** button to scan the recording in the reverse order, from the end to the start. Press the **▶▶** button to scan to the recently recorded 10-second images.

### 2

- Press the **■(STOP)** button once to clear the **TIME SLIP** function.
- To stop a recording while a **TIME SLIP** function is in progress, press the **■(STOP)** button twice.



- The Time Slip feature only works with DVD-RAM discs.
- The Time Slip function is not supported in the DV recording mode.

## Recording From External Devices

Preparatory

Check the remaining time of disc and tape for the recording. Adjust the recording speed.

### 1

Connect the Output jack of your External Devices to the SCART input connector or AUX on the front of using Audio/Video Cable.

### 2

Power on your DVD Recorder-VCR and switch to input source mode by pressing the **INPUT SEL** on the remote .  
The front panel display changes on the following sequence  
↓ PR → AV1 → AV2 → AUX → DV

### 3

When your DVD Recorder-VCR is in the stop state, set the operation mode of your External Devices to play mode.

### 4

Press the **●(REC)** button on your DVD Recorder-VCR when the image from which you want to start recording is displayed.

### 5

Press the **■(STOP)** button on your DVD Recorder-VCR when the recording is finished.



- Also refer to the user manual for your External Devices when recording through input mode using Audio/Video cable or Scart jack.

## Recording through a DV jack



Follow these directions to record onto a disc the outputs of a camcorder that has a DV output jack.

### 1

Connect the DV output jack of your camcorder to the DV input jack on the front of your DVD Recorder-VCR using a DV cable.

### 2

Power on your DVD Recorder-VCR and switch to DV mode by pressing the **INPUT SEL** on the remote.

### 3

With your DVD Recorder-VCR stopped, set the operation mode of your camcorder to play mode.

### 4

Press the **●(REC)** button on your DVD Recorder-VCR when the image from which you want to start recording is displayed.

### 5

Press the **■(STOP)** button on your DVD Recorder-VCR when the recording is finished.



- Some camcorders may not work with your DVD Recorder-VCR even if they have a DV output jack.
- Also refer to the user manual for your camcorder when recording through a DV jack.

## Basic VCR Recording



1. Check TV Programme and Antenna connections.
  2. Check the remaining time on the tape.
- You can record a TV show in progress by inserting a blank tape and pressing the **●(REC)** button. You can even add time in 30-minute increments up to 9 hours by pressing the **●(REC)** button repeatedly; see page 71.



- Be sure your videotape has a Record Safety Tab. If the tab is missing, you can cover the opening with a small piece of tape. Warning: Do not cover this opening unless you are sure you want to record over the tape.

### 1 Insert Tape

Insert a blank Video Tape into the VCR deck.

- Make sure the tape is long enough to record the entire program.

To change the Recording Speed, see page 80.

### 2

**Select a Programme to Record**  
Use the 0-9 buttons or the **PROG/TRK V / ^** buttons to select the desired Programme, or press the **INPUT SEL** button to select AV1, AV2 or AUX or DV if recording from an external device connected to the front or rear inputs, respectively.

### 3 Start Recording

Press the **REC** button on the remote control or front panel.  
For options while recording is in progress, see "Special Recording Features".

### 4

**Pause/Resume Recording**  
Press the **II (REC PAUSE)** button.  
Press **●(REC)** again to resume.

### 5

**Stop Recording**  
Press the **■(STOP)** button.

## Special Recording Features

While a recording is in progress, you can watch a different Programme, watch a different media, or add recording time in 30-minute increments.

### 1 Watch a Different Channel

Press the TV/VCR button on the remote to switch to your TV tuner, then select a different channel on your television.

### 2 Watch a different media during recording

You can watch DVD during VCR recording or watch Video tape during DVD recording.

- During VCR recording, insert a DVD in the DVD deck. The output will automatically change to the DVD and start playback.
- During DVD recording, insert a Video tape in the VCR deck. The output will automatically change to the VCR and start playback. (Only if tape is missing the safety tab)

### 3 Add Recording Time

Refer to the One-Touch Recording (OTR).

### 4 Recording DVD and VCR at the same time

You can record DVD and VCR at the same time, but both modes must be set up to record separately.

- Press the DVD/VCR button to set the unit to DVD or VCR mode.
- Choose input mode (PR, AV1, AV2/AUX, DV) for DVD or VCR.
- Choose REC SPEED for DVD or VCR.
- Press REC button for DVD or VCR.



When DVD Recorder-VCR is connected to TV using S-Video cable, the playback screen on the video tape will not display during DVD recording.

- You cannot record different channel at the same time.
- The DVD and VCR cannot start recording at the exact same time. You must set one mode to start recording, then the other.

## Record Speed

You can slow down the recording speed from SP to LP in order to fit 3 hours of programming on a E-180 tape.

### 1 Start Recording

Follow the Basic VCR Recording on page 79.

### 2 Set Record Speed

Press the REC SPEED button on the remote control to set the Record Speed to one of the following options:

- SP – Standard Play, for best picture quality.
- LP – Long Play, for maximum recording time (3 times SP).



The selected Record Speed will appear on the front panel display and on-screen display.

### Maximum Recording Time

Type	Recording Time (in SP)
E-180	180 mins. or 3 hours
E-240	240 mins. or 4 hours
E-280	280 mins. or 4 hours and 40 mins.
E-300	300 mins. or 5 hours




When you watch or record on the VCR during DVD Recording, some function buttons may not operate.  
The message "This function is not available." will be displayed.

## Copy to DVD or VCR



You can copy DVD to VCR or VCR to DVD. Press MENU button and select Copy.



### DVD to VCR




### 1 Select DVD -> VCR to copy DVD to VCR.

- Check the remaining time on the tape.


### 2 If you want to copy from the Copylist, choose "Edit Copylist".

- To copy from "Edit Copylist", you need to make a Copylist. To make and select a "New Copylist" (See pages 91-92).
- If you want to copy directly, choose "Direct Copy".



### 3 Select the Copylist, you want to copy

using the ▲▼ buttons and then press ► button. To copy play list, select "Copy".



### 1 Direct copy DVD to VCR



### 1 Insert DVD disc you want to copy.

### 2 Insert VHS tape.

### 3 Press VCR copy button on front panel or remote control.


### 4 To stop recording press the STOP button.

## Recording




■ VCR to DVD


- 1 Select VCR --> DVD to copy VCR to DVD.  
VCR --> DVD scene will be displayed.
- Check the remaining time on the disc.




- 2 Press OK button to select the start position.  
You can use ►, ◀, or ◀◀ or ▶▶ buttons to search for the Start position.




- 3 Select the End position in the same way.  
A copylist will be generated.
- The copylist cannot be saved if you press the RETURN or MENU button to exit the menu.



- 4 Press OK button to choose the list you want to copy.



- 5 To copy Copylist, select "Copy".



- The VCR will fast forward, searching for a start position and then automatically start a copy.
- It may not be match up with Start and END point exactly.
- If you want to copy all copylist, select "Copy All".

■ Direct copy VCR to DVD

- 1 Insert the VHS tape you want to copy.
- 2 Insert Recordable DVD disc.
- 3 Press DVD COPY button on front panel or remote control.
- 4 To stop recording press the STOP button.


# Editing

## Viewing the Menu Functions for a Disc




There are a variety of menu functions depending on the disc type. Press the MENU button.

■ No Disc




■ DVD-VIDEO




• Viewing the Menu Functions for a Disc	83
• Viewing Title List	85
• Playing a Title List Entry	86
• Renaming a Title List Entry	87
• Deleting a Title List Entry	88
• Locking a Title List Entry	89
• Deleting a Section from a Title List Entry	90
• Creating a Playlist Entry	91
• Editing a Playlist Entry	93
• Editing Scene for a Playlist Entry	94
• Copying a Playlist Entry to the VCR	98
• Deleting a Playlist Entry from the Playlist	98
• Disc Manager	99




## CD




## DVD-RW(VR)




## JPEG+MP3



## DVD-R(V)



## DVD-RAM(VR)




- Press the MENU button again to hide the menu screen. You can configure the settings on the Setup screen using the arrow and OK buttons.
- If recording or editing could have been finished properly because of any kinds of error, such as sudden power failure, The recording or editing might have not been done. Please be aware that a material that has been damaged is unable retrieved to its original content.

## Viewing Title List

You can playback the recorded titles, edit a title name, edit record list entries and lock or unlock the record list.

- 1 Insert the recorded disc.  
Press the MENU button.




■ Title List : Title refers to a recorded video stream. Title List shows a list to help you select a title. Since the title list consists of the information on data that is actually recorded, if one title is deleted, that title cannot be played again.

## 2

Press the ▲▼ buttons to select Title List, and then press the ► or OK button, or press the TITLE LIST button on the remote control.

- The Title List screen is displayed.



- ① Playback screen for recorded entry.
- ② Information window for the selected entry: Title name, recording date, recording time, lock status, recording mode.
- ③ Recorded entry No.
- ④ Recorded entry title.
- ⑤ Recording duration (i.e., playtime).
- ⑥ Record list edit items.
- ⑦ Button display.

## Record List edit items

## 1

- Press the ▲▼ buttons to select an entry to edit, and then press the ► or OK button.
- Play : Playbacks the selected entry.
- Rename : Renames the title of the selected entry.
- Delete : Deletes the selected entry from the list.
- Edit : Deletes a desired section (DVD-RAM/DVD-R(VR mode))
- Protection : Locks or unlocks the selected entry.

## 2

Press the MENU button after the operation is finished. The menu screen will disappear.

## Editing

## Editing

# Playing a Title List Entry



Follow these directions to playback an entry from the Title List.



4 Press the **▲▼** buttons to select Play, and then press the OK button.

- The selected entry (title) will be played back.



You can also playback a recorded program by pressing the QUICK button using the title, chapter or time items.

1 Insert the recorded disc.  
Press the MENU button.



2 Press the **▲▼** buttons to select Title List, and then press the **►** or OK button, or press the TITLE LIST button on the remote control.

- The View Title List screen is displayed.

3 Press the **▲▼** buttons to select an entry you want to playback from Title List, and then press the **►** or OK button.

- The Edit Title List menu is displayed.

# Renaming a Title List Entry



Follow these directions to rename a title list entry, i.e., to edit the title of a recorded program.


1 Insert the recorded disc.  
Press the MENU button.

2 Press the **▲▼** buttons to select Title List, and then press the **►** or OK button, or press the TITLE LIST button on the remote control.

- The View Title List screen is displayed.


3 Press the **▲▼** buttons to select an entry you want to rename from Title List, and then press the **►** or OK button.

- The Edit Title List menu is displayed.



4 Press the **▲▼** button to select Rename, and then press the OK button.

- The Rename screen is displayed.




5 Enter the desired characters using the arrow (**▲▼◀▶**) buttons.

- Back Space: Moves the cursor to the previous character. (Functions the same as CLEAR.)
- Space: Enters a blank and moves the cursor to the right.
- Delete: Deletes the character at the cursor position.
- Clear: Deletes all the character inputs.
- Save: Registers the character inputs.

6 Press the arrow buttons to select Save, and then press the OK button.

- The changed title is displayed on the title item of the selected entry.



## Deleting a Title List Entry



Follow these directions to delete an entry from the Title List.


- 1 Insert the recorded disc.  
Press the MENU button.

- 2 Press the **▲▼** buttons to select Title List, and then press the **►** or OK button,  
or press the **TITLE LIST** button on the remote control.

- The View Title List screen is displayed.

- 3 Press the **▲▼** buttons to select an entry you want to delete from Title List, and then press the **►** or OK button.


- The Edit Title List menu is displayed.



Editing

- 4 Press the **▲▼** buttons to select Delete, and then press the OK button.
- DVD-RAM, DVD-RW(VR mode): Since Playlist is present, the message "Do you want to delete? (Related Playlist may be deleted)" is displayed.
  - DVD-RW(Video mode), DVD-R: Since Playlist is not present, the message "Do you want to delete?" is displayed.
  - You cannot delete a protected entry.

If you want to delete a protected entry, select "OFF" in the protection menu.



- Be careful, since you cannot recover an entry once it is deleted from Title List.

- 5 Press the **◀▶** buttons to select yes and then press the OK button.

## Locking a Title List Entry




Follow these directions to lock an entry if you want to protect it from unexpected deletions.

- 1 Insert the recorded disc.  
Press the MENU button.


- 2 Press the **▲▼** buttons to select Title List, and then press the **►** or OK button.
- The View Title List screen is displayed.

- 3 Press the **▲▼** buttons to select an entry you want to protect from Title List, and then press the **►** or OK button.
- The Edit Title List menu is displayed.



Editing

- 4 Press the **▲▼** buttons to select Protection, and then press the OK button.
- You will be prompted with the confirmation message "Title Protection".



- 5 Press the **◀▶** buttons to select On, and then press the OK button.
- The Lock icon (a padlock) on the information window for the selected entry changes to the locked status.

## Deleting a Section from a Title List Entry




Follow these directions to delete a section from a Title List entry.

- 1 Insert the recorded disc.  
Press the MENU button.  
• You cannot recover a section once it is deleted from Title List.

- 2 Press the **▲▼** buttons to select Title List, and then press the **▶** or OK button,  
or press the **TITLE LIST** button on the remote control.  
• The View Title List screen is displayed.


- 3 Press the **▲▼** buttons to select an entry you want to edit from Title List, and then press the **▶** or OK button.  
• The Edit Title List menu is displayed.



Editing

- 4 Press the **▲▼** buttons to select Edit, and then press the OK button. The Edit Program is displayed.


- ① Playback bar
- ② Playtime
- ③ Section deletion start point window and time
- ④ Section deletion end point window and time



- 5 Search the start points of the section you want to delete using the playback related buttons.  
• Playback related buttons: **▶**, **⏮**, **⏪**, **⏩**, **⏭**, **⏮**.


- Note
- Be careful, since you cannot recover a section once it is deleted from Title List.

- 6 Press the **▲▼** buttons to select Start, and then press the OK button.  
• The image and time at the start point are displayed on the start window.



- 7 Press the OK button at the end point.

- 8 The image and time at the end point are displayed the end point window.



- 9 Press the **▲▼** buttons to select Delete, and then press the OK button.  
• Message "Do you want to delete?" will be displayed.  
• If you want to cancel, press RETURN button to return to the Title List screen.



- 10 Press the **◀▶** buttons to select yes and then press the OK button.

- 11 Press the MENU button to exit the menu after the operation is finished.  
The Title List screen will disappear.

- Note
- The length of the selection to delete should be at least 5 seconds long.
  - If the length of the section to delete is less than 5 seconds, you will be prompted with the message "The range is too short".
  - If the end time precedes the start time, you will be prompted with the message "End point cannot be marked earlier than start point".


## Creating a Playlist Entry



Follow these directions to create a new playlist entry from a recorded title.

- 1 Insert the recorded disc.  
Press the MENU button when the disc is stopped.

- 2 Press the **▲▼** buttons to select Playlist, and then press the **▶** or OK button.




- 3 Press the **▲▼** buttons to select New Playlist, and then press the **▶** or OK button.  
• The Make Scene screen is displayed.


Editing

- Note
- Playlist : The Playlist is a unit of playback, that is created by selecting a desired scene in the Title List. Since only the information necessary for playing a desired scene is included in a playlist, even if that playlist is deleted, the original data will not be deleted.

- 4 Select the start point of the section from which you want to create a new scene using the playback related buttons, and then press the **►II** button.
- Playback related buttons: **►II**, **►II**, **◀◀**, **▶▶**




- 5 Press the **▲▼** buttons to select Start, and then press the OK button.
- The image and time at the start point are displayed on the Start window.
  - The yellow-colored selection bar moves to the End item.



- 6 Search the end point of the section from which you want to create a new scene using the playback related buttons, and then press the **►II** button.

- 7 Press the OK button to select END point.
- The image and time at the end point are displayed on the End window.
  - The yellow-colored selection bar moves to the Make item.



- 8 Press the OK button to confirm.
- A new make scene screen is displayed.
  - Scenes to be made will be added to the current playlist.
  - Repeat the above steps to make more than one scene.

**Note**

- If you want to make a new playlist, go to the beginning of step1.
- You can check and see all the scenes on Edit scene screen. (see page 94)

- 9 If you want to cancel, press the **▲▼** buttons to select RETURN, and then select the **►** or OK button.
- The Edit Playlist screen is displayed.

- 10 Press the MENU or RETURN button to exit the menu.
- The Playlist screen will disappear.

**Note**


- You can create up to 99 playlist entries.

## Editing a Playlist Entry




Follow these directions to playback or edit (rename, edit scene, copy and delete) the newly created playlist entries.


- 1 Insert the recorded disc.  
Press the MENU button when the disc is stopped.
- 2 Press the **▲▼** buttons to select Playlist, and then press the **►** or OK button.
- 3 Press the **▲▼** buttons to select Edit Playlist, and then press the **►** or OK button, or press the **PLAY LIST** button on the remote control.



- 4 Press the **▲▼** button to select an entry (title) you want to edit from the Playlist, and then press the **►** or OK button.
- The Edit Playlist menu is displayed.



- 5 Press the **▲▼** buttons to select a function to use, and then press the OK button.
- **Play:** Playbacks the selected entry.
  - **Rename:** Renames the title of the selected entry. Functionality is the same as the Rename item in the Edit Record List.
  - **Edit Scene:** Edits scenes of the selected entry.
  - **Copy:** Copies the selected entry to the VCR.
  - **Delete:** Deletes the selected entry from the list.



- 6 Press the MENU or PLAY LIST button after the operation is finished. The Playlist screen will disappear.

## Playing Playlist Entries

Follow these directions to playback the playlist entries.


- 1 Press the **▲▼** buttons to select Play, and then select the OK button.
  - 2 Press the **■** (STOP) button to stop the playback in progress.
- The playlist entries will be played back.
  - The screen returns to the Edit Playlist screen when the playback is finished.
  - The screen returns to the Edit Playlist screen.

**■ Renaming Playlist Entries**

Follow these directions to rename a playlist entry, i.e., edit the title of a playlist entry.

- 1 Press the **▲▼** buttons to select Rename, and then press the OK button.
- The Rename screen is displayed.

- 2 Select the desired characters using the arrow **▲▼◀▶** buttons.
- Functionality is the same as the Rename item in the Edit Record List screen.



- 3 Press the arrow buttons to select save, and then press the OK button.
- The Name you changed is displayed on the title item of the selected playlist entry.

**Editing Scene for a Playlist Entry**



VR mode


Follow these directions to edit scenes for a playlist entry.

- 1 Insert the recorded disc.
- Press the MENU button when the disc is stopped.


- 2 Press the **▲▼** buttons to select Playlist, and then press the **▶** or OK button.

- 3 Press the **▲▼** buttons to select Edit Playlist, and then press the **▶** or OK button, or press **PLAY LIST** button on the remote control.
- The Edit Playlist screen is displayed.

- 4 Press the **▲▼** buttons to select an entry (title) you want to edit from the Playlist, and then press the **▶** or OK button.
- The Edit Playlist menu is displayed.




- 5 Press the **▲▼** button to select Edit Scene, and then press the OK button.
- The Edit Scene screen is displayed.



**■ A. Playing a Desired Scene**

- 1 Press **▲▼◀▶** buttons to select the scene you want to playback, and then press the OK button.
- The playlist entry to playback is selected.




- 2 Press the OK button.
- The selected scene is played back.


**■ B. Modifying a Scene (Replacing a Scene)**

- 1 Press **▲▼◀▶** buttons to select the scene you want to modify, and then press the OK button.


- 2 Press **▲▼** buttons to select Modify, and then press the OK button.
- The Modify Scene screen is displayed.



- 3 Select the start point of the section with which you want to modify the selected scene using the playback related buttons.
- Playback related buttons: **▶▶**, **▶**, **◀**, **◀◀**.



- 4 Press the **▲▼** buttons to select Start, and then press the OK button.
- The image and time at the start point are displayed on the Start window.



Editing


### E. Deleting a Scene from the Playlist

- 1 Press **▲▼◀▶** buttons to select the scene you want to delete, and then press the **OK** button.
- 2 Press the **▲▼** buttons to select delete, and then press the **OK** button.

## 4

Press the **▲▼** buttons to select Start, and then press the OK button.


- The image and time at the start point are displayed on the Start window.



## 5


Select the end point of the section you want to add as a new scene using the playback related buttons.

6 Press the **▲ ▼** buttons to select End, and then press the OK button.



Press the **▲ ▼** buttons to select Add, and then press the OK button.

The section you wanted to add is added before the scene selected in step 1.




If you want to cancel select cancel and then press the OK button.

### 3

Press **▲ ▼ ◀ ▶** buttons to select the position where you want to move the selected scene, and then press the **OK** button.

The selected scene is moved to the new position.



■ You cannot move the selected scene to the position of the next scene, because the selected scene should be inserted before that position

#### D. Adding a Scene

**1** Press **▲ ▼ ◀ ▶** buttons to select the scene before which you want to add a new scene, and then press the **OK** button.

A yellow selection window is displayed on the scene to add as a new scene.

2 Press the ▲ ▼ buttons to select Add and then press the OK button.

The Add Scene screen is displayed.


### 3

Select the start point of the section to which you want to add the scene in step 1 using the playback related buttons.

Playback related buttons: , , , , , 

## 5

Press the OK button at the end point of the scene.



**6** Press the **▲▼** buttons to select Change, and then press the **OK** button.

- The scene you wanted to modify is changed with the selected section.
- If you want to cancel a modification, select cancel and then press the OK button.


### C. Moving a Scene (Changing the Position of a Scene)

# 1

Press **▲ ▼ ◀ ▶** buttons to select the scene you want to move (change the position), and then press the OK button.

2 Press the **▲ ▼** buttons to select Move, and then press the OK button.

- A yellow selection window is displayed on the scene to move.



## Copying a Playlist Entry to the VCR




VCR mode

- 1 Insert the recorded disc and the tape. Press the MENU button when the disc is stopped.

- 2 Press the **▲▼** buttons to select Playlist, and then press the **▶** or OK button.

- 3 Press the **▲▼** buttons to select Edit Playlist, and then press the **▶** or OK button, or press the **PLAY LIST** button on the remote control.

- The Edit Playlist screen is displayed.



- 4 Press the **▲▼** buttons to select an entry(title) you want to copy to the VCR, and then press the **▶** or OK button.

- The Edit Playlist menu is displayed.

Play, Rename, Edit Scene, Copy, Delete

- 5 Press the **▲▼** buttons to select Copy, and then press the OK button.

- The title you choose is played and copied to VCR tape.

## Deleting a Playlist Entry from the Playlist



VCR mode

- 1 Insert the recorded disc. Press the MENU button when the disc is stopped.

- 2 Press the **▲▼** buttons to select Playlist, and then press the **▶** or OK button.


- 3 Press the **▲▼** buttons to select Edit Playlist, and then press the **▶** or OK button, or press the **PLAY LIST** button on the remote control.

- The Edit Playlist screen is displayed.

- 4 Press the **▲▼** buttons to select an entry (title) you want to delete from the Playlist, and then press the **▶** or OK button.


- The Edit Playlist menu is displayed.

Play, Rename, Edit Scene, Copy, Delete




- 5 Press the **▲▼** buttons to select Delete, and then press the OK button.

- You will be prompted with the delete confirmation message "Do you want to delete?".



- 6 Press the **◀▶** buttons to select Yes, and then press the OK button.

- The screen returns to the Edit Playlist screen automatically after the delete operation finished.



## Disc Manager



### Editing Disc Name

Follow these directions to give a name to a disc

- 1 Insert the disc. Press the MENU button when the disc is stopped.


- 2 Press the **▲▼** buttons to select Disc Manager, and then press the **▶** or OK button.



- 3 Press the **▲▼** buttons to select Disc Name, and then press the **▶** or OK button.

- The Edit Name screen is displayed.

- 4 Enter the desired characters using the arrow buttons.





- 5 Press the **▲▼▶◀** buttons to select Save, and then press the OK button.
- A disc name is given to the disc.




**Note** You may need to clear cartridge protection or unlock the protect before beginning editing.

### Disc Protection


Disc Protection allows you to protect your discs from disc format and program deletion due to unintended operations.

- 1 Press the MENU button when the disc is stopped.


- 2 Press the **▲▼** buttons to select Disc Manager, and then press the **▶** or OK button.



- 3 Press the **▲▼** buttons to select Disc Protection, and then press the **▶** or OK button.



- 4 Press the **▲▼** buttons to select Protected, and then press the OK button.



**Note** Disc Protection will operate only if cartridge protect is cleared.

### Formatting a DVD-RAM/DVD-RW Disc

Use these instructions to format a disc. The cartridge write protect tab should be set to the unprotected position. The disc protection should also be cleared.


- 1 Insert a disc to be formatted.  
Press the MENU button with the disc stopped.

- 2 Press the **▲▼** buttons to select Disc Manager, and then press the **▶** or OK button.




- 3 Press the **▲▼** buttons to select Disc Format, and then press the **▶** or OK button.

- You will be prompted with the confirmation message 'Do you want to format disc?'.
- If you select "Yes" you will be prompted with the confirmation message 'All data will be deleted. Do you want to continue?'.



- 4 Press the **◀▶** buttons to select Yes, and then press the OK button.
- The disc is formatted.

**DVD-RW**  
You will be prompted with the confirmation message "Choose the recording format for DVD-RW".



DVD-VR and DVD-V are defined according to their recording format


Editing	DVD-VR	DVD-V
DISC	Possible (Partial editing is possible)	Inconvenience
	DVD-RAM	DVD-RW
	DVD-RW	DVD-R

Editing


Delete All Title Lists

Follow these instructions to delete all title lists.

- 1 Insert the recorded disc.  
Press the MENU button with the disc stopped.
- 2 Press the **▲▼** buttons to select Disc Manager, and then press the **►** or OK button.



- 3 Press the **▲▼** buttons to select Delete All Title Lists, and then press the **►** or OK button.
- You will be prompted with the confirmation message 'Do you want to delete all title lists?':



- You cannot delete a protected entry. If you want to delete a protected entry, disable Protection for it on the Lock Item.
- Disc Protection: When Protected or Cartridge Protection has been set, or when a DVD-RAM is used, data cannot be deleted from a disc.

- 4 Press the **◀▶** buttons to select Yes, and then press the OK button.
- The disc is deleted.

Cartridge Protect Info (DVD-RAM)


Disc Protect allows you to protect discs from disc formatting and program deletion due to unintended operations. The cartridge write protect tab should be set to the unprotect position to be able to make a recording to a DVD-RAM disc.

- 1 Press the MENU button with the disc stopped.
- 2 Press the **▲▼** buttons to select Disc Manager, and then press the **►** or OK button.

- 3 Press the **▲▼** buttons to select Cartridge Protection Info, and then press the **►** or OK button.
- The cartridge protection info for the disc is displayed.
- If the disc cartridge is protected, open the disc tray and check the disc.



If the disc cartridge is not protected, proceed with recording to the disc.



- Disc Protection will operate only if cartridge protect is set to Not Protected.


Finalising a disc

After you record titles onto a DVD-RW/DVD-R disc with your DVD Recorder/VCR, it needs to be finalised before it can be played back on external devices.

- 1 Insert the recorded disc.  
Press the MENU button with the disc stopped.
- 2 Press the **▲▼** buttons to select Disc Manager, and then press the **►** or OK button.



- 3 Press the **▲▼** buttons to select Disc Finalise, and then press the **►** or OK button.
- You will be prompted with the message 'Do you want to finalise disc?'. If you select Yes, you will be prompted again with the message 'Disc will be finalised. Do you want to continue?'




- Press the **◀▶** buttons to select Yes, and then press the OK button.
- The disc is finalised.

- Once a disc is finalised, you cannot delete entries from the record list.
- After being finalised, the DVD-R operates in the same manner as a DVD-Video.
- Depending on the kind of disc, the displayed screen may be slightly different.
- Finalising will be taken few minutes. If you turn the unit on/off or open the tray during finalising, you will not be able to use the disc anymore.



Unfinalising a disc (VVR mode)



- 1
- Insert the finalised disc.  
Press the MENU button with the disc stopped.
- 2
- Press the **▲▼** buttons to select Disc Manager, and then press the **▶** or **OK** button.



- 3
- Press the **▲▼** buttons to select Disc Unfinalise, and then press the **▶** or **OK** button.
- You will be prompted with the message 'Do you want to unfinalise disc?'. If you select 'Yes', you will be prompted again with the message 'Disc will be unfinalised. Do you want to continue?'



Press the **◀▶** buttons to select Yes, and then press the **OK** button.

- The disc is unfinalised.

- A DVD-RW can be finalised or unfinalised in Video mode.

Mark	Finalise	Unfinalise
Operation	DVD-VIDEO(RW) Same as DVD-Video	DVD-RW(V) Additional recording, protection and deletion are possible.

- A DVD-RW can be finalised or unfinalised in VR mode.

Mark	Finalise	Unfinalise
Operation	DVD-RW(VR(F)) Additional recording, deletion, editing, and protection are impossible.	DVD-RW(VR) Additional recording, deletion, editing, and protection are possible.

## MEMO

# 5. Disassembly and Reassembly

## 5-1 Cabinet and PCB

### 5-1-1 Cabinet Top Removal




Fig. 5-1 Cabinet Top Removal

### 5-1-2 Ass'y Bottom Cover Removal




Fig. 5-2 Ass'y Bottom Cover Removal

### 5-1-3 Ass'y Front Panel Removal




Fig. 5-3 Ass'y Front Panel Removal(Top View)




Fig. 5-4 Ass'y Front Panel Removal(Bottom View)

## 5-1-4 Chassis Removal




Fig. 5-5 Chassis Removal

## 5-1-5 VCR Main PCB Removal




Fig. 5-6 VCR Main PCB Removal

## 5-2 Circuit Board Locations




Fig. 5-7 Circuit Board Locations

## 5-3 VCR Deck Parts Locations

### 5-3-1 Top View




Fig. 5-8 Top parts Location-1

- ❶ GEAR FL CAM
- ❷ MOTOR LOADING ASS'Y
- ❸ LEVER FL ARM ASS'Y
- ❹ HOLDER FL CASSETTE ASS'Y
- ❺ LEVER FL DOOR
- ❻ SLIDER FL DRIVE






Fig. 5-9 Top Parts Location-2

- |                          |                       |
|--------------------------|-----------------------|
| ① FE HEAD                | ⑧ DISK S REEL         |
| ② CYLINDER ASS'Y         | ⑨ LEVER S BRAKE ASS'Y |
| ③ ACE HEAD ASS'Y         | ⑩ GEAR IDLE           |
| ④ LEVER UNIT PINCH ASS'Y | ⑪ LEVER IDLE          |
| ⑤ LEVER #9 GUIDE ASS'Y   | ⑫ LEVER T BRAKE ASS'Y |
| ⑥ LEVER TENSION ASS'Y    | ⑬ DISK T REEL         |
| ⑦ BAND BRAKE ASS'Y       |                       |

### 5-3-2 Bottom View




Fig. 5-10 Bottom Parts Location

- ❶ GEAR JOINT 1
- ❷ GEAR JOINT 2
- ❸ BRACKET GEAR
- ❹ MOTOR CAPSTAN ASS'Y
- ❺ LEVER T LOAD ASS'Y
- ❻ GEAR LOADING DRIVE
- ❼ LEVER S LOAD ASS'Y
- ❽ HOLDER CLUTCH ASS'Y
- ❾ BELT PULLEY
- ❿ SLIDER CAM

## 5-4 VCR Deck

### 5-4-1 Holder FL Cassette Ass'y Removal

- 1) Pull the Holder FL Cassette Ass'y ❶ to the eject position.
- 2) Pull the Holder FL Cassette Ass'y ❶ as grasping the Holder FL Cassette Ass'y ❶ and Lever FL Cassette-R ❷ in the same time to release hooking from Main Base until the Boss [A] of Holder FL Cassette Ass'y ❶ is taken out from the Rail [B].
- 3) Lift the Holder FL Cassette Ass'y ❶, in this time, you have to grasp the Lever FL Cassette-R ❷ continuously until the Holder FL Cassette Ass'y ❶ is taken out completely.

**Note :** Be sure to insert Lever FL Cassette-R ❷ in the direction of "A" to prevent separation and breakage of the Lever FL Cassette-R ❷ at disassembling and reassembling.




Fig. 5-11 Holder FL Cassette Ass'y Removal

### 5-4-2 Lever FL Arm Ass'y Removal

- 1) Push the hole "A" in the direction of arrow "B" use the pin.(about Dia. 2.5)
- 2) Pull out the Lever FL Arm Ass'y ❶ from the Boss of Main Base.
- 3) Remove the Lever FL Arm Ass'y ❶ in the direction of arrow "C".




Fig. 5-12 Lever FL Arm Ass'y Removal

### 5-4-3 Lever FL Door Removal

- 1) Release the Hook ❷ and Remove the Lever FL Door ❶ in the direction of arrow "A".




Fig. 5-13 Lever FL Door Removal

### 5-4-4 Slider FL Drive, Gear FL Cam Removal

- 1) Pull the Slider FL Drive ❶ to the front direction.
- 2) Remove the Slider FL Drive ❶ in the direction of arrow. (Refer to Fig. 5-13)
- 3) Remove the Gear FL cam ❷.

**Note :** When reinstalling be sure to reassemble Slider FL drive ❶ after you insert the Boss of Lever FL ARM-R in Groove of Slider FL drive ❶.

**Assembly :** Align the Gear FL Cam ❶ with the Gear worm wheel Post as shown drawing. (Refer to Timing point)




Fig. 5-14 Slider FL Drive Removal




Fig. 5-15 Gear FL Cam, Gear Worm

### 5-4-5 Gear Worm Wheel Removal

- 1) Remove the Gear Worm wheel **1**.




Fig. 5-16 Gear Worm Wheel Removal

### 5-4-6 Cable Flat Removal

- 1) Remove the Drum connecting part of Cable Flat **1** from Connector Wafer **2**.
- 2) Remove the Loading Motor connecting part of Cable Flat **1** from Connector Wafer **3**.




Fig. 5-17 Cable Flat Removal

### 5-4-7 Motor Loading Ass'y Removal

- 1) Remove the screw ❶.
- 2) Remove the Motor Loading Ass'y ❷.




Fig.5-18 Motor Loading Ass'y Removal

### 5-4-8 Bracket Gear, Gear Joint 2, 1 Removal

- 1) Remove the SCREW ❶.
- 2) Remove the Bracket Gear ❷.
- 3) Remove the Gear Joint 2 ❸.
- 4) Remove the Gear Joint 1 ❹.

#### Assembly :

- 1) Be sure to align dot mark of Gear Joint 1 ❶ with dot mark of Gear Joint 2 ❷ as shown Fig 5-20. (Refer to Timing point1)
- 2) Confirm the Timing Point 2 of the Gear Joint 2 ❷ and Slider Cam ❸.




Fig. 5-19 Bracket Gear, Gear Joint 1,2 Removal




Fig. 5-20 Gear Joint 1,2 Assembly

### 5-4-9 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Removal

- 1) Remove the Belt Pulley. (Refer to Fig. 5-38)
- 2) Remove the Gear Loading Drive ❶ after releasing Hook [A] in the direction arrow as shown in detail drawing.
- 3) Remove the Slider Cam ❷.
- 4) Remove the Lever Load S Ass'y ❸ & Lever Load T Ass'y ❹.




Fig. 5-21 Gear Loading Drive, Slider Cam, Lever T, S Load Ass'y Removal

### 5-4-10 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly

- 1) When reinstalling, be sure to align dot of Lever Load T Ass'y ❶ with dot of Lever Load S Ass'y ❷ as shown in drawing, (Refer to Timing Point 1).
- 2) Insert the Pin A,B,C,D into the Slider Cam ❸ hole,
- 3) Be sure to align dot of Lever Load T ❶ and dot of Gear Loading Drive ❹, (Refer to Timing Point 2).
- 4) Aline dot of Gear Loading drive ❹ with mark of Slider Cam ❸ as shown in drawing (Refer to Timing Point 3).




Fig. 5-22 Gear Loading Drive, Slider Cam, Lever Load S, T Ass'y Assembly

#### 5-4-11 Lever Pinch Drive, Lever Tension Drive Removal

- 1) Remove the Lever Pinch Drive ❶, Lever Tension Drive ❷.




Fig. 5-23 Lever Pinch Drive,  
Lever Tension Drive Removal

#### 5-4-12 Lever Tension Ass'y, Band Brake Ass'y Removal

- 1) Remove the Lever Brake S Ass'y (Refer to Fig 5-25).
- 2) Remove the Spring Tension Lever ❶.
- 3) Rotate stopper of Main Base in the direction of arrow "A".
- 4) Lift the Lever Tension Ass'y ❷ & Band brake Ass'y ❸.

##### Note :

- 1) When replacing the Lever Tension Ass'y ❷, be sure to apply Grease on the post,
- 2) Take care not to touch stain on the felt side, and not to be folder and broken Band brake Ass'y
- 3) After Lever Tension Ass'y seated, Rotate stopper of Main Base to the Mark[B].




Fig. 5-24 Lever Tension Ass'y,  
Band Brake Ass'y Removal



### 5-4-13 Lever Brake S, T Ass'y Removal

- 1) Release the Hook [A] and the Hook [B], [C] in the direction of arrow as shown in Fig 5-25.
- 2) Lift the Lever S, T Brake Ass'y ❶, ❷ with spring brake ❸.

#### Assembly :

- 1) Assemble the Lever S Brake Ass'y ❶ on the Main Base.
- 2) Assemble the Lever T Brake Ass'y ❷ with spring brake ❸.

**Note :** Take extreme care not to be folded and transformed Spring Brake at removing or reinstalling.




Fig. 5-25 Lever Brake S, T Ass'y Removal

### 5-4-14 Gear Idle Ass'y Removal

- 1) Push the Lever Idle ❶ in the direction of arrow "A", "B".
- 2) Lift the Lever Idle ❶.

#### Assembly :

- 1) Apply oil in two Bosses of Lever Idle ❶.
- 2) Assemble the Gear Idle ❷ with the Lever Idle ❶.

**Note :** When replacing the Gear Idle ❷, be sure to add oil in the boss of Lever Idle ❶.




Fig. 5-26 Gear Idle Ass'y Removal

## 5-4-15 Disk S, T Reel Removal

- 1) Lift the Disk S, T Reel ❶, ❷.




Fig. 5-27 Disk S, T Reel Removal

## 5-4-16 Holder Clutch Ass'y Removal

- 1) Remove the Washer Slit ❶.
- 2) Lift the Holder Clutch Ass'y ❷.

**Note :** When you reinstall Holder Clutch Ass'y

- 1) Check the condition of spring as shown in detail A.
- 2) Don't push Holder Clutch Ass'y down with excessive force Just insert Holder Clutch Ass'y into post center with dead force and Rotate it smoothly. Be sure to confirm that spring is in the slit of Gear Center Ass'y as shown in detail B.





Fig. 5-28 Holder Clutch Ass'y Removal

### 5-4-17 Lever Up Down Ass'y, Gear Center Ass'y Removal

- 1) Remove the 2 hooks in the direction of arrow as shown Fig. 5-28 and lift the Lever Up Down Ass'y ❶.
- 2) Lift the Gear Center Ass'y ❷.

#### Assembly :

- 1) Insert the Lever Up Down Ass'y ❶ in the rectangular holes on Main Base as shown in Fig 5-30.
- 2) Lift the Lever Up Down Ass'y ❶ about 35°.  
(Refer to Fig 5-30)
- 3) Insert Ring of the Gear Center Ass'y ❷ in the Guide of the Lever Up Down Ass'y ❶.
- 4) Insert the Gear Center Ass'y ❷ in the post on Main Base.
- 5) Push down the Lever Up Down Ass'y ❶ for locking of the Hook.

#### Note :

- 1) Take care not to separate and sentence does not mark sense.
- 2) Be sure to confirm that Ring of the Gear Center Ass'y ❷ is in the Guide of the Lever Up Down Ass'y ❶ after finishing assembly of Lever Up Down Ass'y ❶ and Gear Center Ass'y ❷.




Fig. 5-29 Lever Up Down Ass'y Removal




Fig. 5-30 Lever Up Down Ass'y Removal

### 5-4-18 Guide Cassette Door Removal

- 1) Lift the Hook [A].
- 2) Rotate the Guide Cassette Door ❶ in the direction of arrow.

**Note :** After reinstalling the Guide Cassette Door ❶ sure the Hook [A].




Fig. 5-31 Guide Cassette Door Removal

#### 5-4-19 Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal

- 1) Lift the Unit Pinch Ass'y ❶.
- 2) Remove the Plate Joint ❷ from Lever Pinch Drive.
- 3) Remove the Spring Pinch Drive ❸.

**Note :**

- 1) Take extreme care not to touch the grease on the Roller Pinch.
- 2) When reinstalling, be sure to apply grease on the post pinch roller.




Fig. 5-32 Lever Unit Pinch Ass'y, Plate Joint, Spring Pinch Drive Removal

#### 5-4-20 Lever #9 Guide Ass'y Removal

- 1) Remove the Spring #9 Guide ❶.
- 2) Lift the Spring #9 Guide Ass'y ❷ in the direction of arrow "A".

**Note :**

- 1) Take extreme care not to get grease on the tape Guide Post.
- 2) After reinstalling, check the bottom side of the Post #9 Guide to the top side of Main Base.




Fig. 5-33 Lever #9 Guide Ass'y Removal

### 5-4-21 FE Head Removal

- 1) Remove the screw ❶.
- 2) Lift the FE Head ❷.




Fig. 5-34 FE Head Removal

### 5-4-22 ACE Head Removal

- 1) Pull out the FPC from connector of ACE Head Ass'y ❷.
- 2) Remove the screw ❶.
- 3) Lift the ACE Head Ass'y ❷.




Fig. 5-35 ACE Head Removal

### 5-4-23 Slider S, T Ass'y Removal

- 1) Move the Slider S, T Ass'y ❶, ❷ to slot, and then lift it to remove. (Refer to arrow)




Fig. 5-36 Slider S, T Ass'y Removal

### 5-4-24 Plate Ground Deck, Cylinder Ass'y Removal

- 1) Remove the 3 Screws ❶.
- 2) Lift the Plate Ground Deck ❷.
- 3) Lift the Cylinder Ass'y ❸.

#### Assembly :

- 1) Match the 3 holes in the bottom of Cylinder ass'y ❸ to the 3 holes of Main Base as attending not to drop or knock the Cylinder ass'y ❸.
- 2) Tighten the 1 Screw ❶.
- 3) Match the Plate Ground Deck ❷ to the Hole of Base Main.
- 4) Tighten the other 2 Screws ❶.

#### Note :

- 1) Take care not to touch the Cylinder Ass'y ❸ and the tape guide post at reinstalling.
- 2) When reinstalling, Don't push down too much on Screw Driver.




Fig. 5-37 Plate Ground Deck, Cylinder Ass'y Removal

### 5-4-25 Hook Capstan, Belt Pulley Removal

- 1) Remove the Hook Capstan ❶ after realeasing Hook in the direction arrow as shown in detail drawing.
- 2) Remove the Belt Pulley ❷.

**Note :** Take extreme care not to get grease on Belt Pulley ❷ at assembling or reassembling.




Fig. 5-38 Hook Capstan, Belt Pulley Removal

### 5-4-26 Motor Capstan Ass'y Removal

- 1) Remove the Damper Capstan ❶ in the direction of arrow.
- 2) Remove the 3 Screws ❷.
- 3) Remove the Motor Capstan Ass'y ❸.

#### Assembly :

- 1) Match the 3 holes of Motor Capstan Ass'y ❸ to the 3 holes of Main Base. Be careful not to drop or knock the Motor Capstan Ass'y ❸.
- 2) Tighten the 3 Screws ❷ in the direction of arrow as shown detail drawing.
- 3) Assemble the Damper Capstan ❶.

**Note :** After tightening screws, check if there is gap between the head of screws and the top side of Main Base. There should have no gap between the head of screws and the top side of Main Base. After reinstalling, adjusting the tape transport system again.




Fig. 5-39 Motor Capstan Ass'y Removal

#### 5-4-27 Post #8 Guide Ass'y Removal

- 1) Rotate the Post #8 Guide Ass'y ❶ in the direction of arrow to lift up.




Fig. 5-40 Post #8 Guide Ass'y Removal

#### 5-4-28 Level Head Cleaner Ass'y Removal (Optional)

- 1) Release the Hook ❶.
- 2) Lift the Lever Head Cleaner Ass'y ❷.




Fig. 5-41 Lever Head Cleaner Ass'y Removal

#### 5-4-29 How to Eject the Cassette Tape (If the unit does not operate on condition that is inserted into housing ass'y)

- 1) Turn the Gear worm ❶ clockwise with screw driver.(Refer to arrow)  
(Other method : Remove the Screw of Motor Load Ass'y, Separate the Motor Load Ass'y)




Fig. 5-42

- 2) When Slider S,T are approached in the position of unloading, rotate holder Clutch counterclockwise after inserting screw driver in the hole of frame's bottom in order to wind the unwinded tape. (Refer to Fig.5-43)  
(If you rotate Gear Worm ❶ continuously when tape is in state of unwinding, you may cause a tape contamination by grease and tape damage. Be sure to wind the unwinded tape in the state of set horizontally.)
- 3) Rotate Gear Worm ❶ clockwise using screw driver again up to the state of eject mode and then pick out the tape.(Refer to Fig.5-42)




Fig. 5-43



## 5-5 The table of cleaning, Lubrication and replacement time about principal parts

- 1) The replacement time of parts is not life of parts.
- 2) The table 5-1 is that the VCR Set is in normal condition (normal temperature, normal humidity).  
The checking period may be changed owing to the condition of use, runtime and environmental conditions.
- 3) Life of the Cylinder Ass'y is depend on the condition of use.
- 4) See exploded view for location of each parts.

&lt;Table 5-1&gt;

*	Parts Name	Checking Period										Remark
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	
T A P E  P A T H  S Y S T E M	POST TENSION	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	- To clean the parts, use patch and alcohol (solvent).
	SLANT POST S, T	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	#8 GUIDE SHAFT	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	CAPSTAN SHAFT	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	- After cleaning, use the video tape after alcohol is gone away completely.
	#9 GUIDE POST	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	#3 GUIDE POST	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	
	GUIDE ROLLER S, T	Δ	Δ	Δ	0	0	0	0	0	0	0	- We recommend to use oil [EP-50] or solvent.
	CYLINDER ASS'Y	Δ	0	0	0	0	0	0	0	0	0	
	FE HEAD	Δ	Δ	Δ	0	0	0	0	0	0	0	
	ACE HEAD	Δ	0	0	0	0	0	0	0	0	0	- One or two drops of oil should be applied after cleaning with alcohol.
	PINCH ROLLER	Δ	0	0	0	0	0	0	0	0	0	
	POST REEL S, T		◆		◆		◆		◆		◆	
	SLEEVE TENSION		◆		◆		◆		◆		◆	- Periodic time of applying oil (Apply oil after cleaning) - The excessive applying oil may be the cause of malfunction.
	POST CENTER		◆		◆		◆		◆		◆	
	LEVER IDLE BOSS (2Point)		◆		◆		◆		◆		◆	
D R I V I N G  S Y S T E M	CAPSTAN MOTOR PULLEY	Δ	Δ	Δ	Δ	Δ	0	0	0	0	0	
	BELT PULLEY				0	0	0	0	0	0	0	
	HOLDER CLUTCH ASS'Y	Δ	0	0	0	0	0	0	0	0	0	
	GEAR CENTER ASS'Y		0	0	0	0	0	0	0	0	0	
	GEAR IDLE (2Point)		0	0	0	0	0	0	0	0	0	
	LOADING MOTOR		0	0	0	0	0	0	0	0	0	
B R A K E  S Y S T E M	BAND BRAKE ASS'Y		0	0	0	0	0	0	0	0	0	
	BRAKE T ASS'Y		0	0	0	0	0	0	0	0	0	

Δ : Cleaning

0 : Check and replacement in necessary

◆ : Add Oil

## MEMO

## 6. Alignment and Adjustments

### 6-1 VCR Adjustment

#### 6-1-1 Reference

- 1) X-Point (Tracking center) adjustment, "Head switching adjustment" and "NVRAM option setting" can be adjusted with remote control.
- 2) When replacing the Main PCB Micom (IC601) and NVRAM (IC603 ; EEPROM) be sure to adjust the "Head switching adjustment" and "NVRAM option setting".
- 3) When replacing the cylinder ass'y, be sure to adjust the "X-Point" and "Head switching adjustment".
- 4) How to adjust.
  - Intermittently short-circuit the Test Point on Main PCB with pincers to the adjustment mode.
  - If the corresponding adjustment button is pressed, the adjustment is performed automatically.
  - When the adjustment is completed, be sure to turn the power off.

#### 6-1-1(a) Location of adjustment button of remote control

- ✎ X-Point (Tracking Center) Adjustment ; ① + ⑤
- ✎ NVRAM Option Setting ; ① + ④
- ✎ Head Switching Adjustment ; ① + ①




Fig. 6-1

# 6-1-1(b) TEST location for adjustment mode setting




Fig. 6-2 VCR Main PCB (Top View)

## 6-1-2 Head Switching Point Adjustment

- 1) Playback the alignment tape.
- 2) Intermittently short-circuit the two Test Points on VCR Main PCB while setting the adjustment mode. (See Fig. 6-2)
- 3) Press the “1, 0” buttons; remote control adjustment operates automatically. (See Fig. 6-1)

## 6-1-3 NVRAM Option Setting

- 1) NVRAM Option is adjusted in the factory.
- 2) In case Main PCB Micom (IC601) and NVRAM (IC603 ; EEPROM) are replaced, be sure to set the corresponding option number of the required model. (If the option is not set, the unit will not operate.)

- 1) Intermittently short-circuit the two Test Points on VCR Main PCB. (See Fig. 6-2)
- 2) Press the “1, 4” button on the remote control. The option setting appears. (See Fig. 6-3)
- 3) Select the option number (See table 6-1) of corresponding model with “◀, ▶, ▲, ▼” buttons on the remote control.
- 4) After selecting the option number is completed, press the “▲” button of remote control.  
(If “▲” button is pressed, the selected number is changes color. ; See Fig. 6-4)
- 5) Press the “ENTER” button of remote control again to store the option number.
- 6) Turn the Power off.




Fig. 6-3




Fig. 6-4

&lt;Table 6-1 NVRAM Option Table&gt;

MODEL	OPTION NUMBERS
D-VR3SB	3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 17, 25, 26, 32, 34, 38, 40, 41,, 47, 61, 65, 66, 69, 70, 72
D-VR3SG	2, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 32, 34, 36, 38, 40, 42, 47, 61, 65, 66, 69, 70, 72
D-VR3SF	2, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 20, 21, 26,, 32, 33, 34, 35, 36, 38, 40, 47, 61, 65, 66, 69, 70, 72

## 6-2 VCR Mechanical Adjustment

### 6-2-1 Tape Transport System and Adjustment Locations

The tape transport system has been adjusted precisely in the factory. Alignment is not necessary except for the following :

- 1) Noise observed on the screen.
- 2) Tape damage.
- 3) Parts replacement in the tape transport system.

Lower flange height of tape guide is used as the reference for the transport adjustment.

To maintain the height of the tape guide and prevent damage, do not apply excessive force onto the main base.




Fig. 6-5 Location of Tape Transport Adjustment




Fig. 6-6 Tape Travel Diagram

## 6-2-2 Tape Transport System Adjustment

When parts are replaced, perform the required adjustments by referring to procedures for the tape transport system. If there are any changes to the tape path, first run a T-120 tape and make sure excessive tape wrinkle does not occur at the tape guides.

- ◆ If tape wrinkle is observed at the guide roller S, T, turn the guide roller S, T until wrinkle disappears.
- ◆ If the tape wrinkle is still observed at the tape guide, perform the tilt adjustment of the ACE head.

### (1) ACE Head Assembly Adjustment

#### a. ACE HEAD HEIGHT ADJUSTMENT

- 1) Run the alignment tape (Color bar) in the playback mode.
- 2) Observe surface of the audio head using a dental mirror.
- 3) Turn screw (C) clockwise or counterclockwise until the gap of lower tape edge and the lower edge of the control head is about 0.25mm. (Refer to Fig. 6-7 and 6-8)




Fig. 6-7 Location of ACE Head Adjustment Screw




Fig. 6-8 ACE Head Height Adjustment

b. ACE HEAD TILT ADJUSTMENT

- 1) Playback a blank tape and observe the position of the tape at the lower flange of tape guide.
- 2) Confirm that there is no curl or wrinkle at the lower flange of tape guide as shown in Fig. 6-9 (B).
- 3) If a curl or wrinkle of the tape occurs, slightly turn the screw (A) tilt adjust on the ACE head ass'y.
- 4) Reconfirm the ACE head height.




Fig. 6-9 Tape Guide Check

c. AUDIO AZIMUTH ADJUSTMENT

- 1) Load alignment tape (Mono scope) and playback the 7KHz signal.
- 2) Connect channel-1 scope probe to audio output.
- 3) Adjust screw (B) to achieve maximum audio level. (See Fig. 6-7)



## d. ACE HEAD POSITION (X-POINT) ADJUSTMENT

- 1) Playback the alignment tape (Color bar)
- 2) Intermittently short-circuit the two Test Points on VCR Main PCB. (See Fig. 6-2)
- 3) Press the "0, 5" remote control buttons, then adjustment is operates automatically. (See Fig. 6-1)
- 4) Connect the CH-1 probe to "Envelope" the CH-2 probe to "H'D switching pulse" and then trigger to CH-1.
- 5) Insert the (-) driver into the X-Point adjustment hole and adjust it so that envelope waveform is maximum.

<b>Test point :</b>	TP2 (Audio Output)
	TP3 (Envelope)
	TP4 (H'D S/W -Trigger)
	TP5 (Control Pulse)




Fig. 6-10 Location of Test point (VCR Main PCB-Top View)

## (2) Linearity adjustment (Guide roller S, T adjustment)

- 1) Playback the Mono Scope alignment tape (SP mode).
- 2) Observe the video envelope signal on an oscilloscope (triggered by the video switching pulse).
- 3) Make sure the video envelope waveform (at its minimum) meets the specification shown in Fig. 6-11.

If it does not, adjust as follows :

### Note :

**a**=Maximum output of the video RF envelope.

**b**=Minimum output of the video RF envelope at the entrance side.

**c**=Minimum output of the video RF envelope at the center point.

**d**=Maximum output of the video RF envelope at the exit side.

- 4) If the section A in Fig. 6-12 does not meet the specification, adjust the guide roller S up or down.
- 5) If the section B in Fig. 6-12 does not meet the specification, adjust the guide roller T up or down.




Fig. 6-11 Envelope Waveform Adjustment





Fig. 6-12 Adjustment Points

- 6) Play back the Mono Scope alignment tape (SP mode).
- 7) Connect an oscilloscope CH-1 to the "Envelope" and CH-2 to the "H'D SW Pulse" for triggering.
- 8) Turn the guide roller heads with a flat head (  ) driver to obtain a flat video RF envelope as shown in Fig. 6-13.




Fig. 6-13 Guide Roller S, T Height Adjustment

### (3) Check Transitional Operation from RPS to Play

Check transition from RPS mode to play mode : Using a pre-recorded SP tape, make sure the entry side of envelope comes to an appropriate steady state within 3 seconds (as shown in Fig. 6-14).

If the envelope waveform does not reach specified peak-to-peak amplitude within 3 seconds, adjust as follows :

- 1) Make sure there is no gap between the supply roller lower flange and the tape.  
If there is a gap, adjust the supply guide roller again.
- 2) Change operation mode from the RPS to the play mode (again) and make sure the entry side of envelope rises within 3 seconds.




Fig. 6-14 Video Envelope Rising when Operation mode Changes from RPS to Play Mode

### (4) Envelope Check

- 1) Make recordings on T-120 (E-120) and T-160 (E-180) tape.  
Make sure the playback output envelope meets the specification as shown in Fig. 6-15.
- 2) Play back a self recorded tape (recording made on the unit using with T-120 (E-120)).  
The video envelope should meet the specification as shown in Fig. 6-15.  
In SP mode, (A) should equal (B).  
If the head gap is wide, upper cylinder should be checked.




Fig. 6-15 Envelope Input and Output Level

### (5) Tape Wrinkle Check

- 1) Run the T-160 (E-180) tape in the playback, FPS, RPS and Pause modes and observe tape wrinkle at each guide.
- 2) If excessive tape wrinkle is observed, perform the following adjustments in Playback mode :
  - ◆ Tape wrinkle at the guide roller S, T section : Linearity adjustment.
  - ◆ Tape wrinkle at tape guide flange : ACE head assembly coarse adjustment.

### 6-2-3 Reel Torque

- 1) The rotation of the capstan motor causes the holder clutch ass'y to rotate through the belt pulley.
- 2) The spring wrap PLAY/REV of holder clutch ass'y drives the disk reel S, T through gear idler by rotation of gear center ass'y.
- 3) Brake is operated by slider cam at FF/REW mode.
- 4) Transportation of accurate driving force is done by gears. (Gear Center Ass'y)

**Note :** If the spec. does not meet the followings specifications, replace the holder clutch ass'y and then recheck.

<Table 6-2>

MODE	TORQUE g/cm	GAUGE
PB	$42 \pm 11$	Cassette Torquemeter
RPS	$145 \pm 30$	Cassette Torquemeter

## MEMO

---

## 7. Circuit Operating Descriptions

---

### 7-1 Power

---

#### 7-1-1 About S.M.P.S

---




Fig. 7-1

#### ◆Terms

- 1) 1st : Common power input to 1st winding.
- 2) 2nd : Circuit followings output winding of transformer.
- 3)  $f$  (Frequency) : Switching frequency ( $T$  : Switching cycle)
- 4) Duty :  $(T_{on}/T) \times 100$

#### 7-1-2 Circuit description Control

##### (a) AC Power Rectification/Smoothing Terminal

- 1) BD01 : Convert AC power to DC (Wave rectification).
  - 2) CIS01 : Smooth the voltage converted to DC.
  - 3) L1S02, C1S04, C1S05 : Noise removal at power input/output.
  - 4) R1S04 : Rush current limit resistance at the momemt of power cord insertion.
    - Without R1S04, the bridge diode might be damaged as the rush current increases.
- (b) SNUBBER Circuit : R1S02, R1S03, C1S08, C1S07, D1S05




Fig. 7-2

- 1) Prevent residual high voltage at the terminals of switch during switch off/Suppress noise. High inverted power occurs at switch off, because of the 1st winding of transformer :  $(V = -L1 \times di/dt)$ .  $L1$  : Leakage Induction  
A very high residual voltage exist on both terminals of Q1S01 because dt is a very short.
- 2) SNUBBER circuit protects Q1S01 from damage through leakage voltage suppression by RC, (Charges the leakage voltage to D1S05 and C1S08 and discharges to R1S02, R1S03).
- 3) C1S38 : For noise removal

(c) IC1S01 Vcc circuit

- 1) R1S05, R1S07, R1S08 : IC1S01 driving resistance (IC1S011 works through driving resistance at power cord in)
- 2) IS1S01 Vcc : R1S06, D1S07, C1S09
  - ① Use the output of transformer as Vcc, because the current starts to flow into transformer while IC1S01 is active
  - ② Rectify to D1S07 and smooth to C1S09.
  - ③ Use the output of transformer as IC1S01 Vcc : The loads are different before and after IC1S01 driving. (Vcc of IC1S01 decreases below OFF voltage , using only the resistance due to load increase after IC1S01 driving.)

(d) Feedback Control Circuit




Fig. 7-3



- 1) F/B terminal of IC1S01 determines output duty cycle.
- 2) C-E (Collector-Emitter) of IC1S01 and F/B potential of IC1S01 are same.

### 7-1-3 Internal Block Diagram (Internal Block Diagram of S.M.P.S. Circuit)




Fig. 7-4

## 7-2 AV Codec




Fig. 7-5

- Main system control
- A/V Encoding/Decoding
- Transcoding/rating
- IEEE 1394 link layer function
- ATAPI interface with DVD-Multi Drive
- Analog Progressive/interlaced video output

## 7-2-1 DIC1 Processor Internal Architecture Diagram




Fig. 7-6

## 7-2-2 A/V Processor (DIC1) Functional description

### 1) SPARC Processors

Two 32-bit SPARC processors, one dedicated to video processing and the other assigned general system tasks and audio processing, perform three classes of functions: system processing, audio processing, and high-level control flow and decision-making tasks for video processing. Optionally, they can also perform 2D graphics and host functions.

The DMN8602 also support multiple video inputs, windowed video ad graphics with arbitrarily relocatable and resizable windows, PIP (Picture-in-Picture), letterbox, and side-by-side display of SD sources.

### 2) Host Interface

The host communication functions include initializing the DMN-8602 device, downloading software to the local SDRAM, sending commands, monitoring status, and downloading graphics data such as OSD bitmap.

### 3) Bitstream/Storage interface

#### ◆ ATAPI Controller

ATAPI is an asynchronous, 120ns, 16-bit word interface commonly used to connect devices such as hard disks, CD/DVD ROMs, and DVD RAMs. All operations are initiated by reading/writing a set of ATAPI device registers through programmed input/output(PIO) data transfer. ATAPI has DMA commands for transferring long data. The ATAPI register address is defined by the output pins CS0, CS1, DA[2:0].

- ◆ The IEEE1394 interface can receive MPEG-2 transport stream or DV stream data contained in isochronous packets (IPs). The DMN-8602 device filters the packets by matching channel IDs. In the case of MPEG-2 transport streams, the DMN-8602 device performs descrambling on the data that is scrambled with 5C encryption. Software is responsible for transport section processing and demultiplexing.

### 4) Video Interface

#### ◆ Video Input channel

The video input channel captures ITU-R BT.656-compliant 10-bit digital YUV component video stream from Video decoder chip(TIC1)

#### ◆ Video Digital Encoder (DENC)

The NTSC/PAL digital video encoder (DENC) module converts a digital video data stream into NTSC or PAL composite or component video output.

The DMN-8602 DENC output can be in one of the following formats:

- Baseband composite NTSC (M) or PAL (B,D,G,H,I) analog video.
- Separate analog luma(Y) and chroma(C) output to support S-Video.
- Separate analog component video RGB or SMPTE YPbPr output.

### 5) Audio Interface

The serial audio input port receives uncompressed 16- to 24-bit serial digital audio data from external audio ADC(AIC9). An internally generated clock provides bit serial clocking of the data coming from external ADC. The serial audio output port sends uncompressed 16- to 24-bit serial digital audio data to external audio DAC(AIC1). An internally generated clock provides bit serial clocking of the data coming from external ADC.

### 6) Serial I/O interface

#### ◆ SPI interface

The SPI(Serial Peripheral Interface) port provides a bus for a serial interface with front panel micom(FIC1)

#### ◆ IDC interface

The IDC bus is a simple, two-wire, bidirectional communication bus. The two signals, clock and data, are common to every device connected to the bus.

In this system, IDC bus is connected to EEPROM(DIC8) and Video Decoder(TIC1)

## 7-3 SERVO (DVP Multi Drive)

---

### 1) Pick-Up

Data in the disc is processed from the optical pick-up unit (OPU). OPU includes the Elantec chip (EL6912c) which is a highly integrated laser diode driver designed to support multi-standard writable optical drives. This chip also has an IV amplifier with concurrent read and write sampling. The architecture allows reprogramming of the timers to support different media DVD or CD standards, and different speed.

### 2) A-Chip

A chip is RF processor. This module performs RF signal processing which includes RFIP, RFIN, AGC, RF equalizer. This processor is able to detect tracking error, focus error and various signals such as CE, PE, SBAD, DEFECT, BCA, MIRROR, Wobble, TZC, RC, and RECD.

### 3) C-Chip

C-Chip is composed of DP1, PRML and WS.

First, the Data processor1 (DP1) performs EFM/EFM+ Demodulation and data is stored in the buffer memory in data processor2 (DP2). DVD data in this buffer is transferred to CSS/ATAPI through error-correction code

(ECC), descramble process and error detection code (EDC).

Second, WS performs the following processes.

- ① Delay compensation using Shift register
- ② Sample/Hold pulse generation
- ③ I/V Gain Control
- ④ Providing clock for RF chip
- ⑤ OPC Control signal generation

Lastly, PRML completes the adaptive EQ/VD and Digital PLL.

### 4) D-Chip

D-Chip consists of Servo DSP, DP2 and 1Mbit memory. Servo DSP is dealing with controlling the servo-mechanism in DVD recorder. Servo-DSP has the following features.

- ① Built-in 10Bit ADC(8ch), DAC(3ch) and PWM(7ch)
- ② Step Motor Control Logic: Macro/Micro Step
- ③ Track Counter: long distance velocity control direct seek
- ④ Shock/Defect detection
- ⑤ Header (DVD-RAM)/Land Pre-Pit (DVD-R/RW) Detection
- ⑥ Several Servo Monitor Signal Detection
- ⑦ RF IC Interface
- ⑧ Micom Interface
- ⑨ Digital Servo Control of focus, tracking, sled and seek
- ⑩ Disc Auto-Detection
- ⑪ Automatic Adjustment of the offset, balance and gain of Focus and Tracking Signal
- ⑫ Direct Seek with Velocity Control
- ⑬ Step Motor Control: Macro Seek
- ⑭ De-Track and Lens Shift Detection and Compensation
- ⑮ Center Error Control
- ⑯ DVD Layer Jump
- ⑰ Tilt Detect and Compensation

DP2 performs High Speed ECC and CD DA Decoder.

## 5) ATAPI Controller

ATAPI (ATA Packet Interface) the standard interface protocol used to connect the CD/DVD Drive to IDE interface. Data from the front-end is processed to back-end through this ATAPI protocol. Sanyo chip (LC98600CT-XB0) is utilized for ATAPI interface. LC98600CT-XB0 has the following features.

- ① ECC and EDC correction/addition for CD-ROM data
- ② Subcode decoding/encoding
- ③ Spindle servo control
- ④ CLV/CAV servo control using ATIP data
- ⑤ ATIP decoding and CRC check functions
- ⑥ Providing random EFM output for PCA use
- ⑦ High-accuracy write strategy signal output enabled (CD-R 52x)
- ⑧ Buffer RAM can be accessed by the microcontroller through the LC98600CT-XB0
- ⑨ Built-in ATA-PI(IDE) interface (supports Ultra DMA modes 0,1, and 2)
- ⑩ 52x decoding speed/52x encoding speed supported with 33.8688Mhz
- ⑪ Maximum transfer speed PIO mode: 16.6 MB/s (with IORDY), Ultra-DMA: 66MB/s (with DMARQ)
- ⑫ User can freely set the CD main channel, C2 flag, and subcode areas in buffer RAM
- ⑬ Built-in batch transfer function for transferring (CD main channel, C2 flag, etc., in a single operation)
- ⑭ Built-in multi-transfer function (allows multiple blocks to be sent to the host automatically in a single operation)




Fig. 7-7

## 7-4 Video Input

### 7-4-1 Video Input Outline

D-VR3SB, D-VR3SG, D-VR3SF is the two Line Video input. Line 1 Video input is CVBS1 at the Rear Panel. Line 2 Video input is CVBS2 & S-Video2 at the Front Panel.

The analog Video signal select Line 1 or Line 2 by the IC601 (VCR Micom).

TIC1 (Video Decoder) diverges from the 14.318185MHz crystal, then generates ITU-R656 (10bits) and 27MHz clock.

TIC1 (Video Decoder) does closed caption, copy guard detect processing and A/D conversion of 11bit analog Video signal converted into Digital Video signal (ITU-R656 Format) is outputted via DIC1 (MPEG2 Decoder & Encoder with video Encoder) of digital part.




Fig. 7-8

### 7-4-2 Analog Mux (SV1274)

IC801 is Analog Mux.

As Pin 64, 63 of the IC801 is controlled by the VCR Micom, IC801 select Line1 of CVBS[Pin4] and Line2 of CVBS[Pin 6] and TIC1 select Line2 of S-Video[Pin9, Pin18].

◆The analog Video Signal of IC801 output is selected by the FIC1 via TIC1(Video Decoder : TVP5146) of analog Video input parts.

### 7-4-3 NTSC/PAL Video Decoder (TVP5146 : Video Decoder)

The TIC1 (Video Decoder : TVP5146) device is a high quality, single-chip digital video decoder that digitizes and decodes all popular baseband analog video formats into digital component video. The TIC1 (Video Decoder : TVP5146) supports the analog-to-digital (A/D) conversion of component RGB and YPbPr signals, as well as the A/D conversion and decoding of NTSC, PAL and SECAM composite and S-video into component YCbCr. This TIC1 (Video Decoder : TVP5146) includes four 10-bit 30-MSPS A/D converters. and A/D conversion of 10bit analog Video signal converted into Digital Video signal (ITU-R656 Format) is outputted via DIC1 (MPEG2 Decoder & Encoder with video Encoder) of digital part.

The following output formats supply 10-bit 4:2:2 YCbCr to the DIC1 (MPEG2 Decoder & Encoder with video Encoder) of digital part.

On CVBS and S-video inputs, the user can control video characteristics such as contrast, Brightness, saturation, and hue via an I2C DIC1 port [PIN V17, V18] interface.

The TVP5146 decoder includes methods for advanced vertical blanking interval (VBI) data retrieval. The VBI data processor (VDP) slices, parses, and performs error checking on teletext, closed caption (CC), Copy Guard Detect Processing and other VBI data.



## 7-5 Video Output

### 7-5-1 Outline

DIC1 (MPEG2 Decoder & Encoder with video Encoder) diverges from the 13.5MHz crystal, then generates VSYNC and HSYNC.

DIC1 (MPEG2 Decoder & Encoder with video Encoder) does RGB encoding, copy guard processing and D/A conversion of 10bit Video signal converted into analog signal is outputted via amplifier of analog part.




Fig. 7-9

### 7-5-2 NTSC/PAL Digital

DIC1 inputted from pin E1 with 13.5MHz generates HSYNC and VSYNC which are based on video signal. DIC1 is synchronous signals with decoded video signal.

The above signals, which are CVBS (Composite Video Burst Synchronized), Y(S\_Video), C(S\_Video), Y(Component)/G(Green), Cr(component)/R(Red), Cb(component)/B(Blue), are selectively outputted 480i (interlaced Video Output), 480P(progressive Video Output) by the Front switch.

DIC1 adopts 10bit D/A converter.

DIC1 perform video en-coding as well as copy protection.

### 7-5-3 Amplifier (VIC1: LA73054)

VIC1 is 6dB amplifier.

Based on CVBS signal, the final output level must be 2Vpp without 75ohm terminal resistance.

Because the level of video encoder output is only 1.1Vpp, the level is adjusted with the special amplifier.

When mute of pin 5 is high active, if the pin is floating and connects to power, the output signal is never outputted.

CVBS, Y, C, R, Pb(B), Pr(R) outputted from video encoder are inputted to VIC1 (Pin 2, 8, 6, 16, 14).

The signal to which gain is adjusted by amplifier is outputted from jack via 75ohm Resistance (VR11~VR16).

## 7-6 Audio

### 7-6-1 Input Block

D-VR3SB, D-VR3SG, D-VR3SF has two stereo line input terminals. and internal TV-audio from RF Tuner Block. These three Analog audio signal source are converted to digital data by Input Block. Input Block has a Multiplexer (IC801), Input Filter (AIC81, AIC82), and A/D converter (AIC9). IC203 change it's output by selection control signal from FIC1 (Front Micom). The output signal of IC801 are filtered by OP-Amp (AIC81, AIC82). AIC81 (L-ch) have two op-amp in each.

### 7-6-2 Output Block

DVD-VR300 has two stereo analog line out terminal, and two digital output terminal. Decoded signal by DIC1 is inputted to AIC1 (D/A Converter), then filtered and amplified by AIC4 (OP-Amp). And the digital audio signal (IEC-958) is driven by AIC3 inverter and ouputted in Optical/Coaxial (S/PDIF) terminal.




Fig. 7-10

## 7-7 VCR System Control




Fig. 7-11 Micom Block Diagram

### (1) Outline

The system control circuit inputs the commands given by the operator to set the mechanism and circuit to the commanded mode. The circuit also inputs the detected output from the tape and mechanism protection sensor and protects the VCR and tape against abnormal operation.

Fig. 7-11 is a simplified system control block diagram.

The system control is performed by 4 control sections. (System and timer control, Servo control, F/S Tuner, On Screen Display).




Fig. 7-12 IC601 Block Diagram

## (2) Mechanism/Circuit Control

When the u-COM inputs operator's commands via the key input or remote input, the mechanism and circuits are set to the command mode. This function controls mechanism/servo section and audio/video processing section.

### 1) Cassette Loading Control

Controls loading and ejection of a cassette and determines the mechanism operation mode; tape loading/unloading, action/release of various breaks, tension, take up mechanism etc.

### 2) Tape Protection Sensor Monitoring

Detects abnormal operation in tape using the supply and take up end sensor, reel sensor and SW 30Hz pulse for drum rotation.

### 3) Capstan Motor Control

Determines the tape speed and direction, fast forwards and rewinds the tape etc.

### 4) Tape Counter Control

Counts the control pulses on the control track, picked up by the control head and shows it on the digital multidisplay.

### 5) Servo Control

Determines the operation mode of the servo circuit. Control the speed of drum and capstan motor, and then Control the phase of drum and capstan motor.

### 6) Record Safety Tap Detection

Detects the safety tab on the rear of a cassette to prevent a prerecorded program from being erased.

### 7) Loading/Unloading control

Controls a series of loading/unloading operation after the u-COM judges the operation mode and sets the mechanism to suitable mode. Fig. 7-13 show correlation between u-COM and peripheral components during the loading/unloading operation.

The mechanism state switch (PROG. SW) detects the mechanism position. When the driving gear is turned by the loading motor, the switch driving slider traces the groove, and this switch stops at the correct position corresponding to each mode. In other words, the u-COM judges the present mechanism state from the PROG SW after receiving the mode data, then it outputs the loading motor and capstan motor control signals. This continues until the PROG SW reaches the correct state by the u-COM.




Fig. 7-13 The Relationship Between u-COM, Capstan, Cylinder and Loading Motor

### (3) Program SW Input

The mechanism state for each mode is shown in table 1 below. The mechanism state is classified into position, and correlation between the switch position and mechanism state is shown in table 1, also.

Table 1 : Prog. SW State in Each Mode

POSITION	CAM S/W			START SEN	ACTION MODE
	A	B	C		
STANBY	0	0	0	0	Eject
POWER OFF	0	0	0	1	Unload POWER OFF
LOADING START	0	0	0	1	(Tape loading start point)
LOADING END	1	0	1	1	(Tape loading end point)
REV	1	1	0	X	Reverse picture search, reverse SLOW
PLAY	0	1	0	X	Play, Rec, F-PS, Still, SLOW, F-ADV
STOP 1	0	0	1	1	Stop (Play position 5 Min. over)
STOP 2	0	0	1	X	(MAIN Break ON MODE)
FF/REW 1	1	0	0	X	High speed Rew, Low speed FF
FF/REW 2	0	1	1	X	High speed FF, Low speed Rew

### (4) Motor Control

In case of Scorpio-2 Deck, Loading Motor Drive IC lies in Capstan Motor, not like Scorpio-1 Deck.

In detail, Capstan Motor Drive IC is designed to drive Loading Motor + Capstan Motor + Cylinder Motor in one IC. (See Fig. 7-14)

Table 2 : Motor Control Logic

CN604-PIN10	MOTOR
0 ~ 1V	Reverse
2 ~ 3V	Stop
4 ~ 5V	Forward




Fig. 7-14 Loading Motor + Capstan Motor + Cylinder Motor Block Diagram



**(5) Stop Mode**

The VCR enters the stop mode when the stop button is pressed during playback, record, rewind and fast forward mode. When trouble is detected, the VCR enters the stop mode to protect the tape and mechanism or when the tape reaches the end, etc.

- State Input ;  
Power switch on position.  
Stop button operation in all mode, except for timer recording and XPR.

**(6) Play Mode**

- State input ; Play button operated in stop, fast forward, rewind, forward search, reverse search, still mode, etc.,
- Indication output ;  
“PLAY” lights in LED Module.
- Output at ;  
IC601 Pin 46 (CAP F/R) : H

**(7) Trick Play Mode**

Trick play modes are classified into forward search, reverse search, still, slow and frame advance. Audio signal is muted by pin 32 of IC601 (A.MUTE). V-lock is controlled by pin 24 of IC601.

**(8) Forward Search Mode**

7 Times play speed search in SP and SLP, 21 times play speed search in SLP.

- State input ; Press the fast forward button on the VCR front panel or the remote control in play or still mode.
- Indication output ; “FPS ” display in LED Module during 3 seconds.
- Output at ;  
IC601 Pin 46 (CAP F/R) : H  
IC601 Pin 32 (A.MUTE) : H

**(9) Reverse Search Mode**

7 times play speed reverse search in SP, 21 times play speed reverse search in SLP.

- State input ;  
Press the rewind button on the VCR front panel or on the remote control in play or still mode.
- Indication output ;  
“RPS” display in LED Module during 3 seconds.
- Output ;  
IC601 Pin 46 (CAP F/R) : L  
IC601 Pin 32 (A.MUTE) : H

**(10) Slow Mode**

- State input ; Press “▶||” button and then press “▶▶” button on the remote control.  
The slow speed can be changed when “▶▶” or “◀◀” button is pressed.
- Indication output ; “SLOW” lights in LED Module.
- Output at ;  
IC601 Pin 46 (CAP F/R) : H  
IC601 Pin 32 (A.MUTE) : H

### (11) Play/Still Mode

The same track is traced by the video heads.

- State input ; Press “▶||” button in play modes.
- Indication output ; “STILL” display in LED Module.
- Output at ;  
IC601 Pin 46 (CAP F/R) : H  
IC601 Pin 32 (A.MUTE) : H

### (12) Record Mode

Must use a cassette with the safety tab.

Index signal is recorded on the control track of the tape at the start of recording.

- State input ;  
Press the record button during stop mode and record pause mode or at the preset time reached in the timer record mode. Press the REC button in stop mode.
- Indication output ;  
“REC” lights in LED Module in normal record mode, “0:30, 1:00, 1:30, 2:00, 3:00 or 4:00” display in timer XPR modes.
- Output at ;  
IC601 Pin 46 (CAP F/R) : H

### (13) Record Pause Mode

The pinch roller is released from the capstan shaft in a moment.

The brake is applied to the take up reel to prevent tape slack during the record pause mode.

- State input ; Press “||” button in the record mode.

**Note :** Inoperative during recording and XPR mode.

- Indication output ; “PAUSE” display in LED Module.

### (14) Fast Forward Mode

Tape fast forward operation using capstan motor.

- State input ; Press the rewind button in the stop or fast forward modes.
- Indication output ; “FF” lights in LED Module.
- Output at ;  
IC601 Pin 46 (CAP F/R) : H

### (15) Rewind Mode

Tape rewind operation using the capstan motor.

- State input ; Press the rewind button in the stop or fast forward modes.
- Indication output ; “REW” lights in LED Module.
- Output at ;  
IC601 Pin 46 (CAP F/R) : L

### (16) Rewind Shut-Off Mode

Tape rewind operation then power off mode.

- State input ; Press the power button in the rewind mode.

### (17) Trouble Detection

The trouble detection circuits are provided to protect the from damage (Fig. 7-15). The reel lock sensor detects incorrect rotation of supply and take up reel. The reel lock sensor consists of the disk and photo sensor installed at the bottom of the reel disk. the disk has 6 or 8 shielder parts and the photo sensor consists of the LED and photo transistor assembly. When the light is shielded by the the shielder or enters the photo transistor, the output is obtained from the photo sensor. IC601 measures the period of the pulse. When it is 4 seconds or more during record/play, the VCR enters the reel emergency mode.

The VCR maintains the unload-power-on state in the reel emergency.




Fig. 7-15 Reel and Cylinder Lock T.END/S.END Sensor

### (18) Cylinder Lock Sensor

If the frequency of D-FG is less than 230Hz or more than 430Hz during 500msec, and such situation occurs 3 times continued, micom makes the VCR drum emergency.

### (19) Tape End Sensor

When end sensor detects the transparent section at the end of tape, the VCR enters auto rewind mode, except during timer recording and OTR mode. The cassette LED emits light through the transparent section of tape to the photo transistors, which are installed at both ends of the cassette. When start sensor detects the start section of the tape during reverse search and rewind, the VCR automatically goes to stop mode.

## (20) Tape Counter Control

Fig. 7-16 is a simplified diagram of the tape counter control circuit. The tape counter in the u-COM counts the control pulses derived from control head. The control signal on the control track of the tape is picked up by the control head and supplied to pins 74, 75 of IC601. The control pulse is amplified by the u-COM IC. The u-COM determines the tape direction so the counter counts up when the “CAP F/R” signal is Hi and the counter counts down when the “CAP F/R” signal is Low. By counting the control pulse, the counter data is supplied to the VF display. Counter displays the time and it is increased or decreased by one minute after counting 1800 control pulses. Counter mode is switched to clock mode when the display button is pushed or when the VCR goes to power off mode. When the Clear button is pressed, the counter is reset to “00 : 00”. The tape counter has a memory stop function.




Fig. 7-16 Counter Display

**(21) Timer/OTR Control**

The timer can preset 12 programs in one month including daily and weekly programs. Express recording lets the operator record up to 4 hours without programming the timer.

**(22) Clock Display**

The clock generator inside of the u-COM counts the oscillation signal of XT601 for the timer clock data.

**(23) Power Failure Detection**

u-COM goes to the power failure mode when the 88 port is lower than 4/5 of AD Vcc level.

**(24) 4H'D Control**

During trick play (still,slow,F-advance), it is necessary to control pre-amp,video circuit. the micom control pin 98 (C-ROTARY), pin 99 (HD-AMP) of the IC601 during PB period in Slow mode. These port is applied to video IC to operate the trick play.

## 7-8 VCR Servo

### (1) Outline

The servo system is divided into three loops. The cylinder servo controls the rotation of video heads, the capstan servo controls the tape speed, and the tension. In addition it's necessary to control cylinder motor, especially during trick play in 4H'D models. The tension servo maintains the tape tension constant: it keeps the compression strength of tape against the video heads at the optimum level so that a stable RF signal is produced during recording and playback. The tension servo operation is entirely mechanical. The cylinder servo loop controls the phase and speed of the cylinder motor. The speed is kept at a constant 1800 RPM and the phase determines the mechanical position relative to the vertical Sync signal. The capstan servo loop controls the phase and speed of the capstan motor so that the video head can trace the video track correctly. It keeps tape speed constant according to the mode (SP, SLP) during playback and recording.

Table 3 : Servo System Signal

MOTOR	SYSTEM	MODE	REFERENCE SIGNAL	COMPARISON SIGNAL
CYLINDER (VIDEO HEAD) (4H' D)	PHASE	REC	V-SYNC	SW 30Hz
		PB	REF30Hz	
	SPEED	COMMON	8MHz	CYLINDER FG(720Hz)
	SPEED& PHASE	TRICK PLAY (STILL. SLOW)	MICOM CONTROL CYLINDER SPEED TO MATCH H-SYNC SPEED	
CAPSTAN (4H' D)	PHASE	REC	DIVIDED CFG PULSE	REF 30Hz
		PB	CTL 30Hz	
	SPEED	COMMON	8MHz	CAPSTAN FG
	SPEED& PHASE	TRICK PLAY (STILL. SLOW)	MICOM CONTROL CAPSTAN DRIVE SIGNAL WITH CAP C.L	




Fig. 7-17 Block Diagram

## (2) Capstain Speed Error Detector

The capstan speed control operates so as to hold the capstan at a constant rotational speed, by measuring the period of the CFG signal. A digital counter detects the speed deviation from a preset value. The speed error data is added to phase error data in a digital filter. This filter controls a pulse-width modulate (PWM) output, which controls the rotational speed and phase the capstan.

When the error is zero, the PWM circuit outputs a waveform with a 50% duty cycle.

The CFG input signal from the capstan motor is a square wave the CFG input signal is compared by a comparator and then sent to speed error detector as the CFG signal.

The speed error detector uses the system clock to measure the period of the CFG signal, and detects the deviation from a preset data value. The preset data is the value that would result from measuring the CFG signal period with the clock signal if the capstan motor were running at the correct speed.

The error detector operates by latching a counter value when it detects an edge of the CFG signal.

The latched counter provides 16 bits of speed error data for the digital filter to operate on.

The digital filter adds the speed error data to phase error data from the capstan phase control system, then sends the result to the pulse-width modulator as capstan error data.

## (3) Capstain Phase Error Detector

The capstan phase error detector consists of a 16-bit counter, a capstan phase preset data register pair, a latch signal circuit driven by a feedback signal, and a capstan phase error data register pair.

The capstan phase control in rec mode is executed by comparing HD S/W, which is synchronized with V-sync, with divided CFG signal. And then it does in playback mode by comparing HD S/W, which is synchronized with DFG and DPG, with PB CTL signal.

The latch signal for the phase error data in record mode is the divided CFG signal, which is divided from the CFG signal in the CFG frequency divider to a frequency of 30HZ.

In playback, the latch signal is the divided CFG signal obtained by frequency division from the rising edge of PB-CTL signal (playback control pulse signal).

The error data is a signed binary value centered on a phase error of zero (corresponding to the correct rotational phase). If the phase lags the correct phase, the error is positive (+).

If the phase leads the correct phase, the error is negative (-).

## (4) Drum Speed Error Detector

Drum speed control operates so as to hold the drum at a constant rotational speed, by measuring the period of the DFG signal. A digital counter detects the speed deviation from a preset value. The speed error data is added to phase error data in a digital filter. The filter controls a pulsewidth modulated (PWM) output, which controls the rotational speed and phase of the drum.

The DFG input signal from the drum motor is a square wave. The DFG input signal is compared by a comparator and then sent to the speed error detector as the DFG signal.

The speed error detector uses the system clock to measure the period of the DFG signal, and detects the deviation from a preset data value. The preset data is the value that would result from measuring the DFG signal period with the clock signal if the drum motor were running at the correct speed.

The error detector operates by latching a counter value when it detects an edge of the DFG signal. The latched count provides 16 bits of speed error data for the digital to operate on.

The digital filter adds the speed error data to phase error data from the drum phase control system, then sends the result to the pulse-width modulator as drum error data.



### (5) Drum Phase Error Detector


Drum phase control must start operating after the drum motor is brought to the correct rotational speed by the speed control system. Drum speed control works as follows in record and playback.

- Record : Phase is controlled so that the vertical blanking intervals of the recorded video signal will line up along the edge of the tape.
- Playback : Phase is controlled so as to trace the recorded tracks accurately.

A digital counter detects the phase deviation from a preset value. The phase error data is added to speed error data in a digital filter. This filter controls a pulse-width modulated (PWM) output, which controls the rotation phase and speed of the drum. When the error is zero, the PWM circuit outputs a waveform with a 50% duty cycle.

The phase counter error detector compares the phase of the DPG pulse (tach pulse), which contains video head phase information, with a reference signal. In the actual circuit, the comparison is carried out by comparing the head-switching (HSW) signal, which is delayed by a counter that is reset by DPG, with a reference signal. The reference signal is the REF 30Hz signal, which differs between record and playback as follows.

- Record : V sync signal extracted from the video signal to be recorded (frame rate signal, actually 1/2V sync).
- Playback : 30Hz signal divided from the system clock.



## 2) Main Emphasis Circuit

The dynamically emphasized luminance signal is now supplied to the main emphasis circuit where all the high frequency components of the signal are boosted more than the low frequency components. The boosting action is required for the high frequency components because in the FM recording method, the noise of the playback signal increases in proportion to the modulated signal frequency or low level signal. By using the nonlinear emphasis and main emphasis system, the total S/N ratio is increased. The output of the main emphasis circuit is then supplied to the white and dark clip circuit.

## 3) White and Dark Clip Circuit

After emphasis is performed, large overshoots and undershoots in the luminance signal are limited to a specified level. This is done to avoid FM over modulation. The output of the main emphasis circuit is then supplied to the FM modulator circuit.

## 4) FM Modulator

A. The amplitude of the FM signal is limited, so the signal is recorded on tape near the maximum record level which increases the S/N ratio.

B. The FM carrier is set to 3.4MHz (at the Sync tips) and the deviation to 4.4MHz by inside IC circuit (for the white peak). The actual device which constitutes the FM modulator is a stable multivibrator.

This multivibrator generates a sine wave output of variable frequency.

The frequency of sine wave is governed by the level of the processed video signal at any given point. Therefore, the processed video signal varies the frequency of the sine wave which is frequency modulation (FM). During playback in SLP mode, the crosstalk of the adjacent track is more apparent than in standard mode. It appears as jitter and noise on the monitor. To reduce this noise from the screen, the FM carrier frequency has to be  $1/2f_h$  shifted up during recording. This is done by applying the head switching pulse to the FM modulator control pin 57 during SLP recording. The FM modulated luminance signal goes to record equalizer circuit and it is mixed with chrominance signal at the record Amp circuit inside video IC.

## 5) Record Amp

The frequency modulated luminance signal and chroma signal are mixed in the record amp of pre-amp block inside video IC. Then this mixed signal is amplified and supplied to the video heads via the rotary transformer and recorded on the magnetic tape.

Tape speed selection determines which video heads will be used. That is, signal output from pin 66 (SLP) and 73 (SP) of pre-amp block are supplied to video heads.

Control signal of speed mode is applied to pin 53(clock), 54(data), 55(chip select) of video IC from Micom IC.

## (2) Luminance Signal Playback System




Fig. 7-19 Luminance Playback Process

### 1) Outline

The video signal recorded on the tape is picked up by CH1, CH2 head and is supplied to pre-amp block via rotary trans. During playback, as per the speed, SP and SLP head is determined by Pin60 of respectively. CH1 signal inputs to Pins 65 and 74 while CH2 signal inputs to Pins 67 and 72 of video IC. The pick up operation is controlled by the head switching pulse inputted to pin 57. During the high portion of the switching pulse, CH2 is picked-up and just the opposite is true for CH1. In the pre amp IC, the FM signal is amplified 60dB and this signal is applied to FM AGC.

### 2) FM AGC AMP

At the FM AGC Amp (FM), signals are automatically balanced. One of the AGC circuit outputs is fed to AGC detector circuit which detects signal level fluctuations. The detector output signal is applied to the FM AGC Amp to keep the output constant. This output is applied to the PB FM EQ block. FM EQ is correct the phase distortion and level. The signal through PB EQ circuit is applied to the double limiter.

### 3) Double Limiter Circuit

A FM signal on the tape which contains AM components will be read during playback. If there is a severe AM component, a drastic drop in FM carrier can occur. This lack of FM carrier can be called a noise region. Double limiting is used for improving the S/N ratio and carrier loss. The playback FM signal is split into two paths, one goes to high pass filler and sub-limiter. The other goes to the main-limiter after passing through a LPF. ONE path of the FM signal goes to the high pass filter, so that the low frequency(AM) component can be removed, and the other carrier is supplied to the sub-limiter. The output signal of sub-limiter is mixed with the signal from the low-pass filter and sent to the FM demodulation circuit.

#### **4) FM DEMODULATOR**

The FM demodulator consists of a stable mono multivibrator balanced modulator (BM) and a LPF. The FM demodulator circuit first converts the FM signal to a pulse width modulator signal. Then the circuit smoothes the PWM signal to demodulate the video signal. This demodulated signal is fed to the LPF to remove its FM carrier component and any other harmonics. The demodulated luminance signal outputs from Pin 21 and is applied to the 3MHz LPF through main deemphasis circuit. To reduce demodulation noise, the output of the 3MHz LPF is applied to a non-linear deemphasis circuit through YNR circuit.

#### **5) Main De-emphasis Circuit**

Before modulation, main emphasis was performed. Because the high frequency components of video signal were boosted more than the low frequency components in the recording mode, main deemphasis must be performed to obtain a normal video signal. That is this circuit returns the emphasized high frequency component to the original value.

#### **6) Non Linear De-Emphasis Circuit**

This circuit is the counter part of the dynamic pre-emphasis circuit during recording. The characteristics are also the opposite of those in recording.

#### **7) Drop Out Compensator/YNR Circuit**

This circuit compensated for missing parts of the FM signal due to dust, dirt on the tape or irregular tape coating, etc. The clamped video signal is supplied to the CCD 1H circuit. The 1H delayed video signal from CCD block is also supplied to the 6MHz LPF to reject the sampling noise of CCD IC.

Then, the output of LPF is applied to Pin 34 of video IC. When the DOC detector detects the FM loss, a 1H delayed video signal is added in place of the missing signal.

#### **8) Noise Canceller Circuit**

The noise canceller circuit removes the high frequency noise contained in the video signal which has the reverse characteristics of the detail enhance in the recording mode. The output of the noise canceller circuit is supplied to the Luminance and Chrominance mixer circuit. The mixed chroma and luminance signal are then output at Pin 26.

### (3) Chroma Signal Recording System




Fig. 7-20 Chrominance Record Process

#### 1) Outline

Fig. 7-20 shows the chroma signal recording system. The chroma signal recording process is performed by video IC. The input video signal is fed to Pin 28 of IC and supplied to Y/C COMB circuit through AGC AMP. The output signal of Y/C COMB circuit is applied to ACC amplifier. The ACC amplifier is used for both burst ACC which keeps the burst level at a constant value in recording and the color ACC which controls the reference level of the burst ACC with the color signal level. The color ACC works to maintain a relatively high output level by boosting low level input signals to improve color S/N ratio. The signal is then applied to the burst emphasis circuit. Burst emphasis emphasizes the burst signal by +6dB during recording and feeds it to the main converter. The 3.58MHz signal are mixed in the main converter to perform frequency conversion. The main converter is a mixer having the two types of output components which are the added frequency of  $4.21+3.58=7.8\text{MHz}$  and the difference frequency component 629KHz. Added frequency is rejected by the 1MHz LPF and the 629KHz down converted chroma signal is supplied to the luma/chroma mixer of pre-amp block and then recorded on the tape via the record amp and heads. AFC detection is performed with the head switching pulse and the fh signal generated from 321fh VOC output. The detector output controls the VCO frequency which will be locked precisely at 320fh (5.035MHz). The 320fh signal is counted down to 1/8 and the resultant 40fh (=629KHz) carrier signal is phase shifted triggered by each horizontal sync signal which is wave shaped as a 50% duty pulse by the pulse generator. The direction of the rotational phase shift depends on the levels of the rotary head switching signal from pin 57 and when the switching signal is "H" level, the phase is retarded by 90 degrees for every 1H, and when it is at a "L" level it will advance by 90° for every 1H this 40fh phase shifted sub-carrier (PSSC) signal enters the sub-converter and the 3.58MHz carrier signal is locked at the color burst frequency by the record APC. The PSSC signal is frequency converted into  $3.58\text{MHz} \pm 629\text{KHz}$ . Then 4.21MHz component ( $=3.58\text{MHz} \pm 629\text{KHz}$ ) is extracted through a 4.2MHz BPF. The 4.21MHz signal is used as a carrier signal for down conversion of the color signal as described previously.

## 2) ACC (Automatic Color Gain Control) Circuit

The ACC is used as burst ACC in the LP mode, however it is also used for peak ACC in the SP/SLP mode. The purpose of using two different ACC operations is to improve the overall Chroma S/N ratio during playback. In SP and SLP, there is H-sync alignment. This indicates that there is burst alignment as well. Whenever two video tracks overlap or a video head picks up crosstalk from an adjacent track, beats are produced during playback. Perhaps the most noticeable beats are produced by H-sync and burst. But in SP and SLP, these beats occur right at H-sync and burst and are out of the picture. In LP, however, there is no H-sync alignment and these beats can be seen in the picture. To keep the beats at a minimum in LP, we keep the burst level constant so that the beat intensity is constant. We know that ACC acts to improve the color S/N, and in LP, the ACC detector locks at the burst level, and keeps it constant. Thus we have ACC operation with the least beats. In SP and SLP, the beats caused by burst overlap are out of picture, so we don't really mind if the burst level changes or not. To improve the color S/N ratio even more, we use peak ACC in SP and SLP. That is, if the chroma level is too low to record, the amplification degree is increased by 3dB. However, the chroma level is sufficient for recording, this peak ACC is changed to burst ACC to avoid over amplification. By changing the ACC according to picture color content, the burst level may vary. The color ratio improvement is based on the color content itself during SP and SLP provides a somewhat better S/N ratio.

## 3) Four (4) Phase Rotation

CH1 is advanced  $90^\circ$  every channel, while CH2 is delayed  $90^\circ$ . When the frequency is set to 629KHz, if phase is shifted by  $\pm 90$  it becomes 629KHz  $\pm 90$ . The  $40f_h \pm 90$  ( $=629\text{KHz} \pm 90$ ) is balanced modulated via fsc (3.58MHz) depending on which side band is detected. That is, the  $f_s + 40f_h \pm 90$  (4.2MHz  $\pm 90$ ) of total frequency is supplied to the main converter. In record mode, the signal operates same as in play back mode. During playback, the phase is returned to original state.

## 4) AFC (Automatic Frequency Control) Circuit

Luminance signal is input to H-sync separator. The H-sync is separated and supplied to phase comparator. This signal can be described as  $f_h$  (Horizontal Sync frequency of input video signal). However, VCO oscillates at  $320f_h$  (5.035MHz). This  $321f_h$  is counted down by  $1/8$  and  $1/40$  and resultant  $f_h$  is supplied to phase comparator.  $f_h$  and  $f_h$  are supplied to the phase comparator for comparison of their phases.

After comparison, the phase differences is output to VCO ( $320f_h$ ) in terms of error voltage. Therefore, the oscillation frequency of VCO is controlled by this error voltage. That is, if the  $f_h$  phase is changed by H-sync signal  $f_h$ , error voltage is changed accordingly and if the phases of  $f_h$  and  $f_h$  are met due to change of VCO oscillation frequency, error voltage does not feedback.  $320f_h$  VCO is oscillated in accordance with phase sync at  $f_h$ . Therefore,  $40f_h$  input to sub converter by phase shift is always sync horized with phase.

The AFC loop performs the same operation during record and playback. In recording, phase of VCO is in accordance with H-sync signal of current video signal.

Which in playback, the phase sync of VCO is consistent with H-sync signal which is separated from the video signal.

#### (4) Chroma Signal Playback System




Fig. 7-21 Chrominance Playback Process

##### 1) Outline

Fig. 7-21 shows the chroma signal playback system.

The FM signals picked up by the CH-1 and CH-2 video heads are supplied to the pre-amp block.

The FM signal from CH-1 and CH-2 are alternately selected by the switch and output signal as a continuous signal. Goes to the ACC amp through the 1.3MHz LPF. The 1.3MHz LPF is used for passing only down converted 629KHz chroma signal in the playback mode. The ACC amp stabilizes the 629KHz color signal level.

The output color signal from amp then enters the main converter circuit. In the main converter circuit this signal is mixed with the 4.21MHz phase shifted carrier signal and converted into 4.21MHz + 629KHz signals.

##### 2) Main Converter

Inside of IC, the main converter converts the 629KHz rotational chroma signal to a 3.58MHz non-rotational signal. The two inputs of this main converter are the 629KHz signal, which comes from the output of the ACC, and a 4.21MHz which has the same rotational phase as the 629KHz signal. It is important that the rotational phase of the 4.21MHz signal is the same direction as the 629KHz playback chroma signal. To obtain the 3.58MHz non-rotational stable signal, the same direction rotational signal should be mixed with the rotational chroma signal.

During the conversion process, the phase is also mixed by the frequency. Therefore, when 629KHz is subtracted from 4.21MHz, the result is the non-rotational 3.58MHz stable signal. The output signal of the main converter goes to the 3.58MHz BPF. In the 3.58MHz BPF, the conversion noise ( $4.21\text{MHz} + 629\text{KHz} = 4.8\text{MHz}$ ) is rejected and the 3.58MHz color signal goes to the comb filter.

In the comb filter, the crosstalk components due to the adjacent track are eliminated and the color signal is applied to PB-AMP, BURST De-Emphasis, Killer and are applied to LUMA and CHROMA mixer input through the CNC block.






Fig. 7-22 Block Diagram of Color REC mode by the method of a Down Converter




Fig. 7-23 Block Diagram of Color PB mode by the method of a Down Converter

## 7-10 Hi-Fi Audio

### (1) Outline

Hi-Fi circuit consists of HiFi audio LPF,VCO,BPF,FM detect circuit and switching noise compensator, PRE-AMP etc. Linear audio consists of an ALC circuit,REC EQ circuit and a PB EQ circuit.

Hi-Fi and Linear audio share the same input selector,output selector and mute circuit.

#### 1) REC Mode (L-CH Only)




Fig. 7-24 REC Mode (L-CH Only)

#### 2) PB Mode (L-CH Only)




Fig. 7-25 PB Mode (L-CH Only)

## (2) Block Description

### 1) Input Selector

Input selector outputs 1 signal from 4 different signals received. It outputs 1 selected signal from tuner, rear, front.

### 2) Normal(Linear) Selector

Two signals, L-CH and R-CH are inputted to Hi-Fi IC. But, linear audio is capable of receiving only one signal. Therefore, the 2 input signals must be selected. Usually, the outputs are mixed signals of L-CH and R-CH unlike the input selector, the normal selector does not amplify the selected signal.

### 3) Output Selector

It selects to output Hi-Fi L-CH, Hi-Fi R-CH, LINEAR and MIX(Hi-Fi+LINEAR) signals with the final output IC pin 78 (R-CH) and pin 80 (L-CH).

### 4) Output ALC(Convertor)

ALC is used because when the input level of RF converter gets bigger, it shows up as noise on the screen. But, this block is not used in this model (ALC OFF).

### 5) PNR(Peak Noise Reduction)

It is a type of emphasis, de-emphasis function to eliminate noise during modulation / demodulation. PNR operates as that of VHS FORMAT to reduce noise.

### 6) Audio Limiter

Before modulating the signals from PNR block, it limits signals exceeding the size limit to a maximum deviation of  $\pm 150$  KHz.

### 7) VCO(Voltage Control Oscillation)

It is a modulation function that oscillates 1.3 MHz (L-CH) and 1.7 MHz (R-CH).

### 8) RF LPF

It is a function to eliminate the harmonic components of Hi-Fi carrier formed during VCO, which may affect other blocks. Its pass-band is approximately 2 MHz.

### 9) MIXER

It mixes the Hi-Fi carrier formed in L-CH and R-CH. However, due to the frequency difference between L-CH and R-CH, when an equal amount of R-CH is recorded to tape, R-CH is much smaller than L-CH. Therefore, the R-CH output is approximately 10 dB bigger than L-CH.

### 10) Current Amp

It is the final amplifier of the mixed Hi-Fi carrier. IC pin 28's resistance controls current, which changes the size of IC pin 26.

### 11) AGC(Auto Gain Control)

It maintains uniform size of Hi-Fi envelope, which is inputted by pre-amp in play back mode.

### 12) BPF(Band Pass Filter)

L-CH and R-CH each has BPF. The center frequency is same as carrier frequency. It is used to receive only Hi-Fi carrier from all signals inputted to pre-amp.

### **13) SW Noise Compensation**

Unlike the linear audio, instead of using fixed head, drum heads are used, which creates halting points. However, in order for the audio to be headed continuously, the damages from halting points are modulated, which creates noise. SW noise compensation is a block to minimize this particular noise.

### **14) Hold Pulse**

It makes standard signal(Pulse) to compensate SW noise.

### **15) DET(Hi-Fi/LINEAR)**

From the Hi-Fi envelope inputted from pre-amp, it decides whether the signal passing through L-CH BPF is Hi-Fi or LINEAR tape it's size(the signal passing through BPF is below 10mVpp, it is not Hi-Fi, therefore, it output linear)

### **16) DOC(Drop Out Compensation)**

If demodulation is conducted without properly treating the damage on Hi-Fi envelope caused by scratch on the tape, noise occurs. In order to improve this noise occurrence, DO DET compensates the drop-out using the same method of compensating the switching noise when the damage on the envelope ranges 10~15mVpp.

### **17) ENV DET**

To obtain optimal tracking, envelope must be peak to peak and micom should be in DC. It is a function to convert Hi-Fi envelope to DC. If it is lower than 0.8V at micom, it sends linear mode data to HiFi IC.


### **18) Serial Data Decoder**

It receives IIC BUS to enable the operation of inner block and decodes into serial data.

**(3) Pin Port Description (Tuner Mode ; 1KHz, 100% Modulation Input)**

PIN NO.	PIN NAME	DC VOLT.	SIGNAL	REMARK
1	LINE MUTE	0 / 5	-	Reduce the line out noise.
2	Linear out to TM	4.2 V	-17 dbm	Converter Model Only
3	Vcc 9V	9 V		Power Supply for in/out Select
4	Linear Input	2.5 V	- 28.2 dBV	Audio from A/V IC
5	Vcc 5V	5 V		Power Supply for in/out Select
6	Linear out to A/V	2.5 V	-21.5 dBV	Audio out to A/V IC
7	EXT1-INPUT (L)	0	-28.2 dBV	Line Input 1 ( FRONT )
8	ALC Detector	-		ALC Detector for RF converter
9	EXT2-INPUT (L)	0	-28.2 dBV	Line Input 2 ( REAR )
10	GND	-		
11	EXT3-INPUT (L)	0	-28.2 dBV	Line Input 3 ( DVD )
12	Monitor Input (L)	2.5 V		DVD Audio (L) Input
13	Input changeover switch output (L)	2.2 V	-21 dBV	PB/REC sitch output . Transform R/P signals into DC.
14	ALC Input (L)	2.5 V	-21 dBV	ALC Input Terminal
15	Vcc 5V	5 V		Power Supply for in/out Select
16	1/2 Vcc	2.5 V		1/2 Vcc Terminal
17	Rec Mute Terminal	0 V		GND ( Not in use )
18	NR Waiting Det	-	-	Terminal for waiting detector
19	NR Waiting Filter	2.5 V		NR Waiting Filter 1 For L-CH
20	NR Waiting Filter	2.5 V		NR Waiting Filter 2 For L-CH
21	CCA Reference			CCA Reference for L-CH
22	NR Empha			NR Emphasis for L-CH
23	Tracking DC out	0 ~ 5 v		Hi-Fi Env Det Level Output
24	Audio Pb FM1	2 V / 4 V		Audio Playbak FM 1 input ( H )
25	GND			Hi-Fi PRE-AMP GND
26	REC Current OUT			Rec current out to Head
27	Audio Pb FM2	2 V / 4 V		Audio Playbak FM 2 input ( L )
28	Current adjust	2.4 V		Rec Current adjust point
29	Alc detector			ALC detection
30	Hi-Fi detector			Hi-Fi/ Normal detect
31	Monitor	2.5 V		FM Monitor
32	Vcc 5V	5 V		Power Supply for Hi-Fi
33	Pb FM Out	2.5 V		Output of H'D Amp in PB Mode
34	Pb FM Input	-	350 mVp-p	Input of FM in PB Mode
35	GND			GND FOR LOGIC
36	Vcc 5V	5 V		Power Supply for LOGIC
37	Serial data input	0 / 5 V		
38	Serial clock input	0 / 5 V		
39	Audio head s/w	0 / 5 V		Head s/w 30 hz input
40	Mts Mode out			1V : mo / 2V : St / 3V : Bi

PIN NO.	PIN NAME	DC VOLT.	SIGNAL	REMARK
41	CCA Reference			CCA Reference for R-CH
42	NR Empha			NR Empahasis for R-CH
43	NR Waiting Filter	2.5 V		NR Waiting Filter 2 For R-CH
44	NR Waiting Filter	2.5 V		NR Waiting Filter 1 For R-CH
45	NR Waiting Det	-	-	Terminal for waiting dector
46	Vcc 5V	5 V		Power Supply for in/out Select
47	ALC Input (R)	2.5 V	-21 dBV	ALC Input Terminal
48	Input changeover switch output (R)	2.2 V	-21 dBV	PB/REC sitch output . Transform R/P signals into DC.
49	Mute Control			
50	GND			GND FOR ANALOGE
51	FSC IN		200 mVp-p	3.58 Mhz input
52	DC Reg	1.2 V		Bandgap Power supply for MTS
53	Stereo PLL filter	3.8 V		LPF for Stereo PLL
54	Vcc 5V	5 V		Power Supply for MTS Select
55	Pilot Canceller f	3.8 V		CTL Pin of cancel signal for pilot C.
56	FM Filter			Filter for making stable dc
57	SIF Input			SIF Audio input from TM Block
58	REG Filter	4.5 V		Filter of reference voltage source.
59	Filter Auto Adjust	3.8 V		Loof filterof PLL for auto adj
60	Pilot Det Filter	3.8 V		Detection for pilot detection circuit
61	PC_DC_MO	3.3 V		Absorbing the DC offset
62	PCDOUT	3.8 V		Absorbing the DC offset
63	PCDIN	3.8 V		Absorbing the DC offset
64	PCDBXIN	2.6 V		Absorbing the DC offset
65	Main V/I convert	3.8 V		Converting the voltage of signal
66	SPE Det V/I convert	3.8 V		Connecting pin of smooth capacity of detection circuit.
67	Spectral DET			Converting the voltage of signal
68	Wide Band Det			Connecting pin of smooth capacity of detection circuit.
69	EXT1-INPUT (R)	0	-28.2 dBV	Line Input 1 ( FRONT )
70	GND			GND FOR MTS
71	EXT2-INPUT (R)	0	-28.2 dBV	Line Input 2 ( REAR )
72	Wid det V/I convert	3.8 V		Converting the voltage of signal
73	EXT3-INPUT (R)	0	-28.2 dBV	Line Input 3 ( DVD )
74	Monitor Input (R)	2.5 V		DVD Audio (R) Input
75	PCDCOSPE			Absorbing the DC offset
76	PC_OUT_DBX	3.3 V		Absorbing the DC offset
77	LINE MUTE ( R )	0 / 5	-	Reduce the line out noise.
78	Line out (R-CH)			
79	GND			GND FOR AUDIO
80	Line out (L-CH)			



## 5) PB AMP




Fig. 7-27 PB Amp

The diagram to the left is the playback amp and the gain input/output are as follows.

$$A_v = 1 + \frac{Z_1}{Z_2} \approx \frac{Z_1}{Z_2}$$

The playback characteristic of VHS format can be satisfied by using  $Z_1$ ,  $Z_2$  in the above equation.

PB amp gain should be designed to be approximately 45dB (1KHz).

## 6) REC AMP




Fig. 7-28 REC Amp

The diagram to the left is REC AMP. The amp gain is approximately 14dB.

$R_1$  and  $R_2$  that determine the gain is located inside the IC.

It is uniform and independent to frequency. Frequency characteristics should be considered when designing rec amp. The REC amp should be the opposite to playback characteristics.

## 7) OSC (Oscillation)

Oscillation frequency is 70KHz. It's size is approximately 45Vp-p. it operates on recoed mode. It is supplied to audio erase head and full erase head used to erase already recorded signals.

Also, it conducts "AM (Amplitude Modulation)" using oscillation signals.

## 8) BIAS Control

Oscillation coil is used in oscillation Bias. Coil output changes according to the impedance of F/E, A/E and R/P head connected to the coil.

## 9) 60KHz HPF

There must be standard signal for bias control and that signal uses HPF only to obtain oscillation signal that comes through R/P head.

## 10) S/W

The switch opens when recording, shorts during playback and exterior transistor is used.



**(3) Pin Port Description (IC301 ; LA71207M)**

PIN NO.	PIN NAME	DC VOLT.	SIGNAL	REMARK
9	REC OUT	2.3	-2dBm	REC AMP OUTPUT (GAIN ; 14dB)
75	GND	0	-	
6	BIAS	REC:2.3 PB:0	70KHz+1KHz MIX 3Vp-p	It is grounded due to the switch inside of IC during playback. During recording, it operates on 60KHz input HPF
11	BIAS CTL	REC:4.3V PB:5V	-	The BIAS CTL voltage change depends on the external TR.
6	PB EQ (+)	2.3	-	PB EQ AMP INPUT (+)
5	PB EQ (-)	2.3	-	PB EQ AMP INPUT (-)
7	PB EQ SW	2.3	-	PB EQ AMP SLP SW
3	PB EQ OUT	2.3	-32dBm	PB EQ AMP OUTPUT
2	LINE PB IN	2.3	-32dBm	LINE AMP INPUT (PB)
58	A.MUTE	0	-	Operates at HIGH (5V)
76	INPUT 1	2.3	-27dBm	AUDIO INPUT : -27dBm
78	INPUT 2	2.3	-27dBm	AUDIO INPUT : -27dBm
1	Vref Filter	2.3	-	
80	Input 3	2.3	-27dBm	AUDIO INPUT : -27dBm
77	Vcc	5.0	-	
10	Line Out	2.3	-4dBm	AUDIO OUTPUT : -4dBm
79	ALC IN	2.3	-13dBm	ALC level selector

## 7-12 TM

### (1) Outline

RF and frequency synthesized tuning system

General description : The receiving circuit consists of both ANT input and output circuits, channel selection circuit, PIF circuit and SIF circuit. The receiving circuit selects a desired broadcast signal from TV signals induced on an antenna and sends stable video and audio signals to their respective processing circuits.

### (2) Tuner modulator block

As explained, this model is designed in one package to contain a RF MODULATOR BLOCK, TUNER BLOCK AND IF DEMODULATOR BLOCK. Its size is greatly reduced and other noise interference can be minimized to make performance high.




Fig. 7-29 Tuner/demodulator Block Diagram

### (3) Tuner Block

#### A. Low pass filter & high pass filter

This consists of IF trap circuit and UHF & VHF separation circuit. If the input signal is IF(45.75MHz), this filter prevents interference.

#### B. Single tune & RF AMP

This consists of a filter circuit, RF AMP, impedance conversion circuit, image trap and a single tuning circuit. It prevents noise and other interference signals. RF AMP is controlled by AGC come from IF DEMOD block.

#### C. Double tune

It consists of a double tuning circuit to improve rejection characteristic which results in a better band characteristic.

#### D. MOP IC (Mixer, OSC, PLL)

It consists a VHS and UHF OSC and mixer circuit. We applied a double balance mixer to have better rejection characteristic, it shows especially various beat characteristic.

It selects channels and contains charge pump band driver. The minimum step standard frequency 31.25KHZ.




Fig. 7-30 Tuner Section Block Diagram

#### (4) IF Block

##### A. SAW FILTER

It passes only needed band of the signal that is converted to IF frequency and decrease other band to minimize the effect of adjacent channel.

##### B. IF AMP

IF signal, which is selected in SAW FILTER, is amplified in IF amp frequency enough to be detected. The IF AMP has parallel inputs & outputs structure and consists of 3 series step AMP. Each step has about 20dB gains. These gains are controlled by AGC voltage has maximum 63dB attenuation range.

##### C. RF AGC CONTROL

It is adjusted to determine RF AGC working point in tuner.

##### D. FM DETECTOR

After removing AM signal in the limiter AMP, amplified SIF signal is applied FM detector. This FM detector is PLL detecting type.

##### E. AFT DETECTOR

AFT automatically controls the OSC frequency in the tuner, so that it retains a constant level.

It is a quadrature detection type. The carrier, which is detected from video det is directly input to AFT detector. The 90 degree delayed phase signal is input at the same time to AFT detector and, the results come out. Detected AFT voltage is amplified by DC AMP and then applied to pin 13.




Fig. 7-31 IF Ssection Block Diagram

**7-13 OSD**

The on screen display circuit consist of a character generator decoder, video mixer, sync separator and sync generator, sync detector circuit.

The data is decoded and generates characters in syncro with composite video signal applied pin 49, 50.

Also the sync detector circuit discriminates the presence of a video signal by detecting sync, if no sync is detected, a blue screen is displayed. In other word, the OSD circuit displays character on the video when there is a video signal or on blue screen when there is no video signal. (No sync).




Fig. 7-32 Block Diagram

## MEMO

---

## 8. VCR Deck Operating Descriptions

---

### 8-1 Features of Mechanism

---

The following items describe features of the mechanism in VCR.

- (1) This VCR uses 3-motor system consisted of a cylinder motor, capstan motor, and loading motor.  
A capstan motor is used to drive the reel and the driving force is transmitted through the belt capstan.  
The cassette loading, tape loading, and mode shift operation are performed by the loading motor.
- (2) The time duration from cassette-in to picture appearance is shortened by employing the loading drive mechanism (automatic transferring operation from the cassette loading to the tape loading by rotating the loading motor continuously), and by increasing the speed of the tape loading, etc
- (3) Employment of the full loading system shortens time required to shift the mode such as STOP to PLAY-BACK picture display.
- (4) To simplify wiring and others, the electrical components relating to operation of the mechanical deck, such as sensors, mode switch, servo microcomputer, etc. are mounted on the PCB arranged all over the bottom side of the mechanical deck.

### 8-2 Basic Configuration of Mechanism

---

As shown in Fig. 8-1, the mechanism of VCR is configured with five main blocks, and each operation is precisely controlled by the microcomputer built in the system control section.

First, load a video cassette tape in VCR :

- (1) The cassette is automatically set on the reel disc.
- (2) The tape is pulled out from the cassette, and wrapped around the cylinder.
- (3) The cylinder turns in a constant speed rate synchronizing with the vertical Sync. signal of video signal.
- (4) The tape runs in synchronization with cylinder rotation and traces the video tracks precisely.
- (5) The running tape is taken up by the reel, the tape feeding side is given with a proper tension so that tape is not slacked.

The above series of operations are performed under control of the system control section. The system control section also sends commands to each mechanism according to the operation buttons, thus the VCR is designed so that various operations such as recording, playback, special playback, FPS/RPS, and FF/REW, etc. are correctly performed.




Fig. 8-1 Basic Configuration of Mechanism

## 8-3 Main Mechanism and Functions

### 8-3-1 Tape Path System

The tape come out from the supply reel (S) of the video cassette runs through paths shown in Figs. 8-2 and 8-3, and is taken up by the take-up (T) reel. (S stands for the supply reel, and T for the take-up reel, hereafter.)

At S reel side (tape entrance side of the cylinder) against the cylinder, a tension post to allow the tape surface to contact with each head with a proper tension which assures stable running, an FE head which erases entire data of the tape, and an S guide roller which restricts tape motion in upward/downward direction are provided.

In the same way, a T guide roller, audio head to record audio signals at upper side of the tape, control head to record and reproduce a control signal at lower side of the tape, and an audio erase head to erase only the audio signals and perform after-recording in parallel with the audio head are provided at T reel side. (tape exit side of the cylinder).

The guide parts marked with asterisks (\*) are equipped with the adjusting mechanism to stabilize the tape running or to record and reproduce the signals precisely.




Fig. 8-2 Tape Path System




Fig. 8-3 Guide Path System



### 8-3-2 Reel Drive System

The reel drive system consists of a capstan motor as a drive power source, belt as a power transmission mechanism, clutch mechanism, idle gears, and a reel disc. Selecting of forward rotation or reverse rotation is carried out by an idle gear which changes its rotating direction according to rotating direction of the clutch holder.

Reel take-up torque is selected according to an operation mode.

In the record, playback, fps, rps modes, the reel take-up torque is controlled by the clutch mechanism, thereby the tape fed by the capstan is taken up with a proper torque.

In the FF and REW modes, the clutch enters a direct connecting status in which the clutch mechanism does not operate and the capstan drive torque is transmitted without reduction, so a high speed taking-up is enabled.




Fig. 8-4 Reel Drive System

## 8-4 Basis of the Mechanism

### 8-4-1 Front Loading

- (1) When a video cassette is inserted into the cassette holder and pushed furthermore, FL arm lever is rotated by motion of the cassette holder. The rotation of FL arm lever makes the horizontal moving of FL drive slider.
- (2) When the information of Start Sensor OFF is transmitted to the microcomputer, the loading motor starts to rotate.
- (3) The rotation is transmitted in a sequence shown below :  
Loading motor - worm gear - worm wheel - FL Cam Gear - FL Drive Slider - FL Arm Lever - Cassette Holder
- (4) The video cassette is horizontally moved.
- (5) The cassette tape is vertically moved.  
In this case, the cassette lid is opened.
- (6) The cassette tape is set on the reel disc, and loading operation completes.
- (7) The cassette tape is loaded.
- (8) The status becomes full loading.
- (9) When the cassette is out, the reverse steps of the above procedure are carried out.




Fig. 8-5




Fig. 8-6 Drive Transmission Path

### 8-4-2 Cassette loading/unloading Modes

When a cassette is entered in the VCR, the cassette is set on the reel disc by the front loading mechanism. In this case, the tension post, loading tape guide, capstan motor, and the No.9 guide are positioned inside of the tape in the cassette case.




Fig. 8-7 Cassette IN/OUT Mode

### 8-4-3 Tape Loading

A full loading system is employed.

In the full loading system, the tape loading starts at the same time when the cassette loading operation has completed and cassette has been mounted, and the tape is pulled out, wrapped around the cylinder and the mechanism enters the stop status under this condition.




Fig. 8-8 Tape Loading

### 8-4-4 Playback Standby Mode

In the full loading system, the tape loading starts at the same time when the cassette mounting has completed, the mechanism shifts to the playback position, and enters the standby status with keeping tape wrapped around the cylinder.

In this case, tape tension applied to the cylinder is decreased to protect the tape and to prevent the tape from scratches.

### 8-4-5 FF/REW Modes

The reels enter a free status by rotating the loading motor to go to FF/REW position.

In this case, the capstan motor rotates in colck-wise direction in the REW mode. The idle gear is swung rightward or leftward according to the rotating direction of the capstan motor. As a result, the T reel rotates in the FF mode or the S reel rotates in the REW mode, thus taking up the tape to the rotating reel.




Fig. 8-9 FF/REW Mode

### 8-4-6 Record/Playback Modes

When the record or playback button is pressed, the tape is fed by the rotation of the capstan motor. In this case, a tension post touches the tape and braking forces created by the band brake linked with the tension post is applied to the S reel, thereby stabilizing the tape tension. The tape fed by the capstan is taken up around the T reel. The T reel is driven with a constant torque generated by transmitting rotation of the capstan motor to the clutch mechanism.




Fig. 8-10 Record/Playback Mode

## 8-5 System Control

In the VCR, complex mechanism, video, audio, servo circuits, etc. must be operated in specified timings matched each other. The system control circuit performs entire controls for the VCR.

An automatic stop function is also provided to protect important tape if a trouble occurs on the complex mechanism and the electrical circuits.

For this purpose, status of each part of the mechanism is always monitored with various sensor switches, and the microcomputer controls collectively the unit so that the best condition is kept.

Moreover, the microcomputer controls signal switchings for each circuit according to the mechanism status.




Fig. 8-11 System Control Block Diagram

## 8-6 System Control and Mechanical Operations

### 8-6-1 Mechanical Operation

The operation of mechanism is performed by rotation of the loading motor, and the transmission path of the operation is as shown in Fig. 8-12.




Fig. 8-12 Transmission Path of Operation


Fig. 8-14 shows each mode and mechanism status in each mode concerned with the rotation of the FL cam gear or cam slider shift. The mechanism operates as shown in Fig. 8-13 according to the timing chart in Fig. 8-14.

**Note :**

The Start Sensor is actuated by the horizontal moving of Slider FL Drive and turned on or off by insertion or ejection of a cassette.



## &lt;Top View&gt;



## &lt;Bottom View&gt;




Fig. 8-13 Mechanical Operation




Fig. 8-14 Mecha Timing Chart

**(1) There are two STOP modes and two FF/REW modes.****1) STOP 1**

This mode is performed when PB and FF/REW is not done for 5 minute at power on.

The small load is given to S REEL DISC and T REEL DISC. And the cylinder motor is stopped.

**2) STOP 2**

This mode is performed when you press the stop button as performing FF/REW.

The large load is given to S REEL DISC and T REEL DISC.

**3) FF/REW 1**

This mode is performed when

❶ The tape load is small during performing FF and reducing speed.

❷ The tape load is large during performing REW.

The small load is given to S REEL DISK and no load is given to T REEL DISC.

**4) FF/REW 2**

This mode is performed when

❶ The tape load is large during performing FF.

❷ The tape load is small during performing REW and reducing speed

No load is given to S REEL DISK and the small load is given to T REEL DISK.

(Cf) According to acceleration, deceleration, and the location of tape, tension control which is caused by converting FF/REW 1 and FF/REW 2 each other is performed during FF or REW.

**(2) The condition of S Brake and T Brake at each mode.****< S BRAKE >****1) OFF BRAKE (Unloading completion, RPS, PLAY, FF/REW 2)**

- S BRAKE is detached from S REEL DISC completely. So S REEL DISC is free.




Fig. 8-15

**2) SOFT BRAKE(during LOADING, STOP 1, FF/REW 1)**

- The small load is given to S REEL DISC.




Fig. 8-16

**3) MAIN BRAKE (STOP 2)**

- The large load is given to S REEL DISC.




Fig. 8-17

**< T BRAKE >**

**1) OFF BRAKE (PLAY, FF/REW 1)**

- T BRAKE is detached from T REEL DISC completely. So T REEL DISC is free.




Fig. 8-18

**2) SOFT BRAKE (UNLOADING Completion ,STOP 1, FF/REW 2 )**

- The small load is given to T REEL DISC.




Fig. 8-19

3) REVERSE SEARCH BRAKE (RPS)

- The medium load is given to T REEL DISC.




Fig. 8-20

4) MAIN BRAKE (on the loading, STOP 2)

- The large load is given to T REEL




Fig. 8-21

### 8-6-2 Mode Sensor Drive

The mode sensor converts each mode of the mechanism into an electrical signal and transmits it to the microcomputer. The FL cam gear is rotated by the loading motor, and the cam slider slides after operation of the cassette holder.

Then the mode switch also rotates synchronized with the cam slider and outputs a signal corresponding to each mode. This signal is transmitted to the microcomputer and the microcomputer stops the cam slider at a specified angle, thus establishing each mode.

The IC601 controls Capstan Motor Drive IC for each mode to make the loading motor rotate in forward or reverse direction, thereby setting the mechanism at a specified position.

The mode switch develops three outputs A, B and C.

The circuit configuration of the mode sensor drive is shown in Fig. 8-22.




Fig. 8-22 Mode Sensor Drive

## 8-6-3 Operations in Each Mode

### [1] Cassette loading & Tape loading mode

#### <Cassette loading>

- (1) The FL cam gear is in the Cassette unloading (position I) position, and the cassette holder is in the out status (start sensor ON). Under this condition, each motor is stopped.
- (2) Status of the mechanism is as follows.
  - 1) S.T guide rollers, tension post, No.9 guide are in unloading status and housed in the reel disc side.
  - 2) S brake is released and T brake is in soft brake status.
  - 3) The clutch holder assembly is in clutched status and idle lever assembly is enabled to be engaged with both S and T reel discs.
- (3) When a cassette is inserted, the lock lever of cassette holder is released from the stopper, the cassette holder moves, the FL arm lever rotates, and the FL Drive Slider slides, thereby closing the start sensor.
- (4) IC601 controls Capstan Motor Drive IC to rotate the loading motor in forward direction, and move the cassette holder. At the same time, the capstan motor rotates in the reverse direction and moves the cassette down (vertical motion) while rotating the S reel disc.
- (5) The cassette lid opens when the vertical motion starts.
- (6) When the vertical motion has completed and the cassette is mounted, the capstan motor rotates in the reverse direction. At that time the position "a" is detected with the cam slider shifted and the loading/capstan motors are stopped. After 300msec the loading motor rotates in the forward direction and enters the tape loading operation.




Fig. 8-23 Cassette-Loading Mode (Position I)

# <Tape loading>

- (1) After slot-in operation (cassette loading), FL cam gear rotates and the cam slider starts shifting, and a loading gear is ready to start.

Under this condition, the mechanism status is as follows :

- 1) The T main brake actuates so that tape does not come out from the T reel during the loading operation.
- (2) The cylinder starts to rotate after the loading motor is rotated.
- (3) When the cam slider reaches the position II (loading/unloading modes), the mechanism enters the loading status and operates as described below.
  - 1) S,T sliders are moved through the loading drive gear and turn on the tension post.
  - 2) The No. 9 guide is loaded.
  - 3) The pinch roller is loaded up to front of the capstan.
  - 4) The head cleaner is actuated during loading operation.
  - 5) The S soft brake is actuated.
- (4) When the cam slider passes through the position III, and detects the position IV (playback standby mode), the loading motor stops. Under this condition, the mechanism status is described as below :
  - ❶ The pinch roller is pressed to the capstan.
  - ❷ The No.9 guide is stored in the cassette.
  - ❸ The tension post touches the tape, band brake force is applied, and the tension servo brake mechanism actuates.
  - ❹ Brakes for the reel discs are all off.




Fig. 8-24 Tape Loading Operation (Position II)



## &lt;Playback Stand-by (Stop) mode&gt;

- (1) The tape loading operation completes and the loading motor stops.
- (2) In the same way as in the playback mode, the capstan motor rotates in forward direction and the T reel disc takes up the tape. (For more details, refer to the playback mode.)
- (3) After running the tape for 0.6s, the mechanism rotates the capstan in the reverse direction for 0.3s to slack the tape properly with pinch roller pressed.
- (4) If nothing is operated for about 5 minutes, the loading motor rotates in the forward direction and the cam position reaches the position V, and both the loading motor and the cylinder motor stop.
- (5) During this period, the video and audio systems are in the same status as in the stop mode.

**[2] Tape unloading & Cassette unloading**

## &lt;Tape Unloading&gt;

- (1) When the [EJECT] button is pressed in the stop mode, the mechanism enters the eject mode.
- (2) IC601 controls cylinder motor drive IC to make the cylinder motor rotates.
- (3) IC601 makes the loading motor rotate in the reverse direction, and shifts the cam slider.
  - 1) The mechanism components move in the reverse direction against the loading operation.
- (4) When the cam slider reaches the position II, IC601 makes the capstan motor rotate in the reverse direction (LP X11) and takes up the tape at a specified torque using the clutch mechanism.
- (5) When the cam slider reaches the position I, it brakes the capstan motor to stop, and then stops the loading motor after 230ms passed.

## &lt;Cassette unloading&gt;

- (1) Furthermore, IC601 makes the loading motor rotate in the reverse direction and also the capstan motor in reverse direction, applies braking force to the capstan motor by detecting the tape start sensor OFF --> ON, and the capstan motor stops.
- (2) IC601 makes the loading motor stop after 150ms passed from sensing "ON".
- (3) Also IC601 makes the loading motor rotate in the forward direction after 120ms passed.

### [3] Stop mode

- (1) The cam slider is in the stop mode (position V) and each motor stops.
- (2) The mechanism status is as follows :
  - 1) The S, T guide rollers are in the loading status.
  - 2) The pinch roller is kept away from the capstan.
  - 3) The tension post is shifted to the reel disc side. That is, the band brake is released from the ON status and the back tension is also released.
  - 4) The S, T soft brakes are being applied.




Fig. 8-25 Stop Mode (Position V)

**[4] FF/REW mode**

- (1) When the [REW] button is pressed in playback standby mode, the mode enters the FF/REW mode.
- (2) IC601 controls Capstan Motor Drive IC and makes the loading motor rotate in the forward direction.  
The loading motor stops when the cam position reaches the position VI, VII (FF/REW mode).  
The mechanism status is as follows :
  - 1) The pinch roller is OFF.
  - 2) The No. 9 guide is once loaded but immediately returned.
  - 3) The tension post is moved to the reel disc side. That is, the band brake is released from the ON status and the back tension is released.
  - 4) The clutch holder assembly is in the direct status and the capstan driving force is directly transmitted to the reel disc.
  - 5) Brakes for the reel discs are as follows :
    - ① VI position FF/REW 1 mode (S Brake : soft brake, T Brake : off)
    - ② VII position FF/REW 2 mode (S Brake : off, T Brake : soft brake)
- (3) IC601 makes the capstan motor rotate in the forward direction and the idle gear transmits the rotation to the S/T reel discs to take up the tape.

**[5] FF/REW to STOP mode**

- (1) When the [STOP] button is pressed in the REW mode, the mechanism enters the playback standby mode.
- (2) IC601 makes the loading motor rotate in the reverse direction and stops at the position V.  
With this mode shift, the mechanism actuates S, T main brakes to stop the tape. Then, the capstan motor also stops by braking force 70ms after detecting "e" position.
- (3) IC601 makes the loading motor rotate in the reverse direction again and stops the loading motor when the cam slider reaches the position IV (playback mode), thus setting the playback standby mode.




Fig. 8-26 FF/REW 2 Mode (Position VII)

## [Playback mode]

- (1) When the [PLAY] button is pressed in the stop mode, the mechanism enters the playback mode.
- (2) IC601 controls cylinder motor drive IC and rotates the cylinder motor.
- (3) IC601 controls Capstan Motor Drive IC to rotate the loading motor in the reverse direction and stops the motor when the cam slider reaches the position IV (playback mode). (When operating from the playback standby mode, the cam slider has been already on the position IV.) The mechanism works as follows :
  - 1) The pinch roller moves toward the capstan side and press fits the capstan.
  - 2) The No.9 guide is loaded once and then returned immediately.
  - 3) The tension post touches the tape, the band braking force is applied, and the tension servo mechanism works.
  - 4) The clutch holder assembly enters clutched condition.
  - 5) S,T brakes are released.
- (4) IC601 makes the capstan rotate in the forward direction and feeds the tape. The idle gear transmits the rotation to the T reel disc and the reel disc takes up the tape at a constant torque by the clutch mechanism.
- (5) IC601 controls the video circuit and switches the playback screen.
- (6) The recording speed data identified by IC601 is displayed in the Led module.




Fig. 8-27 Playback Mode (Position IV)

## &lt;Still mode&gt;

- (1) When the [PAUSE] button is pressed in the playback mode, the mechanism enters the still mode.  
The cam slider is in the position IV (playback mode), the cylinder motor is rotating, and the capstan motor is rotating in the forward direction.
- (2) IC 601 controls the audio circuit and actuates the audio mute function.
- (3) The capstan motor enters the intermittent operation mode and then stops.
- (4) IC 601 maintains the recording speed data just before the still operation.
- (5) In the slow mode, the capstan motor rotates continuously in the intermittent driving.

## &lt;FPS mode&gt;

- (1) When the [FF] button is pressed in the playback mode, the mechanism enters the FPS mode (forward picture search). The cam slider is in the position IV (playback mode), the cylinder motor is rotating, and the capstan motor is rotating in the forward direction.
- (2) IC 601 controls the audio circuit to actuate the audio mute operation.
- (3) IC601 makes the capstan rotate at 7 times for SP, 21 times for SLP to feed the tape, respectively.  
The tape is taken up at a constant torque by the clutch mechanism. (The mechanical operation is the same as that in the playback mode.)
- (4) The recording speed data identified by IC601 is displayed on the Led module.

<RPS mode>

- (1) When the [REW] button is pressed in the playback mode, the mechanism enters the RPS mode.  
The cam slider is in the position IV (playback mode), the cylinder motor is rotating, and the capstan motor is rotating in the forward direction.
- (2) IC601 controls the audio circuit to actuate the audio mute operation.
- (3) IC601 controls Capstan Motor Drive IC to make the loading motor rotate in the reverse direction.  
After 180ms the loading motor stops for 250ms. During the mode shift operation, the mechanism rotates the capstan motor in the forward direction for a constant time so that the tape is not slackened.
- (4) When the cam slider reaches the position “c” (loading motor stopped for 250ms), the capstan motor is rotated in the reverse direction for a constant time, and the idle gear is swung toward the S reel disc side.  
Then, the loading motor rotates in reverse direction and shifts to the position III (RPS mode).  
When the cam slider reaches the position III (RPS mode), the loading motor stops.  
The mechanism status is as follows :
  - 1) The No.9 guide is loaded.
  - 2) The tension post is separated from the tape.
  - 3) The T soft brake is turned on.
 The capstan motor rotates in the reverse direction at 7 times for SP, 21 times for SLP to feed the tape in the REW direction, respectively. At the same time, the idle gear transmits the rotation to the S reel disc and the S reel disc takes up the tape by the clutch mechanism.
- (5) The recording speed data identified by IC601 is displayed on the Led module.




Fig. 8-28 RPS Mode (Position III)

**[7] REC mode**

## &lt;REC mode&gt;

- (1) When the [REC] button is pressed in the stop mode, the mechanism enters the REC mode.
- (2) The cylinder motor starts and then the loading motor rotates in reverse direction.  
The cam slider reaches the position IV (playback mode).  
The tape is taken up at a constant torque. The mechanism operations are the same as those in the playback.
- (3) IC601 controls the audio circuit and video circuit to set the record enable mode.
- (4) Recording mute is released, thus setting the recording status. The CTL signal is output for recording.


## &lt;REC PAUSE mode&gt;


- (1) When [PAUSE] button is pressed in the REC mode, the mechanism enters the REC pause mode.
- (2) IC601 controls the audio circuit and the video circuit, and releases the record enable mode and performs the rewinding for synchronous editing.
- (3) After completion of the rewinding for synchronous editing, the cam slider is in the position IV (playback mode), the cylinder motor is rotating, and the capstan motor and the loading motor stop.



## MEMO





## 9. Troubleshooting




























































---

# 10. Exploded View and Parts List


---

10-1 Cabinet Assembly - - - - - 10-2

10-2 VCR Mechanical Parts (Top Side)- - - - - 10-4

10-3 VCR Mechanical Parts (Bottom Side) - - - - - 10-6


10-1 Cabinet Assembly



● S.N.A. : Service Not Available

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
A001	AK59-00028c	BY634856	REMOCON-ASSY;D-VR3TG/TSB,SEC,187.5*54,-,	D-VR3SF/D-VR3SG Only
	AK59-00028B	BY634855	REMOCON-ASSY;D-VR3TB/TSB,SEC,187.5*54,-,	D-VR3SB Only
C001	AK97-01014C	BY630420	ASSY-PANEL FRONT;HIPS 96 V2,D-VR3 TG/TF,	D-VR3SF/D-VR3SG Only
	AK97-01014B	BY630447	ASSY-PANEL FRONT;HIPS 96 V2,D-VR3 TB,04-	D-VR3SB Only
C002	AK64-00823B	BY731668	DOOR-TRAY;D-VR3 TB,ABS 94 HB,T2.0,H26.5,	
C003	AK64-00822A	BY731618	DOOR-CASSETTE;D-VR3,ABS 94HB,T2.5,H26.6,	
C011	AK64-00334A	BY734041	DOOR-SPRING;DVD-V3500,SWPB,,,,,-,,	
C012	AC61-62032A	BY730093	SPRING ETC-MASK;SV-C130,SUS,4.4,-,-,-,-,	
C015	AK64-00621A	BY731610	CABINET-TOP;DVD-VR300,PCM,T0.6,W596,L309	
C022	AK64-00824A	BY731619	DOOR-FRONT;D-VR3,ABS 94HB,T1.5,H34,W124.	
H001	6001-001838	BY731724	ASSY-RECORDER DECK;- ,DP-R1,ASSY RECORDER	
LD61A	AC61-00340A	BY530080	HOLDER-LED;X-11,POM(K300),-,-,-,NTR,-	
P001	AK92-00498E	BY630412	ASSY PCB-MAIN VCR;D-VR3TB/TSB,TOSHIBA PA	
	AK92-00498F	BY630413	ASSY PCB-MAIN VCR;D-VR3TF/TSB,TOSHIBA PA	D-VR3SF Only
P002	AK92-00429D	BY630418	ASSY PCB-MAIN DVD;DVD-VR300E,MAIN DVD P	
P003	AK94-00037B	BY630415	ASSY PCB-JACK;DVD-VR300E/XEU,ASSY SORT-J	D-VR3SB/D-VR3SG Only
	AK94-00037A	BY630414	ASSY PCB-JACK;DVD-VR300E,ASSY SORT-JACK	D-VR3SF Only
P005	AK94-00045A	BY630448	ASSY SORT-FUNCTION;DVD-VR300E,FUNCTION	
P007	AK92-00554B	BY630419	ASSY PCB-KEY;D-VR3TB/TSB,ASSY PCB KEY	
P025	AC39-12022K	BY634126	CBF-POWER CORD;AT,,GP2,HOUING(2P),250V,3	D-VR3SB Only
	AC39-10019A	BY634124	CBF-POWER CORD;KKP-419C,H03VVH2-F,VDE/KE	D-VR3SF/D-VR3SG Only
P030	3103-001152	BY731622	FAN-DC;DC 12.0V,110mA,1700rpm,0.581m^	
S602A	AC61-00341A	BY530081	HOLDER-TR;X-11,POM(K300),-,-,-,NTR,-	
W200	6003-001375	BY731681	SCREW-TAPTITE;BH,+,B,M3,L8,ZPC(YEL),SWRC	
W202	6003-000277	22709856	SCREW-TAPTITE;BH,+,B,M3,L12,ZPC(YEL),SWR	
W252	AC60-12126A	70790218	SCREW-MACHINE;-,-,FE,FZY,BH,-,-,4*12,-,-	
W272	6003-001464	BY731645	SCREW-TAPTITE;BH,+,B,M3,L10,ZPC(WHT)	
	AC39-00017A	BY634253	CABLE-ETC-RF(PAL);-,MALE/FEMALE,1200MM,R	D-VR3SB/D-VR3SG Only
	AC39-00018A	BY634851	CABLE-ETC-RF(SECAM);BOTHMALE,1200MM,R	D-VR3SF Only
	AC39-20017Z	BY634852	CABLE-RCA PHONE CORD;-,-,1500M/M,SINGLEE	
	AC39-42001U	BY631148	CABLE-RCA PHONE CORD;DOUBLE,-,1.5MT,BLK,	
	AK68-00500B	BY731672	MANUAL USERS;D-VR3TB,TOSHIBA,ENGLISH,-,M	D-VR3SB Only
	AK68-00500C	BY731673	MANUAL USERS;D-VR3TG,TOSHIBA,GERMAN,-,MO	D-VR3SG Only
	AK68-00500D	BY731674	MANUAL USERS;D-VR3TF,TOSHIBA,FRENCH,-,MO	D-VR3SF Only


## 10-2 VCR Mechanical Parts (Top Side)



Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
T001	AC97-02258A	BY731659	ASSY-CLLINER;6S,CX11-SEM,FOR SLIM DECK	
T002	AC70-00002A	BY731640	PLATE-GND DECK;X-11,SPTE,T0.3,-,-,-,-	
T003	AC31-00018A	BY631184	MOTOR-LOADING ASSY;-,-,SCORPIO2(TS-10A),-,-	
T004	AC66-00008A	BY730743	GEAR-WORM WHEEL;TS-10,POM,0.8,40,-,-,NAT,3	
T005	AC66-00011A	BY730745	GEAR-FL CAM;TS-10,POM,0.8,59,-,-,BLK,48.48	
T006	AC61-00105A	BY730723	SPRING ETC-PINCH DRIVE;TS-10,SUS304-WPB,	
T007	AC61-30180A	BY730244	PLATE-JOINT;X-9,SECC20/20,T0.8,-,-,-,-	
T008	AC66-80142A	BY730124	SLIDER-SUPPLY ASSY;X-9,SUS,-,-,-,-,SIL,-	
T009	AC66-80141A	BY730123	SLIDER-TAKE UP ASSY;X-9,SUS,-,-,-,-,SIL,-	
T010	AC97-01655A	BY630391	ASSY-HEAD ACE;-,-,SCORPIO2(TS-10A),HVMXA11	
T011	AC66-00074A	BY731526	LEVER-GUIDE(#9);TS-9,PPS,-,-,-,-,BLK,KHA	
T012	AC61-60553A	BY730088	SPRING ETC-GUIDE 9;X-9,SUS304-WPB,0.25,-	
T013	AC33-00015A	BY634836	HEAD-FE;HVFP0050A,PBT3300,2PIN,NATURA	
T014	AC66-00083A	BY731636	LEVER-FL DOOR;X-11,POM(K300),-,-,-,-,BLU	
T015	AC97-02293A	BY731528	ASSY-UNIT PINCH;SECC+SUS304,TS-10,FOR X-	
T016	AC97-02215A	BY630397	ASSY-POST #8 GUIDE;SUS303+POM(M90-44)EQ,	
T019	AC66-10267A	BY730102	REEL-DISK S;X-9,POM,-,-,-,-,-,-,-	
T020	AC66-10268A	BY730103	REEL-DISK T;X-9,POM,-,-,-,-,-,-,-	
T021	AC66-30524A	BY730112	LEVER-IDLER;-,-,POM,-,-,-,-,BLK,-	
T022	AC66-00039A	BY730760	GEAR-IDLE;TS-10,PET K3372,0.5,-,-,-,NTR,28	
T023	AC66-00035A	BY730759	LEVER-TENSION ASS'Y;TS-10,SECC E20/20+SU	
T024	AC61-00107A	BY730725	SPRING ETC-TENSION LEVER;TS-10,SUS304-WP	
T025	AC69-00104A	BY730762	BAND-BRAKE ASS'Y;TS-10,-,-,-,-,-,-,-	
T026	AC66-30550A	BY730121	LEVER-S.BRAKE ASSY;-,-,POM+SUS,-,-,-,-,X-9	
T027	AC66-30549A	BY730120	LEVER-T.BRAKE ASSY;-,-,POM+SUS,-,-,-,-,X-9	
T028	AC61-00106A	BY730724	SPRING ETC-BRAKE;TS-10,SUS304-WPB,-,-,-,-	
T029	AC66-00020A	BY730750	SLIDER-FL DRIVE;TS-10,SECC ,T1.0,-,-,-,SIL	
T030	AC97-02323A	BY731660	ASSY-HOLDER FL CASSETTE;SECC+POM,X-11,Fo	
T031	AC61-60561A	BY730091	SPRING ETC-FL.LEVER-LR;X-9,SUS304 WPB,OD	
T032	AC97-02324A	BY731661	ASSY-LEVER FL ARM;SECC+POM,X-11,For X-11	
T033	AC61-50658A	BY730086	GUIDE-CASS. DOOR;X-9,POM,-,-,-,-,NTR	
W015	6006-001092	BY634416	SCREW-MACHINE;WS,PH,+,M3.0,L6.0,ZPC(YEL)	
W016	6006-001154	BY731647	SCREW-TAPTITE;WSP,PH,+,M2.6,L5.6,ZPC(YEL)	
W201	6001-001711	BY731536	SCREW-MACHINE;PH,+,M3,L3.3,ZPC(YEL)	

## 10-3 VCR Mechanical Parts (Bottom Side)

---





Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
T034	AC66-00076A	BY731626	GEAR-JOINT 1;X-11,POM(K300),-, -, -,BLUE,-	
T035	AC66-00077A	BY731627	GEAR-JOINT 2;X-11,POM(K300),-, -, -,BLUE,-	
T036	AC61-00338A	BY731599	BRACKET-GEAR;X-11,SECC,T0.8,W20,L20,NTR,	
T037	AC66-00075A	BY731651	SLIDER-CAM;X-11,SECC ,T1.2,-, -, -,SIL,-	
T038	AC66-00017A	BY730748	LEVER-PINCH DRIVE;TS-10,SECC E20/20,1.0	
T039	AC70-00003A	BY634837	HOOK-CAPSTAN;-,-,L10,W10,H10,POM(M90-44)	
T040	AC66-00016A	BY730747	LEVER-TENSION DRIVE;TS-10,SECC E20/20,1	
T041	AC66-00078A	BY731628	GEAR-LOADING DRIVE;X-11,POM(K300),-, -, -,	
T042	AC97-02195A	BY630393	ASSY-LEVER LOADING S;SECC+POM+SUS,X-11,F	
T043	AC97-02196A	BY630394	ASSY-LEVER LOADING T;SECC+POM+SUS,X-11,F	
T044	AC81-00002A	BY731637	MOTOR-CAPSTAN;THRUST END PLAY-0.2,MR-FG	
T045	3809-001270	BY634670	CABLE-FLAT;30V,80C,140MM,10P,1.25MM,UL28	
T046	AC66-60051A	BY730122	BELT-PULLEY;- ,5CM-70,2 * 2,-,71.3,-,X-9	
T047	AC61-21012A	BY730084	HOLDER-CLUTCH ASSY;X-9,ABS,-, -, -,BLK,-	
T048	AC66-20581A	BY730111	GEAR-CENTER ASSY;X-9,POM,M=0.5,-, -, -,GRY,-	
T049	AC60-30306A	BY730076	FASTENER-WASHER SLIT;-,-,ID2.1,OD5.0,T0.	
T050	AC66-00006A	BY730742	LEVER-UP DOWN;TS-10,POM,-, -, -, -,NAT,-	
W018	6003-001450	BY731520	SCREW-TAPTITE;PH,+,S,M2.6,L5,ZPC(YEL)	
W019	6003-000108	BY731519	SCREW-TAPTITE;BH,+,B,M2.6,L6,ZPC(YEL),SW	

**MEMO**

## 11. Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
P001	AK92-00498E AK92-00498F	BY630412 BY630413	ASSY PCB-MAIN VCR;D-VR3TB/TSB,TOSHIBA PA ASSY PCB-MAIN VCR;D-VR3TF/TSB,TOSHIBA PA	D-VR3SB/D-VR3SG Only D-VR3SF Only
BD01	0402-001608	BY430109	DIODE-BRIDGE:GBJ2J,600V,2A,SIP-4,BK	
BD1S01	AC27-92001M	70795644	COIL-INDUCTOR;RH3.5X6.5RS,BEAD(RADIAL),-	
BD1S02	AC27-92001M	70795644	COIL-INDUCTOR;RH3.5X6.5RS,BEAD(RADIAL),-	
C1P103	2401-003107	BY130282	C-AL:47uF,20%,16V,GP,TP,5x7,5	
C1P104	2401-003107	BY130282	C-AL:47uF,20%,16V,GP,TP,5x7,5	
C1P105	2401-003107	BY130282	C-AL:47uF,20%,16V,GP,TP,5x7,5	
C1P106	2401-003107	BY130282	C-AL:47uF,20%,16V,GP,TP,5x7,5	
C1P107	2401-002165	BY130280	C-AL:100uF,20%,16V,GP,TP,6.3x7,5	
C1P108	2401-002165	BY130280	C-AL:100uF,20%,16V,GP,TP,6.3x7,5	
C1P109	2401-001730	70795625	C-AL:10UF,20%,50V,GP,TP,5X11,5	
C1P121	2401-001250	70796211	C-AL:4.7uF,20%,35V,GP,TP,4x5,5	
C1P122	2401-000598	BY130042	C-AL:1uF,20%,50V,GP,TP,4x7,5	
C1P123	2401-001730	70795625	C-AL:10UF,20%,50V,GP,TP,5X11,5	
C1P124	2401-001250	70796211	C-AL:4.7uF,20%,35V,GP,TP,4x5,5	
C1P125	2401-000414	BY130273	C-AL:10uF,20%,16V,GP,TP,4x7,5	
C1P126	2401-000414	BY130273	C-AL:10uF,20%,16V,GP,TP,4x7,5	
C1P127	2401-001250	70796211	C-AL:4.7uF,20%,35V,GP,TP,4x5,5	
C1P128	2401-003107	BY130282	C-AL:47uF,20%,16V,GP,TP,5x7,5	
C1P129	2401-003107	BY130282	C-AL:47uF,20%,16V,GP,TP,5x7,5	
C1S01	2401-000342	BY130532	C-AL:100uF,20%,400V,WT,-,20x30,10	
△ C1S04	2301-001719	BY130538	C-FILM,LEAD:100nF,10%,275V,TP,17.5*6*12m	
△ C1S05	2301-001719	BY130538	C-FILM,LEAD:100nF,10%,275V,TP,17.5*6*12m	
△ C1S06	2201-000987	BY130164	C-CERAMIC,DISC:2.2NF,20%,400V,Y5U,BK,12.	
C1S07	2201-000012	BY130519	C-CERAMIC,DISC:0.22NF,10%,1KV,Y5P,TP,6.3	
C1S08	2305-001029	BY130226	C-FILM,LEAD-PEF:10nF,10%,630V,TP,12x9x12	
C1S09	2401-002608	BY130473	C-AL:33uF,20%,35V,GP,TP,5x11,5	
C1S10	2401-001730	70795625	C-AL:10UF,20%,50V,GP,TP,5X11,5	
C1S11	2301-000402	70795094	C-FILM,LEAD-PEF:1nF,5%,50V,TP,5x7x2.8mm,	
C1S12	2201-000556	BY130061	C-CERAMIC,DISC:0.47NF,10%,500V,Y5P,TP,5.	
C1S13	2301-001679	BY130530	C-FILM,PEF:2.2nF,5%,50V,TP,5.8x3x7mm,-	
C1S14	2201-000863	70795084	C-CERAMIC,DISC:0.68NF,10%,50V,Y5P,TP,5X3	
C1S15	2301-000402	70795094	C-FILM,LEAD-PEF:1nF,5%,50V,TP,5x7x2.8mm,	
C1S30	2401-003390	BY130501	C-AL:2200uF,20%,16V,LZ,TP,13x31.5,5	
C1S31	2401-003390	BY130501	C-AL:2200uF,20%,16V,LZ,TP,13x31.5,5	
C1S32	2401-000385	70795431	C-AL:10uF,20%,100V,GP,TP,6.3x11,5	
C1S33	2401-000717	BY130493	C-AL:2200uF,20%,25V,WT,TP,12.5x25,5	
C1S34	2401-001126	BY130045	C-AL:330uF,20%,25V,WT,TP,10x12.5,5	
C1S37	2401-001479	BY130015	C-AL:470uF,20%,10V,GP,TP,6.3*11mm,5	
C1S38	2401-001479	BY130015	C-AL:470uF,20%,10V,GP,TP,6.3*11mm,5	
C1S39	2301-001653	BY130529	C-FILM,LEAD-PEF:220nF,5%,100V,TP,22.5x13	
C1S41	2401-001126	BY130045	C-AL:330uF,20%,25V,WT,TP,10x12.5,5	
C1S42	2201-000812	BY130216	C-CERAMIC,DISC:2.2NF,20%,400V,Y5U,BK,12.	
C315	2203-000975	BY130484	C-CER,CHIP:47nF,10%,25V,X7R,TP,1608,-	
C317	2401-000588	BY130533	C-AL:1uF,20%,50V,GP,TP,3x5,2.5	
C318	2401-000588	BY130533	C-AL:1uF,20%,50V,GP,TP,3x5,2.5	
C319	2203-000843	BY130518	C-CER,CHIP:39nF,10%,25V,X7R,TP,1608,-	
C320	2203-000975	BY130484	C-CER,CHIP:47nF,10%,25V,X7R,TP,1608,-	
C321	2203-002398	BY130454	C-CER,CHIP:22nF,10%,50V,X7R,TP,1608	
C322	2401-000588	BY130533	C-AL:1uF,20%,50V,GP,TP,3x5,2.5	
C324	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C325	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	
C326	2401-000588	BY130533	C-AL:1uF,20%,50V,GP,TP,3x5,2.5	
C327	2203-001211	BY130448	C-CER,CHIP:8.2nF,10%,50V,X7R,TP,1608	
C328	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C329	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C330	2203-000975	BY130484	C-CER,CHIP;47nF,10%,25V,X7R,TP,1608,-	
C331	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C332	2203-000975	BY130484	C-CER,CHIP;47nF,10%,25V,X7R,TP,1608,-	
C333	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C335	2203-001652	BY130452	C-CER,CHIP;470nF,+80-20%,16V,Y5V,TP,1608	
C337	2203-001652	BY130452	C-CER,CHIP;470nF,+80-20%,16V,Y5V,TP,1608	
C338	2203-002398	BY130454	C-CER,CHIP;22nF,10%,50V,X7R,TP,1608	
C339	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C340	2401-001226	BY130016	C-AL;4.7uF,20%,16V,BP,TP,4x7,5mm	
C341	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C342	2202-002037	BY130027	C-CERAMIC,MLC-AXIAL;100nF,80-20%,50V,Y5V	
C343	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,-,1608	
C344	2203-000315	BY130441	C-CER,CHIP;0.12NF,5%,50V,C0G,TP,1608	
C345	2203-001607	BY130451	C-CER,CHIP;0.22nF,5%,50V,NPO,-,1608	
C347	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,-,1608	
C348	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C349	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,-,1608	
C350	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C351	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	
C352	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C353	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C354	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C392	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C3A01	2401-003122	70795626	C-AL;4.7uF,20%,50V,LL,TP,5X7,5	
C3A02	2401-000922	BY130044	C-AL;22uF,20%,16V,GP,TP,5x5,5	
C3A08	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C3A09	2203-001103	BY130447	C-CER,CHIP;6.8nF,10%,50V,X7R,TP,1608,-	
C3A10	2203-001211	BY130448	C-CER,CHIP;8.2nF,10%,50V,X7R,TP,1608	
C3A11	2301-000174	BY130375	C-FILM,LEAD-PEF;15nF,5%,100V,TP,7.2x4.0x	
C3A12	2401-000922	BY130044	C-AL;22uF,20%,16V,GP,TP,5x5,5	
C3A14	2202-000263	BY130172	C-CERAMIC,MLC-AXIAL;470pF,10%,50V,Y5P,TP	
C3A15	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C3A16	2401-003122	70795626	C-AL;4.7uF,20%,50V,LL,TP,5X7,5	
C3A17	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C3A18	2203-001222	BY130449	C-CER,CHIP;0.82NF,10%,50V,X7R,TP,1608	
C3A21A	2203-001554	BY130450	C-CER,CHIP;1.8nF,10%,50V,X7R,TP,1608	
C3A23	2401-002069	BY130245	C-AL;33uF,20%,16V,GP,TP,6.3x5,5	
C3A24	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C3A29	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C3A30	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C3A40	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C3A41	2401-000588	BY130533	C-AL;1uF,20%,50V,GP,TP,3x5,2.5	
C3A70	2203-001126	BY130478	C-CER,CHIP;0.68nF,10%,50V,X7R,TP,1608	
C3S01	2202-000797	70795075	C-CERAMIC,MLC-AXIAL;10NF,30%,16V,Y5S,TP,	D-VR3SF Only
C3S02	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	D-VR3SF Only
C3S03	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	D-VR3SF Only
C3S04	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	D-VR3SF Only
C3S05	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	D-VR3SF Only
C3S06	2401-001324	BY130534	C-AL;0.47UF,20%,50V,GP,BK,3X5,2.5	D-VR3SF Only
C3S07	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	D-VR3SF Only
C3S08	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	D-VR3SF Only
C3S09	2401-001324	BY130534	C-AL;0.47UF,20%,50V,GP,BK,3X5,2.5	D-VR3SF Only
C3S10	2401-003107	BY130282	C-AL;47uF,20%,16V,GP,TP,5x7,5	D-VR3SF Only
C3S11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	D-VR3SF Only
C3S12A	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	D-VR3SF Only
C3S14	2401-000665	BY130424	C-AL;2.2uF,20%,50V,GP,TP,3.5x5,5	D-VR3SF Only
C3S14A	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	D-VR3SF Only
C3S15	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	D-VR3SF Only
C501	2401-000408	BY130395	C-AL;10uF,20%,16V,GP,TP,3.5x5,2.5	
C502	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C503	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C504	2401-000408	BY130395	C-AL:10uF,20%,16V,GP,TP,3.5x5,2.5	
C505	2401-001249	BY130496	C-AL:4.7uF,20%,35V,GP,TP,4x5,2.5	
C506	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C507	2401-000909	BY130494	C-AL:22uF,20%,16V,GP,TP,5x5,2.5	
C508	2203-000888	BY130483	C-CER,CHIP:4.7nF,10%,50V,X7R,TP,1608	
C510	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	
C511	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C513	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C517	2203-000888	BY130483	C-CER,CHIP:4.7nF,10%,50V,X7R,TP,1608	
C518	2401-000909	BY130494	C-AL:22uF,20%,16V,GP,TP,5x5,2.5	
C519	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C520	2401-001249	BY130496	C-AL:4.7uF,20%,35V,GP,TP,4x5,2.5	
C521	2401-000408	BY130395	C-AL:10uF,20%,16V,GP,TP,3.5x5,2.5	
C522	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C523	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C524	2401-001249	BY130496	C-AL:4.7uF,20%,35V,GP,TP,4x5,2.5	
C525	2401-001249	BY130496	C-AL:4.7uF,20%,35V,GP,TP,4x5,2.5	
C526	2401-002165	BY130280	C-AL:100uF,20%,16V,GP,TP,6.3x7,5	
C527	2202-000797	70795075	C-CERAMIC,MLC-AXIAL:10NF,30%,16V,Y5S,TP,	
C529	2401-001250	70796211	C-AL:4.7uF,20%,35V,GP,TP,4x5,5	
C530	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C537	2401-000665	BY130424	C-AL:2.2uF,20%,50V,GP,TP,3.5x5,5	
C538	2401-002569	BY130537	C-AL:2.2uF,20%,50V,GP,TP,4x5,2.5	
C541	2401-000588	BY130533	C-AL:1uF,20%,50V,GP,TP,3x5,2.5	
C603	2401-000360	BY130317	C-AL:100uF,20%,50V,GP,TP,8x11.5,5	
C604	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C605	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C606	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C607	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C607A	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	
C609	2401-001543	BY130543	C-AL:47uF,20%,25V,GP,TP,6.3x5mm,2.5	
C610	2202-002037	BY130027	C-CERAMIC,MLC-AXIAL:100nF,80-20%,50V,Y5V	
C613	2401-003107	BY130282	C-AL:47uF,20%,16V,GP,TP,5x7,5	
C614	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C623	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C626	2203-000626	BY130444	C-CER,CHIP:0.022nF,5%,50V,C0G,TP,1608	
C627	2203-000626	BY130444	C-CER,CHIP:0.022nF,5%,50V,C0G,TP,1608	
C628	2203-000681	BY130445	C-CER,CHIP:0.027NF,5%,50V,C0G,TP,1608	
C633	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C635	2203-000491	BY130443	C-CER,CHIP:2.2nF,10%,50V,X7R,TP,1608,-	
C636	2203-000491	BY130443	C-CER,CHIP:2.2nF,10%,50V,X7R,TP,1608,-	
C637	2203-002041	BY130477	C-CER,CHIP:0.47nF,10%,50V,X7R,TP,1608	
C638	2401-001250	70796211	C-AL:4.7uF,20%,35V,GP,TP,4x5,5	
C639	2203-000236	BY130439	C-CER,CHIP:0.1NF,5%,50V,C0G,TP,1608	
C640	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C641	2401-003221	BY130499	C-AL:100uF,20%,16V,GP,TP,8X5,2.5	
C642	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	
C645	2203-000357	BY130442	C-CER,CHIP:0.15NF,5%,50V,C0G,TP,1608	
C646	2203-005148	BY130480	C-CER,CHIP:100nF,10%,16V,X7R,TP,1608	
C657	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C659A	2203-001140	BY130526	C-CER,CHIP:68nF,10%,16V,X7R,TP,1608	
C661	2202-002055	BY130286	C-CERAMIC,MLC-AXIAL:47nF,+80-20%,50V,Y5V	
C662	2401-002095	BY130048	C-AL:47uF,20%,25V,GP,TP,6.3x5,5	
C663	2401-000118	70796210	C-AL:1000uF,20%,10V,GP,TP,10x12.5,5	
C688	2401-003107	BY130282	C-AL:47uF,20%,16V,GP,TP,5x7,5	
C691	2203-000257	BY130440	C-CER,CHIP:10nF,10%,50V,X7R,TP,1608	
C695	2203-000357	BY130442	C-CER,CHIP:0.15NF,5%,50V,C0G,TP,1608	
C696	2203-000236	BY130439	C-CER,CHIP:0.1NF,5%,50V,C0G,TP,1608	
C6P01	2202-000797	70795075	C-CERAMIC,MLC-AXIAL:10NF,30%,16V,Y5S,TP,	
C6P02	2203-000315	BY130441	C-CER,CHIP:0.12NF,5%,50V,C0G,TP,1608	
C6P04	2203-000681	BY130445	C-CER,CHIP:0.027NF,5%,50V,C0G,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C6P05	2203-000681	BY130445	C-CER,CHIP;0.027NF,5%,50V,C0G,TP,1608	
C6P08	2203-001071	BY130445	C-CER,CHIP;0.056NF,5%,50V,C0G,TP,1608	
C6P10	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,-,1608	
C6P11	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	
C6P12	2401-002095	BY130048	C-AL;47uF,20%,25V,GP,TP,6.3x5,5	
C6P13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C6P15	2202-000797	70795075	C-CERAMIC,MLC-AXIAL;10NF,30%,16V,Y5S,TP,	
C702	2203-005571	BY130528	C-CER,CHIP;10000nF,+80-20%,6.3V,Y5V,-,20	
C703	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
C704	2401-000118	70796210	C-AL;1000uF,20%,10V,GP,TP,10x12.5,5	
C708A	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C822A	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,C0G,TP,1608	
CN01	3708-000270	70795501	CONNECTOR-FPC/FFC/PIC;33P,1.25MM,STRAIGH	
CN02	3708-000270	70795501	CONNECTOR-FPC/FFC/PIC;33P,1.25MM,STRAIGH	
CN03	3711-004379	BY634830	CONNECTOR-HEADER:BOX,4P,1R,2MM,STRAIGHT,	
CN04	3711-000827	BY634827	CONNECTOR-HEADER:BOX,2P,1R,2mm,STRAIGHT,	
CN1S01	3711-000203	BY634858	CONNECTOR-HEADER;1WALL,2P,1R,7.92MM,STRA	
CN301	3708-000391	70796387	CONNECTOR-FPC/FFC/PIC;10P,1.25MM,STRAIGH	
CN303	3708-001165	BY634023	CONNECTOR-FPC/FFC/PIC;6P,1.25MM,STRAIGHT	
CN303B	3809-001206	BY634415	CABLE-FLAT;30V,-20to+80C,140mm,6P,1.25mm	
CN3A02	AC37-00028A	BY634831	CONNECTOR-SOCKET;-X-11,T9.0,W8.5,PBT NT	
CN604	AC37-00027A	BY634826	CONNECTOR-HEADER;20045WS,X-11,T8.5,W17.4	
CN701	3711-004625	BY634422	CONNECTOR-HEADER;3WALL,8P,1R,2MM,STRAIGH	
D1P101	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D1P102	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D1P103	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D1P104	0402-001533	BY430120	DIODE-RECTIFIER;1N5408,1000V,3A,-,BK	
D1P105	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1P106	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1P107	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1P108	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1P130	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D1S05	0402-000012	BY430047	DIODE-RECTIFIER;UF4007,1KV,1A,DO-41,TP	
D1S06	0402-001196	BY430012	DIODE-RECTIFIER;1T5,600V,1A,TS-1,TP	
D1S07	0402-001195	BY430011	DIODE-RECTIFIER;F1T4,400V,1A,DO-204AC,TP	
D1S08	0402-001195	BY430011	DIODE-RECTIFIER;F1T4,400V,1A,DO-204AC,TP	
D1S09	0402-001195	BY430011	DIODE-RECTIFIER;F1T4,400V,1A,DO-204AC,TP	
D1S30	0404-001225	BY430112	DIODE-SCHOTTKY;SRAF560,60V,5000mA,ITO-22	
D1S31	0404-001225	BY430112	DIODE-SCHOTTKY;SRAF560,60V,5000mA,ITO-22	
D1S32	0404-001225	BY430112	DIODE-SCHOTTKY;SRAF560,60V,5000mA,ITO-22	
D1S33	0404-001225	BY430112	DIODE-SCHOTTKY;SRAF560,60V,5000mA,ITO-22	
D1S34	0402-001195	BY430011	DIODE-RECTIFIER;F1T4,400V,1A,DO-204AC,TP	
D1S35	0402-001194	BY430010	DIODE-RECTIFIER;SHG2D,200V,2A,-,TP	
D1S37	0402-001195	BY430011	DIODE-RECTIFIER;F1T4,400V,1A,DO-204AC,TP	
D1S39	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D301	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D603	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D620	0402-000127	70796385	DIODE-RECTIFIER;1N4002,100V,1A,DO-41,TP	
D688	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D701	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D702	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D703	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D704	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D705	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D706	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
D805	0401-000101	70795150	DIODE-SWITCHING;1N4148,75V,150MA,DO-35,T	
DT701	AK07-00017A	BY634844	LED DISPLAY;LTG-0377M,DVD-VR300,70,10,7,	
F1S01	3601-001123	BY634112	FUSE-CARTRIDGE;250V,1.6A,TIME-LAG,CERAMI	
FL3A01	2702-000166	70795862	INDUCTOR-RADIAL;47uH,5%,6.0x6.4mm	
H254	3809-001581	BY634835	FFC CABLE-FLAT;30V,80C,60mm,33P,1.25mm,U	
H254	3809-001581	BY634835	FFC CABLE-FLAT;30V,80C,60mm,33P,1.25mm,U	

	Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
△	IC1P01	AC14-12006N	70796345	IC-VOLT REGU;KA78R12,SIP,STICK	D-VR3SF Only
	IC1P02	AC14-12006N	70796345	IC-VOLT REGU;KA78R12,SIP,STICK	
	IC1P03	1203-003230	BY631243	IC-POS.FIXED REG.:G9105,TO-220F,4P,10.1	
	IC1P05	1203-003293	BY631244	IC-POS.FIXED REG.:G9205,TO-220F,4P,10.1	
	IC1P06	1203-003230	BY631243	IC-POS.FIXED REG.:G9105,TO-220F,4P,10.1	
	IC1S01	1203-003462	BY631282	IC-PWM CONTROLLER:STR-W6853N,TO-220,6P,1	
	IC1S02	0604-001028	BY530004	PHOTO-COUPLER;TR,50-600%,250mW,DIP-4,ST	
	IC1S03	AC14-12006D	70795271	IC;KA431Z,TO-92,TAPING	
	IC301	1204-002140	BY631205	IC-VIDEO PROCESS;LA71750EM-MPB-E,QFP,100	
	IC3S01	1204-001921	BY631190	IC-CHROMA;LA70100M,SOP,30P,375MIL,PLASTI	
	IC501	1204-001920	BY631189	IC-AUDIO PROCESSOR;LA72646M,QFP,80P,14x1	
	IC601	AC09-00274A	BY631286	IC MICOM;UPD78F4928GF-3BA,FRESH ROM,100	
	IC604	AC14-12006C	70795269	IC;KA7533,DIP,-	
	IC605	1103-001331	BY631281	IC-EEPROM;S524A60X51,2Kx8Bit,DIP,8P,9.2x	
	IC6P01	1204-001796	BY631284	IC-OSD PROCESSOR;LC74759JM-9820,MFP,24P,	
	IC701	1003-001561	BY631280	IC-LED DRIVER;PT6961,SOP,32P,300MIL,-,40	
	J330	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
	J905	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
	J910	2007-000029	70795513	R-CHIP;0ohm,5%,1/8W,TP,2012	
	△ △	J911	2007-000029	70795513	
J913		2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
J914		2007-000029	70795513	R-CHIP;0ohm,5%,1/8W,TP,2012	
L1P02		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L1P101		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L1S01		AC29-30050B	BY330056	FILTER LINE NOISE:-,400uH,-,AC250V,TR12.	
L1S02		AK29-00002A	BY330083	FILTER EMI;RECORDER,SQ2222,20mH,1	
L1S30		AH27-00039A	BY330081	COIL CHOKE;DR CHOKE(8*6),DVD-R2000,22uH,	
L1S31		AH27-00039A	BY330081	COIL CHOKE;DR CHOKE(8*6),DVD-R2000,22uH,	
L1S32		AC27-12001N	70796213	COIL CHOKE;10UH-15%,RA,K-30,Q80,150KHZ,-	
L301		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L301A		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L302		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L304		3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,,TP,,	
L370		2701-000113	70795159	INDUCTOR-AXIAL;100UH,5%,2534	
L3A01		2702-000120	70795171	INDUCTOR-RADIAL;15000uH,5%,6.2x7.4mm	
L3A02		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L3A03		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L3A70		2702-000120	70795171	INDUCTOR-RADIAL;15000uH,5%,6.2x7.4mm	
L3S01		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L501		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L502		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L602		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L603		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L605		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
L6P01		2702-000108	70795168	INDUCTOR-RADIAL;100uH,5%,6.0x6.4mm	
L6P03		2701-000160	70795162	INDUCTOR-AXIAL;22uH,5%,2434	
L6P05		2701-000165	BY330052	INDUCTOR-AXIAL;27uH,5%,2434	
L701		2701-000002	BY330009	INDUCTOR-AXIAL;100UH,10%,4298	
LD601		0601-001817	BY430114	LED-IR;SIDE-VIEW,2.5mm,75mW,6V,940,TR	
PT1SD1		AC26-00013L	BY634849	TRANS SWITCHING;EER4032,DVD-VR300E,-,FRE	
PT601		0604-001275	BY631213	PHOTO-INTERRUPTER:-,-,-,SNAP,TR	
PT602		0604-001275	BY631213	PHOTO-INTERRUPTER:-,-,-,SNAP,TR	
Q1P103		0505-001522	BY530083	FET-SILICON;FQP33N10,N,100V,33A,52mhom,1	
Q1P105		0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO	
Q1P106		0504-000142	70693084	TR-DIGITAL;KSR2001,PNP,300MW,4.7K/4.7K,T	
Q1P107	0501-000398	70795136	TR-SMALL SIGNAL;KSC945,NPN,250mW,TO-92,T		
Q1P108	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO		
Q1P109	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO		
Q1P110	0501-000362	BY530008	TR-SMALL SIGNAL;KSC2328A-Y,NPN,1000MW,TO		
Q302	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-		
Q3A01	0501-000398	70795136	TR-SMALL SIGNAL;KSC945,NPN,250mW,TO-92,T		

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
Q3A02	0501-000303	70795134	TR-SMALL SIGNAL;KSA733,PNP,250mW,TO-92,T	
Q3A03	0501-000442	70795142	TR-SMALL SIGNAL;KTC3203-Y,NPN,400mW,TO-9	
Q3A04	0501-000442	70795142	TR-SMALL SIGNAL;KTC3203-Y,NPN,400mW,TO-9	
Q3A05	0501-000442	70795142	TR-SMALL SIGNAL;KTC3203-Y,NPN,400mW,TO-9	
Q3A06	0501-000303	70795134	TR-SMALL SIGNAL;KSA733,PNP,250mW,TO-92,T	
Q601	0504-000129	70795815	TR-DIGITAL;KSR1104,NPN,200mW,47K/47K,SOT	
Q6P01	0501-000303	70795134	TR-SMALL SIGNAL;KSA733,PNP,250mW,TO-92,T	
Q6P02	0501-000303	70795134	TR-SMALL SIGNAL;KSA733,PNP,250mW,TO-92,T	
Q802	0504-000129	70795815	TR-DIGITAL;KSR1104,NPN,200mW,47K/47K,SOT	
Q803	0504-000129	70795815	TR-DIGITAL;KSR1104,NPN,200mW,47K/47K,SOT	
Q804	0504-000156	BY530075	TR-DIGITAL;KSR2103,PNP,200MW,22K/22K,SOT	
R1P102	2001-000008	70795014	R-CARBON;15KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1P104	2001-000449	70795020	R-CARBON;2.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P107	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1P108	2001-000812	BY230038	R-CARBON;5.6KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P109	2001-000812	BY230038	R-CARBON;5.6KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P121	2001-000362	70796067	R-CARBON;1500HM,5%,1/8W,AA,TP,1.8X3.2MM	
R1P122	2001-000449	70795020	R-CARBON;2.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1P123	2001-000405	70795607	R-CARBON;1800HM,5%,1/8W,AA,TP,1.8X3.2MM	
R1P124	2001-000062	70796173	R-CARBON;4700HM,5%,1/4W,AA,TP,2.4X6.4MM	
R1P131	2001-000855	BY230025	R-CARBON;5600HM,5%,1/4W,AA,TP,2.4X6.4MM	
R1S02	2006-000273	70796087	R-CEMENT;27KOHM,5%,2W,CA,BK,6.4X6.5X18M	
R1S03	2006-000273	70796087	R-CEMENT;27KOHM,5%,2W,CA,BK,6.4X6.5X18M	
R1S04	2006-000262	BY230170	R-CEMENT;2.7ohm,10%,2W,CB,TP,7.5x11x20.	
R1S05	2001-000319	70795318	R-CARBON;120KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S06	2001-001006	BZ230067	R-CARBON;820HM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S07	2001-000319	70795318	R-CARBON;120KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S08	2001-000319	70795318	R-CARBON;120KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S09	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S10	2001-000773	70795354	R-CARBON;470KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S11	2001-000577	70795506	R-CARBON;2KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S12	2001-000734	70795040	R-CARBON;4.7KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S13	2005-001198	BY230337	R-WIRE WOUND,NON:0.18ohm,1%,1W,AA,TP,4.3	
R1S14	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S15	2007-008711	BY230377	R-CHIP;1MOHM,5%,1/2W,TP,5025	
R1S31	2001-000780	70795039	R-CARBON;4700HM,5%,1/8W,AA,TP,1.8X3.2MM	
R1S32	2001-000221	BY230019	R-CARBON;1.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S35	2001-000221	BY230019	R-CARBON;1.2KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R1S36	2007-000515	BY230356	R-CHIP;2.7Kohm,1%,1/8W,TP,2012	
R1S37	2003-000148	BY230003	R-METAL OXIDE;100ohm,5%,2W,AE,TP,6x16mm	
R1S38	2008-001033	BY230265	R-FUSIBLE(S);10ohm,5%,2W,AF,TP,3.9x10mm	
R315	2007-000122	BY230294	R-CHIP;1.2Kohm,5%,1/10W,TP,1608	
R316	2007-001179	BY230305	R-CHIP;8.2Kohm,5%,1/10W,TP,1608	
R320	2007-000458	BY230372	R-CHIP;18Kohm,5%,1/10W,TP,1608	
R321	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R322	2007-000458	BY230372	R-CHIP;18Kohm,5%,1/10W,TP,1608	
R323	2007-000125	BY230296	R-CHIP;3.9Kohm,5%,1/10W,TP,1608	
R324	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
R325	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
R326	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
R327	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R328	2007-000122	BY230294	R-CHIP;1.2Kohm,5%,1/10W,TP,1608	
R329	2007-000080	BY230343	R-CHIP;2Kohm,5%,1/10W,TP,1608	
R330	2007-000087	BY230284	R-CHIP;6.8Kohm,5%,1/10W,TP,1608	
R331	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
R333	2007-001039	70795708	R-CHIP;56Kohm,5%,1/8W,TP,2012	
R334	2007-000123	BY230306	R-CHIP;1.5Kohm,5%,1/10W,TP,1608	
R335	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
R336	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R350	2007-000123	BY230306	R-CHIP;1.5Kohm,5%,1/10W,TP,1608	
R360	2007-001196	BY230309	R-CHIP;820Kohm,5%,1/10W,TP,1608	

D-VR3SF Only

D-VR3SF Only



Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
R372	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R373	2007-000093	BY230308	R-CHIP;20Kohm,5%,1/10W,TP,1608	
R374	2001-000290	70795006	R-CARBON;10KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R380	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
R3A04	2001-000221	BY230019	R-CARBON;1.2KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R3A05	2007-000616	BY230300	R-CHIP;24Kohm,5%,1/10W,TP,1608	
R3A06	2007-000539	BY230357	R-CHIP;200ohm,5%,1/10W,TP,1608	
R3A07	2007-000133	BY230297	R-CHIP;330Kohm,5%,1/10W,TP,1608	
R3A08	2007-000091	BY230286	R-CHIP;12Kohm,5%,1/10W,TP,1608	
R3A09	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R3A11	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
R3A12	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R3A13	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
R3A14	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R3A16	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R3A17	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
R3A18	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
R3A23	2007-000091	BY230286	R-CHIP;12Kohm,5%,1/10W,TP,1608	
R3A24	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R3A25	2001-000221	BY230019	R-CARBON;1.2KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R3A26	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R3A28	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
R3A50	2001-000800	70795044	R-CARBON;5.1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R3A51	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R3A60	2007-000704	BY230374	R-CHIP;3.6Kohm,5%,1/10W,TP,1608	
R3A70	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R3S01	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	D-VR3SF Only
R3S02	2001-000435	70795008	R-CARBON;1MOHM,5%,1/8W,AA,TP,1.8X3.2MM	D-VR3SF Only
R501	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R503	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R509	2007-000087	BY230284	R-CHIP;6.8Kohm,5%,1/10W,TP,1608	
R510	2007-000913	BY230302	R-CHIP;43Kohm,5%,1/10W,TP,1608	
R511	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R512	2001-000660	70795032	R-CARBON;33KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R517	2007-000087	BY230284	R-CHIP;6.8Kohm,5%,1/10W,TP,1608	
R518	2007-000913	BY230302	R-CHIP;43Kohm,5%,1/10W,TP,1608	
R545	2007-000512	BY230373	R-CHIP;2.4Kohm,5%,1/10W,TP,1608	
R546	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R547	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R570	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R571	2007-000098	BY230291	R-CHIP;56Kohm,5%,1/10W,TP,1608	
R608	2001-000864	70795047	R-CARBON;56KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R609	2001-000864	70795047	R-CARBON;56KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R610	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R611	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R614	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R615	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R617	2007-001038	BY230376	R-CHIP;56Kohm,1%,1/10W,TP,1608	
R620	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R621	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	D-VR3SF Only
R630	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R631	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R632	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R633	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R634	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R635	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R636	2001-000281	70795004	R-CARBON;100OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R637	2001-000290	70795006	R-CARBON;10KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R640	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R641	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	
R642	2001-000780	70795039	R-CARBON;470OHM,5%,1/8W,AA,TP,1.8X3.2MM	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
R647	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R651	2001-000010	70795052	R-CARBON;68KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R657	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R660	2001-000786	70795041	R-CARBON;47KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R661	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
R666	2001-000734	70795040	R-CARBON;4.7KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R667	2001-000734	70795040	R-CARBON;4.7KOHM,5%,1/8W,AA,TP,1.8X3.2M	
R668	2001-000780	70795039	R-CARBON;4700HM,5%,1/8W,AA,TP,1.8X3.2MM	
R669	2001-000780	70795039	R-CARBON;4700HM,5%,1/8W,AA,TP,1.8X3.2MM	
R670	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R671	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R672	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R673	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R674	2001-000290	70795006	R-CARBON;10KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R675	2001-000032	BY230164	R-CARBON;1800HM,5%,1/4W,AA,TP,2.4X6.4MM	
R676	2001-000633	70795029	R-CARBON;30KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R677	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R678	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R679	2007-000572	70795525	R-CHIP;220ohm,5%,1/8W,TP,2012	
R682	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R685	2007-000086	BY230283	R-CHIP;5.6Kohm,5%,1/10W,TP,1608	
R688	2007-000129	BY230307	R-CHIP;27Kohm,5%,1/10W,TP,1608	
R691	2007-000572	70795525	R-CHIP;220ohm,5%,1/8W,TP,2012	
R698	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R6P05	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R6P07	2007-000539	BY230357	R-CHIP;200ohm,5%,1/10W,TP,1608	
R6P08	2007-000118	BY230293	R-CHIP;390ohm,5%,1/10W,TP,1608	
R6P09	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
R6P10	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
R701	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R702	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
R703	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R704	2007-001010	BY230360	R-CHIP;51Kohm,5%,1/10W,TP,1608	
R711	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R802	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
R803	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
RM701	AC32-00006A	BY630162	MODULE REMOCON;TSOP2238WE1,38KHZ,-,5.08m	
S602	0603-001134	BY631212	PHOTO TR;- ,30V,4V,50mA,75mW,TRAY	
SW602	AC34-00006A	BY634846	SWITCH-REC;- ,,,,,,,,,,,,,,	
SW603	AC34-00005A	BY634845	SWITCH MODE;- ,,,,,,,,,,,,,,	
SW701	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW702	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW703	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW704	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW705	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW706	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW710	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
VA1S01	1405-001026	BY634022	VARIATOR;470V,600A,9x7mm, TP	
W177	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
W178	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
W205	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
W206	2001-000281	70795004	R-CARBON;1000HM,5%,1/8W,AA,TP,1.8X3.2MM	
W250	2001-000429	70795005	R-CARBON;1KOHM,5%,1/8W,AA,TP,1.8X3.2MM	
W253	3301-000297	BY330019	BEAD-AXIAL;25ohm,3.6x1.2x5.7mm,, TP,,	
XT301	2801-001397	BY633009	CRYSTAL-UNIT;4.433619MHz,20ppm,28-AAA,S,	
XT602	2801-003139	BY633010	CRYSTAL-UNIT;8MHz,50ppm,28-AAA,22pF,80oh	
ZD1P02	0403-001211	BY430015	DIODE-ZENER;MTZJ12B,11.8-12.3V,500MW,DO-	
ZD1P03	0403-000720	BY430013	DIODE-ZENER;MTZJ9.1B,8.57-9.01V,500MW,DO	
ZD1P04	0403-000717	BY430005	DIODE-ZENER;MTZJ5.1B,4.94-5.2V,500MW,DO-	
ZD401	0403-000390	70795272	DIODE-ZENER;UZP33B,31.4-34.6V,1000MW,DO-	
ZD801	0403-000297	BY430024	DIODE-ZENER;MTZ6.2B,5.96-6.27V,500MW,DO-	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
<b>P002</b>	<b>AK92-00429D</b>	<b>BY630418</b>	<b>ASSY PCB-MAIN DVD;DVD-VR300E,MAIN DVD P</b>	
AC101	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC104	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
AC105	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC28	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC29	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC30	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC816	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,C0G,TP,1608	
AC818	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,C0G,TP,1608	
AC820	2203-000783	BY130435	C-CER,CHIP;0.33nF,5%,50V,C0G,TP,1608	
AC821	2203-001554	BY130450	C-CER,CHIP;1.8nF,10%,50V,X7R,TP,1608	
AC822	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
AC823	2203-000783	BY130435	C-CER,CHIP;0.33nF,5%,50V,C0G,TP,1608	
AC824	2203-001554	BY130450	C-CER,CHIP;1.8nF,10%,50V,X7R,TP,1608	
AC831	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
AC891	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC892	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC908	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC911	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
AC912	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC913	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
AC914	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC915	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
AC917	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
AE1	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
AE2	2402-000202	BY130506	C-AL,SMD;100uF,20%,10V,WT,TP,6.6x6.6x5.	
AE3	2402-000179	BY130505	C-AL,SMD;47uF,20%,16V,GP,TP,6.6x6.6x5.4	
AIC1	1002-001294	BY631221	IC-D/A CONVERTER;PCM1742KE,24BIT,TSSOP,1	
AIC3	1203-002178	BY631234	IC-POS.FIXED REG.;1563,SOP,7P,173MIL,PL	
AIC81	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	
AIC82	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	
AIC9	1002-001387	BY631222	IC-A/D CONVERTER;PCM1802,24BIT,SSOP,20P,	
AJ1	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
AL5	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
AL6	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
AL7	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
AR1	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
AR10	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR11	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR12	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR13	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR14	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR15	2007-000120	BY230350	R-CHIP;680ohm,5%,1/10W,TP,1608	
AR16	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
AR2	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
AR3	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
AR4	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR5	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR6	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR7	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
AR8	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
AR801	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR802	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR803	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR804	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
AR805	2007-000122	BY230294	R-CHIP;1.2Kohm,5%,1/10W,TP,1608	
AR806	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR807	2007-000122	BY230294	R-CHIP;1.2Kohm,5%,1/10W,TP,1608	
AR808	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
AR809	2007-000080	BY230343	R-CHIP;2Kohm,5%,1/10W,TP,1608	
AR811	2007-000080	BY230343	R-CHIP;2Kohm,5%,1/10W,TP,1608	
AR812	2007-000080	BY230343	R-CHIP;2Kohm,5%,1/10W,TP,1608	
AR813	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR814	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
AR881	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
AR882	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
AR894	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
AR895	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
AR9	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
ATAR1	2011-000475	BY230366	R-NET;330HM,5%,1/16W,L,CHIP,8P,TP,32	
ATAR2	2011-000475	BY230366	R-NET;330HM,5%,1/16W,L,CHIP,8P,TP,32	
ATAR3	2011-000475	BY230366	R-NET;330HM,5%,1/16W,L,CHIP,8P,TP,32	
ATAR4	2011-000475	BY230366	R-NET;330HM,5%,1/16W,L,CHIP,8P,TP,32	
ATCN1	3708-001935	BY634823	CONNECTOR-FPC/FFC/PIC:40P,0.5mm,SMD-S,Sn	
C110	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C111	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C112	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C115	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C117	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C119	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C123	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
C124	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
C125	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C126	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C127	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C128	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C129	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C130	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C140	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C141	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C142	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C143	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C144	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C145	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C146	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C147	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C150	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C166	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
C167	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C168	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C169	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C171	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C173	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
C174	2402-001096	BY130508	C-AL,SMD;220UF,20%,16V,GP,TP,6.6X6.6X7.	
C177	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C178	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
C179	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C183	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C184	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C185	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C210	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C214	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
C215	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C217	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C218	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C219	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C220	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C222	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C223	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C224	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C225	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C226	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C227	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C228	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C230	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C231	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C232	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C78	2203-000746	BY130517	C-CER,CHIP;0.03NF,5%,50V,C0G,TP,1608	
C79	2203-000746	BY130517	C-CER,CHIP;0.03NF,5%,50V,C0G,TP,1608	
CA1	2402-001096	BY130508	C-AL,SMD;220UF,20%,16V,GP,TP,6.6X6.6X7.	
CA2	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
CC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
CL1	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
CL2	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
CL3	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
CN1	3710-002075	BY634832	CONNECTOR-SOCKET;30P,2R,2MM,SMD,SnPb,BLK	
CN2	3710-002075	BY634832	CONNECTOR-SOCKET;30P,2R,2MM,SMD,SnPb,BLK	
CN3	3711-005595	BY634833	CONNECTOR-SOCKET;BOX,12P,2R,2.0MM,SMD-S,	
CR1	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
CR2	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
CR3	2007-000083	BY230344	R-CHIP;3Kohm,5%,1/10W,TP,1608	
DC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC14	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC15	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC16	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC18	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC19	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC20	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC21	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC22	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC23	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC24	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC25	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
DC26	2203-000315	BY130441	C-CER,CHIP;0.12NF,5%,50V,C0G,TP,1608	
DC27	2203-000659	BY130515	C-CER,CHIP;0.27NF,5%,50V,C0G,TP,1608	
DC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC66	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC9	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DE1	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
DE2	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
DE3	2402-000007	BY130502	C-AL,SMD;22uF,20%,6.3V,GP,TP,4.3x4.3x5.	
DE4	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
DE6	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
DIC1	1205-002442	BY631249	IC-CODEC;DMN-8602,BGA,308P,27x27mm,PLAS	
DIC2	0801-002522	BY631215	IC-CMOS LOGIC;74VHC541,BUFFER/LINE DRIVE	
DIC3	1107-001273	BY631230	IC-FLASH MEMORY;29DL323,4Mx8/2Mx16,TSOP,	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
DIC4	1106-001471	BY631229	IC-SRAM:K6X8016T3B,512Kx16Bit,TSOP2,44	
DIC5	0801-002741	BY631218	IC-CMOS LOGIC:BU4053BCFV,MUX,SSOP,16P,17	
DIC6	0802-001115	BY631219	IC-CMOS LOGIC:74ALVCH16373,D LATCH,TSSOP	
DIC7	0801-002587	BY631216	IC-CMOS LOGIC:74LVX541,8BIT BUFFER/DRIVE	
DIC8	1103-001134	BY631225	IC-EEPROM:24C040,512x8,SOP8P,5.13x3.95m	
DL1	2007-000029	70795513	R-CHIP:0ohm,5%,1/8W,TP,2012	
DR1	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR10	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR11	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR2	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR21	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR28	2007-007332	BY230364	R-CHIP:1.18Kohm,1%,1/8W,TP,2012	
DR29	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR3	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR30	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR31	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR32	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR33	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR34	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR35	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR36	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR37	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR38	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR39	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR4	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR40	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR41	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR42	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR43	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR44	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR45	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR46	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR47	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR48	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR49	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR5	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR50	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR51	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR52	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR53	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR54	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR55	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR56	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR57	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR58	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR59	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR6	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR60	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR61	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR62	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR63	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR64	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR65	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR66	2007-000074	BY230276	R-CHIP:100ohm,5%,1/10W,TP,1608	
DR67	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR68	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
DR69	2007-000084	BY230282	R-CHIP:4.7Kohm,5%,1/10W,TP,1608	
DR7	2007-000071	BY230341	R-CHIP:22ohm,5%,1/10W,TP,1608	
DR71	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR72	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	
DR74	2007-000070	BY230274	R-CHIP:0ohm,5%,1/10W,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
DR75	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR76	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR77	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR78	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR79	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR8	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR80	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR81	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
DR82	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
DR84	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR85	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR86	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR87	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR88	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR89	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR9	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR90	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR91	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR92	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
DR95	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR96	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR97	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
DR98	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
FB23	2007-000029	70795513	R-CHIP;0ohm,5%,1/8W,TP,2012	
PC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC11	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC14	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC15	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC16	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC18	2203-001607	BY130451	C-CER,CHIP;0.22nF,5%,50V,NPO,-,1608	
PC19	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC20	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC3	2203-000384	BY130521	C-CER,CHIP;0.015NF,5%,50V,COG,TP,1608	
PC4	2203-000384	BY130521	C-CER,CHIP;0.015NF,5%,50V,COG,TP,1608	
PC5	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC7	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC9	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
PCB	AK41-00238A	BY630401	PCB MAIN-DVD;DVD-VR300,EPOXY,4,00,1.6T,1	
PE1	2402-000007	BY130502	C-AL,SMD;22uF,20%,6.3V,GP,TP,4.3x4.3x5.	
PE2	2402-000007	BY130502	C-AL,SMD;22uF,20%,6.3V,GP,TP,4.3x4.3x5.	
PE3	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
PE4	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
PE5	2402-000170	BY130503	C-AL,SMD;1uF,20%,50V,GP,TP,4.3x4.3x5.4,	
PIC1	1205-001988	BY631248	IC-DATA COMM./GEN.;TSB41AB1-PAP,QFP,64P,	
PL1	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
PL2	2007-000029	70795513	R-CHIP;0ohm,5%,1/8W,TP,2012	
PL3	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
PR1	3301-001419	BY330073	BEAD-SMD;- ,220,-,500,TP,-,0.3	
PR10	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
PR12	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR13	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR14	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR15	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR16	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
PR17	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR18	2007-000965	BY230303	R-CHIP;5.1Kohm,5%,1/10W,TP,1608	
PR19	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
PR2	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
PR20	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
PR21	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
PR22	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
PR23	2007-001056	BY230273	R-CHIP;6.2Kohm,5%,1/10W,TP,1608	
PR24	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
PR4	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
PR5	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
PR60	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
PR9	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
PRA1	2011-000002	BY230365	R-NET;220HM,5%,1/16W,L,CHIP,8P,TP,32	
PRA2	2011-000002	BY230365	R-NET;220HM,5%,1/16W,L,CHIP,8P,TP,32	
PY1	2801-004021	BY633022	CRYSTAL-SMD;24.576MHz,20ppm,28-AAN,12pF,	
R1	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,DA,TP,1608	
R213	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R214	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R215	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R216	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R217	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R218	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R219	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R220	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R221	3301-001309	BY330076	BEAD-SMD;47ohm,1.6x0.8x0.8mm,500mA,TP,-	
R222	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,DA,TP,1608	
R223	3301-001309	BY330076	BEAD-SMD;47ohm,1.6x0.8x0.8mm,500mA,TP,-	
R224	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,DA,TP,1608	
R225	3301-001309	BY330076	BEAD-SMD;47ohm,1.6x0.8x0.8mm,500mA,TP,-	
R226	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,DA,TP,1608	
R227	3301-001309	BY330076	BEAD-SMD;47ohm,1.6x0.8x0.8mm,500mA,TP,-	
R228	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R229	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R230	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R232	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R234	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R237	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R238	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R239	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R240	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R241	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,DA,TP,1608	
R242	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,DA,TP,1608	
R243	2007-001014	BY230361	R-CHIP;510HM,5%,1/10W,DA,TP,1608	
R246	2007-001044	BY230362	R-CHIP;56ohm,5%,1/10W,TP,1608	
R247	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R248	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
R67	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R68	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R69	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R70	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
RC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC5	2203-001683	BY130486	C-CER,CHIP;0.068nF,5%,50V,NP0,TP,1608	
RE1	2402-001096	BY130508	C-AL,SMD;220UF,20%,16V,GP,TP,6.6X6.6X7.	
RE2	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
RE3	2402-000007	BY130502	C-AL,SMD;22uF,20%,6.3V,GP,TP,4.3x4.3x5.	
RE4	2402-001237	BY130509	C-AL,SMD;330uF,##20%,6.3V,-,REEL,6.3X7.	
RIC1	1203-003182	BY631242	IC-POS.FIXED REG.;LP3965,TO-263,5P,10.1	



Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
RIC2	1203-002612	BY631236	IC-POS1.ADJUST REG.;3966,TO-263,5P,10.16	
RL1	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
RL2	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RL3	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RL5	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RL6	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RL7	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
RP1	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP10	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP12	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP14	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP15	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP17	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP18	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP19	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP20	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP21	2011-000002	BY230365	R-NET;22OHM,5%,1/16W,L,CHIP,8P,TP,32	
RP22	2011-000002	BY230365	R-NET;22OHM,5%,1/16W,L,CHIP,8P,TP,32	
RP23	2011-000002	BY230365	R-NET;22OHM,5%,1/16W,L,CHIP,8P,TP,32	
RP24	2011-000002	BY230365	R-NET;22OHM,5%,1/16W,L,CHIP,8P,TP,32	
RP25	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP26	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP27	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP28	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP29	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP3	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP30	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP31	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP34	2011-001194	BY230370	R-NET;51ohm,5%,1/16W,L,CHIP,8P,TP	
RP5	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RP7	2011-000686	BY230368	R-NET;56OHM,5%,1/16W,L,CHIP,8P,TP	
RR3	2007-000964	BY230007	R-CHIP;5.1Kohm,5%,1/8W,TP,2012	
RR4	2007-000300	70795516	R-CHIP;10Kohm,5%,1/8W,TP,2012	
TC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC14	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC16	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,TP,2012	
TC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC18	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,TP,2012	
TC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC20	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC21	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC23	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,TP,2012	
TC24	2203-002793	BY130032	C-CER,CHIP;1000nF,+80-20%,25V,Y5V,2012	
TC25	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC3	2203-001658	BY130485	C-CER,CHIP;0.047nF,5%,50V,NP0,TP,1608	
TC31	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC34	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC38	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC41	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC48	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC55	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC61	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC67	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC7	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,TP,2012	
TC74	2203-000646	BY130514	C-CER,CHIP;0.024NF,5%,50V,C0G,TP,1608	
TC75	2203-000646	BY130514	C-CER,CHIP;0.024NF,5%,50V,C0G,TP,1608	
TC76	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
TC78	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC80	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,TP,2012	
TC9	2203-000206	BY130352	C-CER,CHIP;100nF,10%,50V,X7R,TP,2012	
TC90	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC91	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TC92	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
TE2	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
TE3	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
TE4	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
TE5	2402-000176	BY130504	C-AL,SMD;10uF,20%,16V,GP,TP,4.3x4.3x5.4	
TIC1	1204-002235	BY631247	IC-PAL/NTSC DECODER:TVP5146PFP,PQFP,80P,	
TIC2	1203-002577	BY631235	IC-POS.FIXED REG.:MM1561J,SOP,7P,173MIL	
TL7	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
TL8	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
TL9	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
TNR50	2011-000475	BY230366	R-NET;330HM,5%,1/16W,L,CHIP,8P,TP,32	
TNR54	2011-000475	BY230366	R-NET;330HM,5%,1/16W,L,CHIP,8P,TP,32	
TNR60	2011-000515	BY230367	R-NET;4.7Kohm,5%,1/16W,L,CHIP,8P,TP	
TNR66	2011-000515	BY230367	R-NET;4.7Kohm,5%,1/16W,L,CHIP,8P,TP	
TR28	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
TR29	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
TR30	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
TR33	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
TR34	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
TR35	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
TR36	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
TR37	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
TR40	3301-001419	BY330073	BEAD-SMD:-,220,-,500,TP,-,0.3	
TR43	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
TR44	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
TR69	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
TR70	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
TR711	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
TR72	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
TR73	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
TR74	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
TR75	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
TX1	2801-004183	BY633026	CRYSTAL-SMD;14.31818MHZ,30PPM,28-AAN,16P	
U23	1105-001530	BY631228	IC-DRAM;K4H561638,16Mx16Bit,TSOPII,66P	
U24	1105-001530	BY631228	IC-DRAM;K4H561638,16Mx16Bit,TSOPII,66P	
U25	1203-003038	BY631238	IC-POSI.ADJUST REG.:LP2995,SO,8P,4.9x3.9	
U34	0401-000008	BY430108	DIODE-SWITCHING;DAN217,80V,100MA,SOT-23,	
Y3	2801-004182	BY633025	CRYSTAL-SMD;13.5MHZ,10PPM,28-AAN,24PF,60	
<b>P003</b>	<b>AK94-00037B</b> <b>AK94-00037A</b>	<b>BY630415</b> <b>BY630414</b>	<b>ASSY PCB-JACK;DVD-VR300E/XEU,ASSY SORT-J</b> <b>ASSY PCB-JACK;DVD-VR300E,ASSY SORT-JACK</b>	<b>D-VR3SB/D-VR3SG Only</b> <b>D-VR3SF Only</b>
AC14	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AC15	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC16	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC21	2203-000357	BY130442	C-CER,CHIP;0.15NF,5%,50V,COG,TP,1608	
AC22	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC23	2203-000125	BY130520	C-CER,CHIP;1.2nF,10%,50V,X7R,TP,1608,-	
AC24	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC25	2203-000357	BY130442	C-CER,CHIP;0.15NF,5%,50V,COG,TP,1608	
AC26	2203-000125	BY130520	C-CER,CHIP;1.2nF,10%,50V,X7R,TP,1608,-	
AC27	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
AC9	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
AD1	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
AD2	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
AD3	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
AD4	0401-000008	BY430108	DIODE-SWITCHING;DAN217,80V,100MA,SOT-23,	
AD5	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
AE11	2401-000909	BY130494	C-AL:22uF,20%,16V,GP,TP,5x5,2.5	
AE12	2401-002144	BY130049	C-AL:47uF,20%,16V,GP,TP,5x11,5	
AE13	2401-000909	BY130494	C-AL:22uF,20%,16V,GP,TP,5x5,2.5	
AE14	2401-001502	BY130535	C-AL:47uF,20%,16V,GP,TP,6.3x5,2.5	
AE15	2401-002112	BY130498	C-AL:10uF,20%,16V,GP,TP,4x7,2.5	
AE16	2401-003221	BY130499	C-AL:100uF,20%,16V,GP,TP,8X5,2.5	
AE3	2401-000909	BY130494	C-AL:22uF,20%,16V,GP,TP,5x5,2.5	
AE5	2401-000909	BY130494	C-AL:22uF,20%,16V,GP,TP,5x5,2.5	
AE6	2401-001249	BY130496	C-AL:4.7uF,20%,35V,GP,TP,4x5,2.5	
AE7	2401-001250	70796211	C-AL:4.7uF,20%,35V,GP,TP,4x5,5	
AIC4	1201-000163	BY631232	IC-OP AMP:4560,SOP,8P,173MIL,DUAL,100V/m	
AIC5	1201-000163	BY631232	IC-OP AMP:4560,SOP,8P,173MIL,DUAL,100V/m	
AL3	3301-001419	BY330073	BEAD-SMD;- ,220,-,500,TP,-,0.3	
AL4	3301-001419	BY330073	BEAD-SMD;- ,220,-,500,TP,-,0.3	
AQ1	0504-000113	BY530082	TR-DIGITAL:DTC144EUA,NPN,200MW,47K/47K,S	
AQ2	0504-000152	BY530078	TR-DIGITAL:KSR2101,PNP,200mW,4.7K/4.7K,S	
AQ3	0501-000341	BY530073	TR-SMALL SIGNAL:KSC1623-L,NPN,200mW,SOT-	
AQ4	0504-000113	BY530082	TR-DIGITAL:DTC144EUA,NPN,200MW,47K/47K,S	
AQ5	0504-000152	BY530078	TR-DIGITAL:KSR2101,PNP,200mW,4.7K/4.7K,S	
AQ6	0501-000341	BY530073	TR-SMALL SIGNAL:KSC1623-L,NPN,200mW,SOT-	
AQ7	0504-000129	70795815	TR-DIGITAL:KSR1104,NPN,200mW,47K/47K,SOT	
AQ8	0504-000156	BY530075	TR-DIGITAL:KSR2103,PNP,200MW,22K/22K,SOT	
AQ9	0501-000002	BY430105	TR-SMALL SIGNAL:KSA812,PNP,150MW,SOT-23,	
AR12	2007-000076	BY230310	R-CHIP:330ohm,5%,1/10W,TP,1608	
AR13	2007-000076	BY230310	R-CHIP:330ohm,5%,1/10W,TP,1608	
AR14	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
AR15	2007-000075	BY230277	R-CHIP:220ohm,5%,1/10W,TP,1608	
AR16	2007-000075	BY230277	R-CHIP:220ohm,5%,1/10W,TP,1608	
AR17	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	
AR18	2007-000075	BY230277	R-CHIP:220ohm,5%,1/10W,TP,1608	
AR28	2007-000090	BY230285	R-CHIP:10Kohm,5%,1/10W,TP,1608	
AR29	2007-000075	BY230277	R-CHIP:220ohm,5%,1/10W,TP,1608	
AR30	2007-000075	BY230277	R-CHIP:220ohm,5%,1/10W,TP,1608	
AR31	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	
AR32	2007-000075	BY230277	R-CHIP:220ohm,5%,1/10W,TP,1608	
AR33	2007-000132	BY230354	R-CHIP:180Kohm,5%,1/10W,TP,1608	
AR34	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR35	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR36	2007-000074	BY230276	R-CHIP:100ohm,5%,1/10W,TP,1608	
AR37	2007-000132	BY230354	R-CHIP:180Kohm,5%,1/10W,TP,1608	
AR38	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR39	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR40	2007-000074	BY230276	R-CHIP:100ohm,5%,1/10W,TP,1608	
AR41	2007-001179	BY230305	R-CHIP:8.2Kohm,5%,1/10W,TP,1608	
AR42	2007-000084	BY230282	R-CHIP:4.7Kohm,5%,1/10W,TP,1608	
AR43	2007-000092	BY230287	R-CHIP:15Kohm,5%,1/10W,TP,1608	
AR44	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR45	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR46	2007-001179	BY230305	R-CHIP:8.2Kohm,5%,1/10W,TP,1608	
AR47	2007-000084	BY230282	R-CHIP:4.7Kohm,5%,1/10W,TP,1608	
AR48	2007-000092	BY230287	R-CHIP:15Kohm,5%,1/10W,TP,1608	
AR49	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR50	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR52	2007-000078	BY230279	R-CHIP:1Kohm,5%,1/10W,TP,1608	
AR54	2007-000102	BY230292	R-CHIP:100Kohm,5%,1/10W,TP,1608	
AR55	2007-000077	BY230278	R-CHIP:470ohm,5%,1/10W,TP,1608	
AZ1	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
AZ2	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
AZ3	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
AZ4	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
BR2	2007-000076	BY230310	R-CHIP;330ohm,5%,1/10W,TP,1608	
BT501	AC43-12002P	BY634817	BATTERY:VL2330-1HF,3V,OD23XH3.0,	
C401	2401-002144	BY130049	C-AL;47uF,20%,16V,GP,TP,5x11,5	
C402	2203-000604	BY130525	C-CER,CHIP;22nF,10%,25V,X7R,TP,1608	
C403	2401-002144	BY130049	C-AL;47uF,20%,16V,GP,TP,5x11,5	
C404	2401-001077	BY130431	C-AL;330nF,20%,50V,GP,TP,4x7mm,5mm	
C404A	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C405	2401-002438	BY130472	C-AL;47uF,20%,50V,WT,TP,6.3x11,5	
C406	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C407	2401-002144	BY130049	C-AL;47uF,20%,16V,GP,TP,5x11,5	D-VR3SB/D-VR3SG Only
C409	2401-002299	BY130136	C-AL;4.7uF,20%,50V,GP,TP,5x7,5	D-VR3SB/D-VR3SG Only
C410	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C4N01	2203-000140	BY130459	C-CER,CHIP;1.5nF,10%,50V,X7R,TP,1608,-	
C4N02	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C4N03	2203-001607	BY130451	C-CER,CHIP;0.22nF,5%,50V,NPO,-,1608	
C4N04	2401-000665	BY130424	C-AL;2.2uF,20%,50V,GP,TP,3.5x5,5	
C4N05	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C4N06	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C4N07	2203-001656	BY130453	C-CER,CHIP;0.47nF,5%,50V,NPO,TP,1608	
C4N08	2203-000140	BY130459	C-CER,CHIP;1.5nF,10%,50V,X7R,TP,1608,-	
C4N09	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C4N10	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C4N11	2401-002186	BY130536	C-AL;3.3UF,20%,50V,GP,BK,4X5,2.5	
C4N12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C4N13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C4N14	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C4N15	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C4N16	2401-002144	BY130049	C-AL;47uF,20%,16V,GP,TP,5x11,5	
C4N17	2203-001656	BY130453	C-CER,CHIP;0.47nF,5%,50V,NPO,TP,1608	
C4N18	2203-001656	BY130453	C-CER,CHIP;0.47nF,5%,50V,NPO,TP,1608	
C4N19	2203-001658	BY130485	C-CER,CHIP;0.047nF,5%,50V,NPO,TP,1608	
C4N21	2203-000160	BY130524	C-CER,CHIP;0.0015NF,0.25PF,50V,COG,TP,16	
C4N22	2203-000160	BY130524	C-CER,CHIP;0.0015NF,0.25PF,50V,COG,TP,16	
C4N23	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	
C4N24	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	
C4N25	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C4N30	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C6P01	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C6P04	2203-000681	BY130445	C-CER,CHIP;0.027NF,5%,50V,COG,TP,1608	
C6P05	2203-000681	BY130445	C-CER,CHIP;0.027NF,5%,50V,COG,TP,1608	
C6P06	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
C6P07	2401-001249	BY130496	C-AL;4.7uF,20%,35V,GP,TP,4x5,2.5	
C6P08	2203-001071	BY130465	C-CER,CHIP;0.056NF,5%,50V,COG,TP,1608	
C6P10	2203-005065	BY130479	C-CER,CHIP;1000nF,+80-20%,10V,Y5V,-,1608	
C6P11	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
C6P12	2401-003221	BY130499	C-AL;100uF,20%,16V,GP,TP,8X5,2.5	
C6P13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C6P15	2203-001140	BY130526	C-CER,CHIP;68nF,10%,16V,X7R,TP,1608	
C800	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C801	2401-002144	BY130049	C-AL;47uF,20%,16V,GP,TP,5x11,5	
C802	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C803	2401-001502	BY130535	C-AL;47uF,20%,16V,GP,TP,6.3x5,2.5	
C804	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C805	2203-000975	BY130484	C-CER,CHIP;47nF,10%,25V,X7R,TP,1608,-	
C805B	2203-005571	BY130528	C-CER,CHIP;10000nF,+80-20%,6.3V,Y5V,-,20	
C806	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C806B	2203-005571	BY130528	C-CER,CHIP;10000nF,+80-20%,6.3V,Y5V,-,20	
C807	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C808	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
C809	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C810	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C813	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C814	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C817	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C818	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C819	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C819B	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C820	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C820B	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C821	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C822	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C824	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C824B	2203-001697	BY130487	C-CER,CHIP;0.082nF,5%,50V,NP0,TP,1608	
C825	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C825A	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C825B	2203-005571	BY130528	C-CER,CHIP;10000nF,+80-20%,6.3V,Y5V,-,20	
C826	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C826A	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C826B	2203-005571	BY130528	C-CER,CHIP;10000nF,+80-20%,6.3V,Y5V,-,20	
C827	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
C828A	0403-001083	BY430111	DIODE-ZENER:UDZ9.1B,8.85-9.23V,200MW,UMD	
C829	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C830	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C831	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C832	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C833	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C833A	2203-000998	BY130446	C-CER,CHIP;0.047NF,5%,50V,COG,TP,1608	
C833J	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C834	2203-000236	BY130439	C-CER,CHIP;0.1NF,5%,50V,COG,TP,1608	
C835	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
C835A	2401-001249	BY130496	C-AL;4.7uF,20%,35V,GP,TP,4x5,2.5	
C835J	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
C836	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C836A	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C836J	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
C837	2401-002112	BY130498	C-AL;10uF,20%,16V,GP,TP,4x7,2.5	
C838	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C839	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C841	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
C842	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C843	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C844	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C845	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C846	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
C853	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
C854	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
C901	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
C902	2401-000414	BY130273	C-AL;10uF,20%,16V,GP,TP,4x7,5	
CE76	2401-003480	BY130339	C-AL;1000UF,20%,10V,LZ,TP,10X16MM,5	
CN3	3711-005612	BY634828	CONNECTOR-HEADER:BOX,30P,2R,2mm,STRAIGHT	
CN4	3711-005612	BY634828	CONNECTOR-HEADER:BOX,30P,2R,2mm,STRAIGHT	
CN5	AC37-00027A	BY634826	CONNECTOR-HEADER:20045WS,X-11,T8.5,W17.4	
CNC1	2203-001697	BY130487	C-CER,CHIP;0.082nF,5%,50V,NP0,TP,1608	
CNL1	3301-001419	BY330073	BEAD-SMD;- ,220,-,500,TP,-,0.3	
CNL2	3301-001419	BY330073	BEAD-SMD;- ,220,-,500,TP,-,0.3	
CNR1	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR11	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR12	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR13	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR14	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
CNR15	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR16	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR17	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR18	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR19	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR20	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR21	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR22	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR23	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR24	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR25	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR26	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR27	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR28	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR3	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
CNR30	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR35	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR36	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR37	3301-001419	BY330073	BEAD-SMD;-220,-,500,TP,-,0.3	
CNR37A	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR38	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR39	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR4	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
CNR40	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR5	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR6	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR7	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CNR9	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CS01	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
CS02	2401-002144	BY130049	C-AL;47uF,20%,16V,GP,TP,5x11,5	
CS04	2401-000415	BY130492	C-AL;10uF,20%,16V,GP,TP,5x11,5	
CVL1	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CVL2	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CVL3	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
D4N01	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
D4N02	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
D501	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
D6P01	0407-000114	BY430113	DIODE-ARRAY;DAN202K,80V,100mA,CA2-3,SOT-	
DOC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DOC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DOC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DOE1	2401-000598	BY130042	C-AL;1uF,20%,50V,GP,TP,4x7,5	
DOE2A	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
DOIC1	AH14-10004R	BY631252	IC:M74HCU04,SOP,TAPE 14P	
DOIC2	3707-001060	BY634799	CONNECTOR-OPTICAL;PLUG,GP1FA550TZ,6DB,2.	
DOL1	2901-001273	BY330077	FILTER-EMI SMD;50V,2A,-,220pF,3.2x1.6x0.	
DOL2	3301-001419	BY330073	BEAD-SMD;-220,-,500,TP,-,0.3	
DOL3	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
DOL4	3301-001419	BY330073	BEAD-SMD;-220,-,500,TP,-,0.3	
DOR1	2007-000076	BY230310	R-CHIP;330ohm,5%,1/10W,TP,1608	
DOR2	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
DOR3	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
DOZ1	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
DOZ2	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
DVR1	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DVR2	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DVR3	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DVR4	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DVR5	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
DVR6	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
DVR7	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
DVR8	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
FJACK1	3708-000249	BY634821	CONNECTOR-FPC/FFC/PIC;27P,1.25MM,STRAIGH	
FVR1	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
FVR2	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
FVR3	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
FVR4	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
FVR5	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
FVR6	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
FVR7	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
IC4N01	1204-001765	BY631149	IC-AUDIO PROCESSOR:MSP3417D(PQFP),PQFP,4	
IC6P01	1204-001794	BY631157	IC-AUDIO PROCESSOR:LC74775NM-9808,MPF,30	
IC801	AC14-12015T	BY631278	IC:SV1274/LA7274M,QFP,64PIN,-,-	
JACK1	3722-002206	BY634848	JACK-PIN;6P,SN/NI,RD/WH/BL,RD/WH/YL,ANG	
JL1	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
JL2	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
JP1	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
L401	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
L4N01	2703-000411	BY330089	INDUCTOR-SMD;4.7uH,20%,3225	
L4N02	2703-000002	BY330080	INDUCTOR-SMD;100uH,10%,3225	
L4N03	2703-000411	BY330089	INDUCTOR-SMD;4.7uH,20%,3225	
L4N04	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
L6P01	2703-000002	BY330080	INDUCTOR-SMD;100uH,10%,3225	
L6P03	2703-000403	BY330088	INDUCTOR-SMD;22uH,10%,3225	
L6P05	2702-000144	70795859	INDUCTOR-RADIAL;27uH,5%,6.0x6.4mm	
L801	2703-000002	BY330080	INDUCTOR-SMD;100uH,10%,3225	
L802	2703-000002	BY330080	INDUCTOR-SMD;100uH,10%,3225	
L803	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L804	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L805	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L806	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L807	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L808	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L809	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L810	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L811	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L812	2703-000367	BY330087	INDUCTOR-SMD;33uH,5%,2520	
L814	3301-001419	BY330073	BEAD-SMD;- ,220,- ,500,TP,- ,0.3	
L901	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
L902	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
L903	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
LS01	2703-000002	BY330080	INDUCTOR-SMD;100uH,10%,3225	
MCON1	3708-000270	70795501	CONNECTOR-FPC/FFC/PIC;33P,1.25MM,STRAIGH	
MCON2	3708-000270	70795501	CONNECTOR-FPC/FFC/PIC;33P,1.25MM,STRAIGH	
PC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PE3	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
PE4	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
PE5	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
PE6	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
PE7	2401-002165	BY130280	C-AL;100uF,20%,16V,GP,TP,6.3x7,5	
PL3	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
PL4	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
PL6	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
PL7	2007-000033	70693337	R-CHIP;0ohm,5%,1/4W,TP,3216	
Q401	0501-000002	BY430105	TR-SMALL SIGNAL:KSA812,PNP,150MW,SOT-23,	D-VR3SB/D-VR3SG Only
Q6P02	0501-000002	BY430105	TR-SMALL SIGNAL:KSA812,PNP,150MW,SOT-23,	
Q6P04	0501-000341	BY530073	TR-SMALL SIGNAL:KSC1623-L,NPN,200mW,SOT-	
Q806	0504-000152	BY530078	TR-DIGITAL;KSR2101,PNP,200mW,4.7K/4.7K,S	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
Q809	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
Q810	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
Q810J	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
QS01	0501-000002	BY430105	TR-SMALL SIGNAL;KSA812,PNP,150MW,SOT-23,	
QS02	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
QS03	0501-000341	BY530073	TR-SMALL SIGNAL;KSC1623-L,NPN,200mW,SOT-	
R201	2007-000256	BY230371	R-CHIP;1.6Kohm,1%,1/10W,TP,1608	
R202	2007-000256	BY230371	R-CHIP;1.6Kohm,1%,1/10W,TP,1608	
R301	2007-000122	BY230294	R-CHIP;1.2Kohm,5%,1/10W,TP,1608	
R302	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R401	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	D-VR3SB/D-VR3SG Only
R401A	2007-000450	BY230299	R-CHIP;180ohm,5%,1/10W,TP,1608	
R402	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R402A	2007-000450	BY230299	R-CHIP;180ohm,5%,1/10W,TP,1608	
R403	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R404	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R406	2007-001010	BY230360	R-CHIP;51Kohm,5%,1/10W,TP,1608	D-VR3SB/D-VR3SG Only
R408	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	D-VR3SB/D-VR3SG Only
R440	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	D-VR3SB/D-VR3SG Only
R441	2007-000116	BY230349	R-CHIP;120ohm,5%,1/10W,TP,1608	D-VR3SB/D-VR3SG Only
R4N01	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R4N02	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R4N03	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R4N04	2007-000129	BY230307	R-CHIP;27Kohm,5%,1/10W,TP,1608	
R4N05	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R4N06	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R4N07	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R6P01	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R6P02	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R6P03	2007-000081	BY230281	R-CHIP;2.7Kohm,5%,1/10W,TP,1608	
R6P04	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R6P05	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
R6P06	2007-000086	BY230283	R-CHIP;5.6Kohm,5%,1/10W,TP,1608	
R6P08	2007-000821	BY230375	R-CHIP;390ohm,1%,1/10W,TP,1608	
R6P12	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
R6P13	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
R6P14	2007-000123	BY230306	R-CHIP;1.5Kohm,5%,1/10W,TP,1608	
R801A	2007-000116	BY230349	R-CHIP;120ohm,5%,1/10W,TP,1608	
R805	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R806	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R806B	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
R807	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R807A	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R807J	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R808	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R808A	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R809	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R810	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R811	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R813	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R813A	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
R814	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R814B	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
R815	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R816	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R817	2007-000450	BY230299	R-CHIP;180ohm,5%,1/10W,TP,1608	
R818A	2007-000450	BY230299	R-CHIP;180ohm,5%,1/10W,TP,1608	
R819A	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R820	2007-000643	BY230325	R-CHIP;270ohm,5%,1/10W,TP,1608	
R821	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
R821A	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	



Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
R822	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
R822A	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R822B	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
R839	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R841	2007-000119	BY230332	R-CHIP;560ohm,5%,1/10W,TP,1608	
R842	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R842J	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
R854	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
R855	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
R856	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
R900	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
R901	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
RS01	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
RS02	2007-000125	BY230296	R-CHIP;3.9Kohm,5%,1/10W,TP,1608	
RS03	2007-000094	BY230288	R-CHIP;22Kohm,5%,1/10W,TP,1608	
RS04	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
RS05	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
RS06	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
RS07	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
RS08	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
RS09	2007-000125	BY230296	R-CHIP;3.9Kohm,5%,1/10W,TP,1608	
RS10	2007-000077	BY230278	R-CHIP;470ohm,5%,1/10W,TP,1608	
SCART	3722-001345	BY631287	JACK-SCART;42P/2R,-,SN,BLK,-	
SJACK	3722-001375	BY634838	JACK-DIN;4P,-,NI,BLK,-	
SVL1	3301-001419	BY330073	BEAD-SMD;-,.220,-,500,TP,-,0.3	
SVL2	3301-001419	BY330073	BEAD-SMD;-,.220,-,500,TP,-,0.3	
TM401	AC40-00029A	BY633021	TM BLOCK;TCMK0601PD20A,PAL B/G + I + D/	D-VR3SB/D-VR3SG Only
TM401	AC40-00031A	BY630409	TM BLOCK;TCPL0601PD20A,PAL B/G + SECAM,	D-VR3SF Only
VC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC13	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,COG,TP,1608	
VC14	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
VC15	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
VC16	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,COG,TP,1608	
VC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC18	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,COG,TP,1608	
VC50	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC9	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VDR1	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR2	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR3	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR4	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR5	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VDR6	2007-000040	BY230339	R-CHIP;150ohm,1%,1/10W,TP,1608	
VE1	2401-003221	BY130499	C-AL;100uF,20%,16V,GP,TP,8X5,2.5	
VE2	2401-000909	BY130494	C-AL;22uF,20%,16V,GP,TP,5x5,2.5	
VE4	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
VE5	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
VE6	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
VE7	2401-001479	BY130015	C-AL;470uF,20%,10V,GP,TP,6.3*11mm,5	
VIC1	1204-001978	BY631245	IC-VIDEO PROCESS;LA73054,-,36P,-,SSOP,7V	
VL1	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
VL2	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
VL3	3301-000314	BY330074	BEAD-SMD;120ohm,1.6x0.8x0.8mm,150mA,,,,	
VL6	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
VR30	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
VR31	2007-001167	BY230304	R-CHIP;75ohm,5%,1/10W,TP,1608	
VR49	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
VR51	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
VR53	2007-001164	BY230333	R-CHIP;75ohm,1%,1/10W,TP,1608	
VR54	2007-001164	BY230333	R-CHIP;75ohm,1%,1/10W,TP,1608	
VR55	2007-001164	BY230333	R-CHIP;75ohm,1%,1/10W,TP,1608	
VSEL1	1204-001748	BY631283	IC-SELECTOR;MM1503XN,SOP,6P,63MIL,PLASTI	
VZ1	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ10	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ2	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ3	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ4	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ5	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ6	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ7	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ8	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
VZ9	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
W205	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
W206	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
W2095	2007-000076	BY230310	R-CHIP;330ohm,5%,1/10W,TP,1608	
W2198	2007-000076	BY230310	R-CHIP;330ohm,5%,1/10W,TP,1608	
W225	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
XT4N01	2801-004096	BY631285	CRYSTAL-UNIT;18.432MHZ,20PPM,28-AAA,16PF	
ZD807	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD809	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD811	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD851	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD852	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD853	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD854	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZD863	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZDS806	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
ZDS810	0403-001083	BY430111	DIODE-ZENER;UDZ9.1B,8.85-9.23V,200MW,UMD	
<b>P005</b>	<b>AK94-00045A</b>	<b>BY630448</b>	<b>ASSY SORT-FUNCTION;DVD-VR300E,FUNCTION</b>	
C701	2301-001679	BY130530	C-FILM,PEF;2.2nF,5%,50V,TP,5.8x3x7mm,-	
C702	2301-001679	BY130530	C-FILM,PEF;2.2nF,5%,50V,TP,5.8x3x7mm,-	
L701	2702-000142	70795856	INDUCTOR-RADIAL;22uH,5%,6.0x6.4mm	
L702	2702-000142	70795856	INDUCTOR-RADIAL;22uH,5%,6.0x6.4mm	
SW710	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW712	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW713	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW714	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW715	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
AVIO	3722-002106	BY634840	JACK-PIN;3P+1P,SN/NI,BLK,ANGLE	
AVIO1A	AK63-00158A	BY731629	GROUND-AV JACK;DVD-VR300,PBS,T0.2,W156,L	
CN7	3722-002118	BY634839	JACK-IEEE1394;4P,NI,BLK,ANGLE,IEEE1394	
FJACK2	3708-000249	BY634821	CONNECTOR-FPC/FFC/PIC;27P,1.25MM,STRAIGH	
FJACKB	3809-001338	BY634818	CABLE-FLAT;30V,80C,120mm,27P,1.25mm,UL28	
<b>P007</b>	<b>AK92-00554B</b>	<b>BY630419</b>	<b>ASSY PCB-KEY;D-VR3TB/TSB,ASSY PCB KEY</b>	
SW709	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW721	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
SW722	3404-001182	BY632011	SWITCH-TACT;DC12V,50MA,100GF,6.0X6.0X5.0	
CN702	3710-001626	BY634423	CONNECTOR-SOCKET;8P,1R,2mm,ANGLE,SN	
			<b>ASSY-RECORDER DECK;-DP-R1,ASSY RECORDER</b>	<b>S.N.A</b>
CB1	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CB2	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
CC11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
CC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
CC13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	

[illegible]

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
CC84	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
CC85	2203-000560	BY130523	C-CER,CHIP;220nF,+80-20%,25V,Y5V,TP,1608	
CC9	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
CIC1	AK13-00008A	BY631273	IC ASIC:-,-,256PIN,+3.3V,-40TO85C,LQFP	
CIC2	AK13-00012A	BY731641	PLD:EPM3064A,TQFP,44	
CIC3	1209-001550	BY631250	IC-PLL/SYNTHESIZER;TLC2933IPWR,SOP,14P,5	
CL3	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
CL4	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
CON1	3708-001915	BY634824	CONNECTOR-FPC/FFC/PIC;54P,0.5MM,SMD-A,SN	
CON2	3708-001916	BY634820	CONNECTOR-FPC/FFC/PIC;20P,0.5MM,SMD-A,SN	
CON3	3708-001878	BY634825	CONNECTOR-FPC/FFC/PIC;6P,1MM,SMD-A,SNPB,	
CON4	3708-001331	BY634822	CONNECTOR-FPC/FFC/PIC;40P,0.5MM,SMD-A,SN	
CR1	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
CR10	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
CR11	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
CR15	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
CR16	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
CR17	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
CR18	2007-000121	BY230351	R-CHIP;820ohm,5%,1/10W,TP,1608	
CR19	2007-000119	BY230332	R-CHIP;560ohm,5%,1/10W,TP,1608	
CR2	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
CR20	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
CR26	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
CR28	2007-000116	BY230349	R-CHIP;120ohm,5%,1/10W,TP,1608	
CR29	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CR3	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
CR30	2007-001010	BY230360	R-CHIP;51Kohm,5%,1/10W,TP,1608	
CR31	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
CR34	2007-000088	BY230345	R-CHIP;7.5Kohm,5%,1/10W,TP,1608	
CR35	2007-001157	BY230363	R-CHIP;750ohm,5%,1/10W,TP,1608	
CR36	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
CR37	2007-000072	BY230275	R-CHIP;47ohm,5%,1/10W,TP,1608	
CR38	2007-000072	BY230275	R-CHIP;47ohm,5%,1/10W,TP,1608	
CR4	2007-000074	BY230276	R-CHIP;100ohm,5%,1/10W,TP,1608	
CR5	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CR6	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CR7	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CR8	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
CR9	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DC1	2203-000332	BY130461	C-CER,CHIP;0.012NF,5%,50V,C0G,TP,1608	
DC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC11	2203-000332	BY130461	C-CER,CHIP;0.012NF,5%,50V,C0G,TP,1608	
DC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC13	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC14	2203-000405	BY130463	C-CER,CHIP;0.18NF,5%,50V,C0G,TP,1608	
DC15	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC16	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC19	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC20	2203-000140	BY130459	C-CER,CHIP;1.5nF,10%,50V,X7R,TP,1608,-	
DC25	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC26	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC27	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC29	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC30	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC32	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC33	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC36	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC37	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC38	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
DC39	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC41	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC42	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC44	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC45	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC47	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC49	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC51	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC53	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC55	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC57	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC58	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC59	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC60	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC62	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
DC63	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC64	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,C0G,TP,1608	
DC65	2203-000715	BY130516	C-CER,CHIP;3.3nF,10%,50V,X7R,TP,1608,-	
DC66	2203-000715	BY130516	C-CER,CHIP;3.3nF,10%,50V,X7R,TP,1608,-	
DC67	2203-000715	BY130516	C-CER,CHIP;3.3nF,10%,50V,X7R,TP,1608,-	
DC68	2203-000715	BY130516	C-CER,CHIP;3.3nF,10%,50V,X7R,TP,1608,-	
DC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC70	2203-000715	BY130516	C-CER,CHIP;3.3nF,10%,50V,X7R,TP,1608,-	
DC71	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
DC77	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC78	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
DC79	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DC9	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
DIC1	AK13-00009A	BY631274	IC ASIC;-,-,256PIN,+3.3V,-40TO85C,LQFP	
DIC2	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	
DIC3	0801-002694	BY631217	IC-CMOS LOGIC;74VHC4053,ANALOG MULTILPEX	
DR12	2007-000109	BY130423	R-CHIP;1Mohm,5%,1/10W,TP,1608	
DR13	2007-000072	BY230275	R-CHIP;47ohm,5%,1/10W,TP,1608	
DR14	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
DR15	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR16	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
DR17	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR22	2007-000539	BY230357	R-CHIP;200ohm,5%,1/10W,TP,1608	
DR25	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR26	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR27	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR28	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR29	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
DR30	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
DR31	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR32	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
DR33	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
DR36	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
DR37	2007-000082	BY230233	R-CHIP;3.3Kohm,5%,1/10W,TP,1608	
DR39	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR43	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
DR44	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
DR45	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
MC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC11	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC14	2203-000815	BY130476	C-CER,CHIP;0.033nF,5%,50V,C0G,TP,1608	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
MC15	2203-000815	BY130476	C-CER,CHIP;0.033NF,5%,50V,COG,TP,1608	
MC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC20	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
MC21	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC22	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC23	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC5	2203-000626	BY130444	C-CER,CHIP;0.022nF,5%,50V,COG,TP,1608	
MC6	2203-000626	BY130444	C-CER,CHIP;0.022nF,5%,50V,COG,TP,1608	
MC7	2203-000626	BY130444	C-CER,CHIP;0.022nF,5%,50V,COG,TP,1608	
MC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
MC9	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
MIC1	AK09-00051A	BY631275	IC MICOM;-,-,-,0.3 ~ +3.8V,30Mhz,-,-,2	
MIC3	1107-001419	BY631231	IC-FLASH MEMORY;49BV8192A,1Mx8/512Kx16,T	
MIC5	1203-003177	BY631241	IC-VOL. DETECTOR;BD5326G,SSOP,5P,2.9x1.6	
MLL1	2703-000398	BY330078	INDUCTOR-SMD;10uH,10%,3225	
MR11	2007-000402	BY230314	R-CHIP;150ohm,5%,1/10W,TP,1608	
MR13	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
MR14	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
MR15	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
MR16	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
MR22	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
MR25	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
MR28	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
MR29	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
MR31	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
MR35	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
MR37	2007-000104	BY230346	R-CHIP;150Kohm,5%,1/10W,TP,1608	
MY1	2801-004074	BY633023	CRYSTAL-SMD;40MHz,50ppm,28-AAN,18pF,30oh	
PC1	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
PC11	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
PC12	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
PC14	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
PC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC24	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
PC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC4	2402-001042	BY130507	C-AL,SMD;100uF,20%,16V,GP,TP,6.6x6.6x5.	
PC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PC7	2404-000256	BY130511	C-TA,CHIP;47UF,20%,16V,GP,TP,7343	
PC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
PCN	3711-005477	BY634829	CONNECTOR-HEADER;BOX,4P,1R,2mm,SMD-A,Sn+	
PIC1	1203-003175	BY631239	IC-MULTI REG.;BA33C25HFP,HRP,5P,9.39X8MM	
PIC2	1203-003176	BY631240	IC-MULTI REG.;BA33C18HFP,HRP,5P,9.39X8MM	
PL1	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
PL2	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
PL3	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
PL4	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
PL5	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
RC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC10	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
RC11	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC12	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC13	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC14	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC15	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
RC16	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC18	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
RC19	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC20	2203-000236	BY130439	C-CER,CHIP;0.1nF,5%,50V,C0G,TP,1608	
RC21	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC22	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC23	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC25	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC26	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC27	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC28	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC29	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC30	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC31	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC32	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
RC33	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
RC34	2203-000626	BY130444	C-CER,CHIP;0.022nF,5%,50V,C0G,TP,1608	
RC35	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC36	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC37	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC38	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC39	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC4	2203-000560	BY130523	C-CER,CHIP;220nF,+80-20%,25V,Y5V,TP,1608	
RC41	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
RC42	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
RC43	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
RC44	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC45	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC46	2203-000440	BY130462	C-CER,CHIP;1nF,10%,50V,X7R,TP,1608,-	
RC47	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
RC49	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC5	2203-000560	BY130523	C-CER,CHIP;220nF,+80-20%,25V,Y5V,TP,1608	
RC50	2203-005105	BY130488	C-CER,CHIP;0.68nF,5%,50V,C0G,TP,1608	
RC51	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC52	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC53	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC54	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC55	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC56	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC57	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC58	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC59	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC60	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC61	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC65	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC66	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RC68	2203-001634	BY130460	C-CER,CHIP;33nF,10%,50V,X7R,TP,1608,1.6m	
RC69	2203-001634	BY130460	C-CER,CHIP;33nF,10%,50V,X7R,TP,1608,1.6m	
RC70	2404-000232	BY130510	C-TA,CHIP;4.7uF,20%,10V,-,TP,3216	
RC71	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
RC72	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
RC73	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
RC74	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
RC8	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
RC9	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
RIC1	AK13-00007A	BY631272	IC ASIC;-,-,128 PIN,7V,-,0- +70,TQFP,Tr	
RIC2	1201-002091	BY631233	IC-OP AMP;ELM854,SOP,TP,8P;-,-,DUAL,85dB,P	
RIC3	0801-002097	BY631214	IC-CMOS LOGIC;7ST08,AND GATE,SOP,5P,110M	
RIC4	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	
RIC5	1201-000163	BY631232	IC-OP AMP;4560,SOP,8P,173MIL,DUAL,100V/m	

## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
RR1	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR10	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR12	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
RR13	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
RR14	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
RR15	2007-000431	BY230355	R-CHIP;16Kohm,5%,1/10W,TP,1608	
RR16	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR19	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
RR2	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR20	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
RR23	2007-001056	BY230273	R-CHIP;6.2Kohm,5%,1/10W,TP,1608	
RR24	2007-000097	BY230290	R-CHIP;47Kohm,5%,1/10W,TP,1608	
RR25	2007-000130	BY230352	R-CHIP;39Kohm,5%,1/10W,TP,1608	
RR26	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
RR27	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
RR28	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR29	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR3	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR30	2007-000616	BY230300	R-CHIP;24Kohm,5%,1/10W,TP,1608	
RR31	2007-000079	BY230280	R-CHIP;1.8Kohm,5%,1/10W,TP,1608	
RR32	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR33	2007-000060	BY230387	R-CHIP;100Kohm,1%,1/10W,TP,1608	
RR34	2007-000092	BY230287	R-CHIP;15Kohm,5%,1/10W,TP,1608	
RR35	2007-000092	BY230287	R-CHIP;15Kohm,5%,1/10W,TP,1608	
RR36	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
RR37	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
RR38	2007-000109	BY130423	R-CHIP;1Mohm,5%,1/10W,TP,1608	
RR4	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR40	2007-000098	BY230291	R-CHIP;56Kohm,5%,1/10W,TP,1608	
RR41	2007-000093	BY230308	R-CHIP;20Kohm,5%,1/10W,TP,1608	
RR42	2007-000093	BY230308	R-CHIP;20Kohm,5%,1/10W,TP,1608	
RR43	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR5	2007-000067	BY230340	R-CHIP;15Kohm,1%,1/10W,TP,1608	
RR51	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
RR52	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
RR54	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
RR7	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
RR8	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
RR9	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VC10	2203-000843	BY130518	C-CER,CHIP;39nF,10%,25V,X7R,TP,1608,-	
VC11	2203-000843	BY130518	C-CER,CHIP;39nF,10%,25V,X7R,TP,1608,-	
VC12	2203-000843	BY130518	C-CER,CHIP;39nF,10%,25V,X7R,TP,1608,-	
VC13	2203-000843	BY130518	C-CER,CHIP;39nF,10%,25V,X7R,TP,1608,-	
VC14	2203-000843	BY130518	C-CER,CHIP;39nF,10%,25V,X7R,TP,1608,-	
VC15	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
VC16	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
VC17	2203-000491	BY130443	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1608,-	
VC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC4	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
VC5	2404-001269	BY130513	C-TA,CHIP;10uF,20%,20V,-,TP,3528	
VC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
VC8	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
VC9	2203-000843	BY130518	C-CER,CHIP;39nF,10%,25V,X7R,TP,1608,-	
VIC1	1003-001676	BY631251	IC-MOTOR DRIVER;BD7905BFS,SSOP-A54,54P,1	
VIC2	1003-001677	BY631224	IC-MOTOR DRIVER;BA5962FVM,MSOP-8,8P,4.0x	
VR1	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR10	2007-000034	BY230338	R-CHIP;1OHM,5%,1/4W,DA,TP,3216	
VR11	2007-000034	BY230338	R-CHIP;1OHM,5%,1/4W,DA,TP,3216	
VR12	2007-000034	BY230338	R-CHIP;1OHM,5%,1/4W,DA,TP,3216	



Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
VR13	2007-000034	BY230338	R-CHIP;10HM,5%,1/4W,DA,TP,3216	
VR14	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR15	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
VR16	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
VR17	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
VR18	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
VR19	2007-000965	BY230303	R-CHIP;5.1Kohm,5%,1/10W,TP,1608	
VR2	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR24	2007-000502	70796026	R-CHIP;2.2ohm,5%,1/8W,TP,2012	
VR25	2007-000716	BY230359	R-CHIP;3.9ohm,5%,1/8W,TP,2012	
VR26	2007-000502	70796026	R-CHIP;2.2ohm,5%,1/8W,TP,2012	
VR27	2007-000716	BY230359	R-CHIP;3.9ohm,5%,1/8W,TP,2012	
VR3	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR4	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR40	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR41	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR42	2007-000093	BY230308	R-CHIP;20Kohm,5%,1/10W,TP,1608	
VR43	2007-000093	BY230308	R-CHIP;20Kohm,5%,1/10W,TP,1608	
VR5	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR6	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
VR7	2007-000124	BY230295	R-CHIP;2.2Kohm,5%,1/10W,TP,1608	
VR8	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
VR9	2007-000131	BY230353	R-CHIP;91Kohm,5%,1/10W,TP,1608	
Y1	2801-004180	BY633024	CRYSTAL-SMD;33.8688MHZ,50PPM,28-AAN,12PF	
ZAR1	2011-000475	BY230366	R-NET;33OHM,5%,1/16W,L,CHIP,8P,TP,32	
ZAR2	2011-000475	BY230366	R-NET;33OHM,5%,1/16W,L,CHIP,8P,TP,32	
ZAR3	2011-000475	BY230366	R-NET;33OHM,5%,1/16W,L,CHIP,8P,TP,32	
ZAR4	2011-000475	BY230366	R-NET;33OHM,5%,1/16W,L,CHIP,8P,TP,32	
ZAR5	2011-001085	BY230369	R-NET;82OHM,5%,1/16W,L,CHIP,8P,TP	
ZB1	2007-000070	BY230274	R-CHIP;0ohm,5%,1/10W,TP,1608	
ZC1	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC10	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC12	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC14	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC15	2203-001634	BY130460	C-CER,CHIP;33nF,10%,50V,X7R,TP,1608,1.6m	
ZC16	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC17	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC18	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC19	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC2	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC20	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC21	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC22	2203-000715	BY130516	C-CER,CHIP;3.3nF,10%,50V,X7R,TP,1608,-	
ZC25	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC26	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC27	2203-000560	BY130523	C-CER,CHIP;220nF,+80-20%,25V,Y5V,TP,1608	
ZC28	2203-000560	BY130523	C-CER,CHIP;220nF,+80-20%,25V,Y5V,TP,1608	
ZC3	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC30	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC31	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC32	2203-000783	BY130435	C-CER,CHIP;0.33NF,5%,50V,COG,TP,1608	
ZC33	2203-000140	BY130459	C-CER,CHIP;1.5nF,10%,50V,X7R,TP,1608,-	
ZC34	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC35	2203-000257	BY130440	C-CER,CHIP;10nF,10%,50V,X7R,TP,1608	
ZC36	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC37	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC38	2203-001662	BY130482	C-CER,CHIP;5.6NF,10%,50V,X7R,TP,1608	
ZC39	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC4	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC40	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC41	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	


## Electrical Parts List

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
ZC42	2203-000715	BY130516	C-CER,CHIP;3.3nF,10%,50V,X7R,TP,1608,-	
ZC43	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC44	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC45	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC46	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC47	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC48	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC49	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC5	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC50	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC51	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC52	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC53	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC54	2203-000560	BY130523	C-CER,CHIP;220nF,+80-20%,25V,Y5V,TP,1608	
ZC55	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC56	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
ZC57	2404-000284	BY130512	C-TA,CHIP;10uF,20%,16V,-,TP,3528	
ZC6	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC60	2203-006035	BY130490	C-CER,CHIP;220NF,+/-10%,10V,X7R,TP,1608	
ZC61	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC7	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZC8	2203-005148	BY130480	C-CER,CHIP;100nF,10%,16V,X7R,TP,1608	
ZIC1	0904-001840	BY631220	IC-I/O CONTROLLER:LC98600CT,16Bit,LQFP,2	
ZIC2	1105-001305	BY631227	IC-DRAM:4S641632,1MX16X4BIT,TSOP,54P,4	
ZL2	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
ZL4	2901-001281	BY330084	FILTER-EMI SMD;16V,2A,-,220000pF,2.00x1.	
ZR1	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR11	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
ZR14	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
ZR15	2007-000402	BY230314	R-CHIP;150ohm,5%,1/10W,TP,1608	
ZR18	2007-000081	BY230281	R-CHIP;2.7Kohm,5%,1/10W,TP,1608	
ZR19	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR2	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR21	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
ZR22	2007-000086	BY230283	R-CHIP;5.6Kohm,5%,1/10W,TP,1608	
ZR23	2007-001179	BY230305	R-CHIP;8.2Kohm,5%,1/10W,TP,1608	
ZR24	2007-001179	BY230305	R-CHIP;8.2Kohm,5%,1/10W,TP,1608	
ZR25	2007-000075	BY230277	R-CHIP;220ohm,5%,1/10W,TP,1608	
ZR27	2007-000107	BY230312	R-CHIP;470Kohm,5%,1/10W,TP,1608	
ZR28	2007-000132	BY230354	R-CHIP;180Kohm,5%,1/10W,TP,1608	
ZR3	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR30	2007-000134	BY230298	R-CHIP;33Kohm,5%,1/10W,TP,1608	
ZR31	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
ZR32	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
ZR33	2007-000402	BY230314	R-CHIP;150ohm,5%,1/10W,TP,1608	
ZR34	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
ZR35	2007-000102	BY230292	R-CHIP;100Kohm,5%,1/10W,TP,1608	
ZR36	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
ZR37	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
ZR38	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
ZR39	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
ZR4	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR40	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	
ZR41	2007-000084	BY230282	R-CHIP;4.7Kohm,5%,1/10W,TP,1608	
ZR5	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR58	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
ZR59	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
ZR6	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR60	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
ZR61	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
ZR62	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	

Loc. No	Reference No.	TSB Parts No.	Description ; Specification	Remark
ZR63	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
ZR64	2007-000071	BY230341	R-CHIP;22ohm,5%,1/10W,TP,1608	
ZR65	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
ZR66	2007-000115	BY230348	R-CHIP;82ohm,5%,1/10W,TP,1608	
ZR67	2007-000078	BY230279	R-CHIP;1Kohm,5%,1/10W,TP,1608	
ZR7	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR8	2007-000113	BY230328	R-CHIP;33ohm,5%,1/10W,TP,1608	
ZR9	2007-000090	BY230285	R-CHIP;10Kohm,5%,1/10W,TP,1608	


## MEMO

# 12. Block Diagram



MEMO

13. Wiring Diagram



MEMO



---


14. PCB Diagrams

---


14-1 VCR Main PCB- - - - -	14-2
14-2 DVD Main PCB - - - - -	14-4
14-3 Jack PCB - - - - -	14-6
14-4 Front PCB - - - - -	14-8
14-5 Key PCB - - - - -	14-8

14-1 VCR Main PCB

COMPONENT SIDE




CONDUCTOR SIDE









## CONDUCTOR SIDE






CONDUCTOR SIDE




14-4 Front PCB

COMPONENT SIDE




CONDUCTOR SIDE




14-5 Key PCB

COMPONENT SIDE



CONDUCTOR SIDE





## 15. Schematic Diagrams

◆ Block Identification of Main PCB- - - - -	15-2
15-1 S.M.P.S (VCR Main PCB)- - - - -	15-3
15-2 Power (VCR Main PCB) - - - - -	15-4
15-3 System Control/Servo (VCR Main PCB)- - - - -	15-5
15-4 Display/Function (VCR Main PCB) - - - - -	15-6
15-5 Secam/Connector (VCR Main PCB) - - - - -	15-7
15-6 A/V (VCR Main PCB) - - - - -	15-8
15-7 Hi-Fi (VCR Main PCB) - - - - -	15-9
15-8 Osd (VCR Main PCB) - - - - -	15-10
15-9 Main Connector (DVD Main PCB)- - - - -	15-11
15-10 DDR (DVD Main PCB) - - - - -	15-12
15-11 IEEE 1494 (DVD Main PCB)- - - - -	15-13
15-12 Video Decoder (DVD Main PCB) - - - - -	15-14
15-13 A/V Codec (DVD Main PCB) - - - - -	15-15
15-14 Audio In/Out (DVD Main PCB) - - - - -	15-16
15-15 FLASH & SRAM (DVD Main PCB) - - - - -	15-17
15-16 MUX & TM (Jack PCB) - - - - -	15-18
15-17 Coaxlal/Optical Out (Jack PCB) - - - - -	15-19
15-18 A/V Out (Jack PCB)- - - - -	15-20
15-19 Scart Jack (Jack PCB) - - - - -	15-21
15-20 A2/Nicam (Jack PCB) - - - - -	15-22
15-21 Osd/Vps/Pdc (Jack PCB) - - - - -	15-23
15-22 Front/Key (Front PCB) - - - - -	15-24

### Note

For schematic Diagram  
- Resistors are in ohms, 1/8W unless otherwise noted.


#### Special note :

Most semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.



#### Note :

Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list (may be slightly different or amended since this drawing was prepared).


#### Important safety notices :

Components identified with the mark  have the special characteristics for safety. When replacing any of these components. Use only the same type.


◆ Block Identification of Main PCB




15-1 S.M.P.S (VCR Main PCB)



15-2 Power (VCR Main PCB)







### 15-3 System Control/Servo (VCR Main PCB)






15-5 Secam/Connector (VCR Main PCB)




SECAM BLOCK

15-6 A/V (VCR Main PCB)






15-7 Hi-Fi (VCR Main PCB)






### 15-9 Main Connector (DVD Main PCB)




15-10 DDR (DVD Main PCB)

A/V CODECK




## 15-11 IEEE 1394 (DVD Main PCB)






### 15-13 A/V Codec (DVD Main PCB)




15-14 Audio In/Out (DVD Main PCB)











15-16 MUX & TM (Jack PCB)




15-17 Coaxial/Optical Out (Jack PCB)




AUDIO




15-18 A/V Out (Jack PCB)




## 15-19 Scart Jack (Jack PCB)




15-20 A2/Nicam (Jack PCB)



15-21 Osd/Vps/Pdc (Jack PCB)



15-22 Front/Key (Front PCB)





# **TOSHIBA CORPORATION**

1-1, SHIBAURA 1-CHOME, MINATO-KU, TOKYO 105-8001, JAPAN